# **DIDOJATAGO**

# Magellan™ 8500Xt





**Product Reference Guide** 

#### Datalogic ADC, Inc.

959 Terry Street Eugene, OR 97402 USA

Telephone: (541) 683-5700 Fax: (541) 345-7140

#### © 2004-2014 Datalogic, Inc.

An Unpublished Work - All rights reserved. No part of the contents of this documentation or the procedures described therein may be reproduced or transmitted in any form or by any means without prior written permission of Datalogic ADC, Inc. or its subsidiaries or affiliates ("Datalogic" or "Datalogic ADC"). Owners of Datalogic products are hereby granted a non-exclusive, revocable license to reproduce and transmit this documentation for the purchaser's own internal business purposes. Purchaser shall not remove or alter any proprietary notices, including copyright notices, contained in this documentation and shall ensure that all notices appear on any reproductions of the documentation. Should future revisions of this manual be published, you can acquire printed versions by contacting your Datalogic representative. Electronic versions may either be downloadable from the Datalogic website (www.datalogic.com) or provided

#### Disclaimer

on appropriate media. If you visit our website and would like to make comments or suggestions about this or other Dat-

Datalogic has taken reasonable measures to provide information in this manual that is complete and accurate, however, Datalogic reserves the right to change any specification at any time without prior notice.

Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A. in many countries, including the U.S.A. and the E.U. All other brand and product names may be trademarks of their respective owners.

Magellan is a registered trademark of Datalogic ADC, Inc. in many countries, including the U.S.A. and All-Weighs, First-Strike and SurroundScan are registered trademarks of Datalogic ADC, Inc. in the U.S.A. OmegaTek, Produce Rail, Productivity Index Reporting and SmartSentry are all trademarks of Datalogic ADC, Inc.

#### This product may be covered by one or more of the following patents:

alogic publications, please let us know via the "Contact Datalogic" page.

```
4603262 * 4639606 * 4652750 * 4672215 * 4699447 * 4709369 * 4749879 * 4786798 * 4792666 * 4794240 * 4798943 * 4799164 *
4820911 = 4845349 = 4861972 = 4861973 = 4866257 = 4868836 = 4879456 = 4939355 = 4939356 = 4943127 = 4963719 = 4971176 =
4971177 = 4991692 = 5001406 = 5015831 = 5019697 = 5019698 = 5086879 = 5115120 = 5144118 = 5146463 = 5179270 = 5198649 =
5200597 • 5202784 • 5208449 • 5210397 • 5212371 • 5212372 • 5214270 • 5229590 • 5231293 • 5232185 • 5233169 • 5235168 •
5237161 • 5237162 • 5239165 • 5247161 • 5256864 • 5258604 • 5258699 • 5260554 • 5274219 • 5296689 • 5298728 • 5311000 •
5327451 • 5329103 • 5330370 • 5347113 • 5347121 • 5371361 • 5382783 • 5386105 • 5389917 • 5410108 • 5420410 • 5422472 •
5426507 * 5438187 * 5440110 * 5440111 * 5446271 * 5446749 * 5448050 * 5463211 * 5475206 * 5475207 * 5479011 * 5481098 *
5491328 = 5493108 = 5504350 = 5508505 = 5512740 = 5541397 = 5552593 = 5557095 = 5563402 = 5565668 = 5576531 = 5581707 =
5594231 • 5594441 • 5598070 • 5602376 • 5608201 • 5608399 • 5612529 • 5629510 • 5635699 • 5641958 • 5646391 • 5661435 •
5664231 • 5666045 • 5671374 • 5675138 • 5682028 • 5686716 • 5696370 • 5703347 • 5705802 • 5714750 • 5717194 • 5723852 •
5750976 = 5767502 = 5770847 = 5786581 = 5786585 = 5787103 = 5789732 = 5796222 = 5804809 = 5814803 = 5814804 = 5821721 =
5822343 • 5825009 • 5834708 • 5834750 • 5837983 • 5837988 • 5852286 • 5864129 • 5869827 • 5874722 • 5883370 • 5905249 •
5907147 * 5923023 * 5925868 * 5929421 * 5945670 * 5959284 * 5962838 * 5979769 * 6000619 * 6006991 * 6012639 * 6016135 *
6024284 = 6041374 = 6042012 = 6045044 = 6047889 = 6047894 = 6056198 = 6065676 = 6069696 = 6073849 = 6073851 = 6094288 =
6112993 • 6129279 • 6129282 • 6134039 • 6142376 • 6152368 • 6152372 • 6155488 • 6166375 • 6169614 • 6173894 • 6176429 •
6188500 • 6189784 • 6213397 • 6223986 • 6230975 • 6230976 • 6244510 • 6259545 • 6260763 • 6266175 • 6273336 • 6276605 •
6279829 = 6290134 = 6290135 = 6293467 = 6303927 = 6311895 = 6318634 = 6328216 = 6332576 = 6332577 = 6343741 = 6454168 =
6478224 = 6568598 = 6578765 = 6705527 = 6857567 = 6974084 = 6991169 = 7051940 = 7170414 = 7172123 = 7201322 = 7204422 =
7215493 * 7224540 * 7234641 * 7243850 * 7374092 * 7407096 * 7490770 * 7495564 * 7506816 * 7527198 * 7527207 * 7537166 *
7562817 • 601 26 118.6 • AU703547 • D312631 • D313590 • D320011 • D320012 • D323492 • D330707 • D330708 • D349109 • D350127
D350735 D351149 D351150 D352936 D352937 D352938 D352939 D358588 D361565 D372234 D374630 D374869 D374869 D352939 D358588 D361565 D372234 D374630 D374869 D374860 D374869 D374860 D37486
D375493 * D376357 * D377345 * D377346 * D377347 * D377348 * D388075 * D446524 * D606544 * EP0256296 * EP0260155 *
EP0260156 • EP0295936 • EP0325469 • EP0349770 • EP0368254 • EP0442215 • EP0498366 • EP0531645 • EP0663643 • EP0698251 •
EP01330772 • EP870761 • GB2252333 • GB2284086 • GB2301691 • GB2304954 • GB2307093 • GB2308267 • GB2308678 • GB2319103 •
GB2333163 = GB2343079 = GB2344486 = GB2345568 = GB2354340 = ISR107546 = ISR118507 = ISR118508 = JP1962823 = JP1971216 =
JP2513442 • JP2732459 • JP2829331 • JP2953593 • JP2964278 • MEX185552 • MEX187245 • RE37166 • RE40071
```

# **TABLE OF CONTENTS**

Section 1. Introduction	1-1
Manual Overview	1-2
How to Use This Manual	1-3
Scanner and Scanning-Scale Nomenclature	1-4
Connectors	1-5
Physical Parameters	1-6
Scanning	1-6
EAS Tag Deactivation System	1-6
Weighing	1-7
Warm-Up Time	1-8
Electrical Specifications	1-9
Power Supply	
Laser and Product Safety	
Labeling	1-13
Agency Compliances	
Barcodes Supported	
Technical Support	
Datalogic Website Support	
Reseller Technical Support	
Telephone Technical Support	1-16
Section 2. Site Preparation and Installation	
Pre-Installation Considerations	2-2
Checkstand Design	2-3
Scanner Installation	
Scanner Maintenance	
References	
Scanner Usage	
Site Preparation Overview	
Ventilation and Spacing	
Service Access	
Power Installation	
Grounding	
Checkstand Preparation	
Liquid Spills and Moisture	2-11

Counter Cutout	2-11
Checkstand Mounting	2-18
Installation Overview	2-18
Unpacking	2-19
Operational Verification	
Diagnostic Modes	
Cables & Connections	
Remote Scale Display Placement/Installation	
Lighting Considerations	
Viewing Angle	
Remote Display Cabling	
Model 8300RD: Placing and Installing the Remote Display	
Model 960RD: Placing and Installing the Remote Scale Display	
Changing Weighing Modes	
Set-Up & Installation	
Set-up	
Installation	
System Power-Up Recap	
Section 3. Operation and Maintenance	3-1
Section 3. Operation and Maintenance  Scanning Items	
	3-1
Scanning Items	3-1 3-3
Scanning Items Deactivating Security Labels	3-1 3-3 3-5
Scanning Items  Deactivating Security Labels  Proper Weighing Technique	3-1 3-3 3-5 3-6
Scanning Items  Deactivating Security Labels  Proper Weighing Technique  Operational Controls	3-1 3-3 3-5 3-6 3-6
Scanning Items  Deactivating Security Labels  Proper Weighing Technique  Operational Controls  Operational Modes	3-1 3-3 3-5 3-6 3-6
Scanning Items  Deactivating Security Labels  Proper Weighing Technique  Operational Controls  Operational Modes  Power-Up/Selftest & Pre-Operation	3-13-33-53-63-63-63-8
Scanning Items  Deactivating Security Labels  Proper Weighing Technique  Operational Controls  Operational Modes  Power-Up/Selftest & Pre-Operation  Operating Mode	3-13-33-53-63-63-63-83-9
Scanning Items Deactivating Security Labels Proper Weighing Technique Operational Controls Operational Modes Power-Up/Selftest & Pre-Operation Operating Mode Additional Functions	3-13-33-53-63-63-63-83-9
Scanning Items	3-13-33-53-63-63-63-93-9
Scanning Items	3-13-33-53-63-63-63-93-93-9
Scanning Items Deactivating Security Labels Proper Weighing Technique Operational Controls Operational Modes Power-Up/Selftest & Pre-Operation Operating Mode Additional Functions Programming Diagnostic Mode Scanner and Scale Reset	3-13-33-53-63-63-83-93-93-93-9
Scanning Items Deactivating Security Labels Proper Weighing Technique Operational Controls Operational Modes Power-Up/Selftest & Pre-Operation Operating Mode Additional Functions Programming Diagnostic Mode Scanner and Scale Reset Scale Adjustments	3-13-33-53-63-63-63-93-93-93-93-10
Scanning Items Deactivating Security Labels Proper Weighing Technique Operational Controls Operational Modes Power-Up/Selftest & Pre-Operation Operating Mode Additional Functions Programming Diagnostic Mode Scanner and Scale Reset Scale Adjustments Operational Maintenance	3-13-33-53-63-63-83-93-93-93-103-12
Scanning Items Deactivating Security Labels Proper Weighing Technique Operational Controls Operational Modes Power-Up/Selftest & Pre-Operation Operating Mode Additional Functions Programming Diagnostic Mode Scanner and Scale Reset Scale Adjustments Operational Maintenance Vertical Scan Window Replacement	3-13-33-53-63-63-63-83-93-93-93-103-123-15

Diagnostic Procedures	4-2
Error Codes	4-3
Scale Error Reporting	4-6
Flowcharts	4-7
Section 5. Calibration Procedures, Single Interval	
Description of Calibration Sequence	
Motion Test	
Automatic Zero Tracking Test	
Preparing the Scanner/Scale for Calibration	
Calibrating the Scale (Pounds & Kilograms)	
Calibration Verification (U.S. Pounds)	
Increasing-Load Test (Phase 1)	
Shift Test	5-9
Increasing- Load Test (Phase 2)	5-10
Blanking Test	5-10
Decreasing-Load Test	5-11
Return to Zero Test	5-11
Calibration Verification (Kilograms)	5-12
Increasing-Load Test (Phase 1)	5-12
Shift Test (Metric)	5-13
Increasing- Load Test (Phase 2)	
Blanking Test	
Decreasing-Load Test	
Return to Zero Test	
Section 6. Calibration Procedures, Dual Interval	
Description of Calibration Sequence	
Motion Test	
Automatic Zero Setting Test	
Preparing the Scanner/Scale for Calibration	
Calibrating the Scale (Pounds & Kilograms)	
Calibration Verification (Pounds)	
Calibration Verification (Kilograms)	6-13
Section 7. Programming	7-1
Introduction to Label Programming	

Understanding the Basics	7-1
Integrating the Scanner With Your Host System	7-1
Customizing Your Scanner's Operation	7-2
Programming Overview	7-3
Programming via Handheld Device	7-3
What Is Programming Mode?	7-4
Entering and Exiting Programming Mode	7-4
Programming Session	7-5
LED and Beeper Indicators	7-9
If You Make a Mistake	7-9
Return to Factory Settings	7-9
Test Mode	7-10
General Scanner and Scale Features	7-11
Double Read Timeout	7-11
Laser Timeout	7-13
Motor Timeout	7-15
Green LED Idle State	7-18
Scanner Button Options	7-19
Power-up Beep Control	7-21
Good Read Beep Control	7-22
Good Read Beep Frequency	7-23
Good Read Beep Length	7-25
Good Read Beep Volume	7-26
Good Read When to Indicate	7-29
Scale Enable	7-32
Scale Enforced Zero Return	7-33
Scale Interface Type	
Remote Display — Enable/Disable	7-37
Aux Port Mode	7-38
Laser Failure Mode	
Productivity Index Reporting (PIR)/Cashier Training (CT)	
EAS Features — Sensormatic	7-42
EAS Mode	
EAS Beep Duration	
EAS Retry Count	
Manual EAS Deactivation Push Button	
EAS Deactivation Duration — Coupled	7-51

EAS Deactivation Duration — Retry	
EAS Deactivation Duration — Manual	
EAS Features — Checkpoint	
EAS Active State	
EAS Timeout	
Interface Related Features	
Interface Type	
Maximum Host-Transmitted Message Length	
Number of Host Transmission Buffers	
Global Prefix	
Global Suffix	
IBM Features	
IBM Interface Options	
IBM Scale Address	
IBM Transmit Labels in Code 39 Format	
OEM USB Interface Options	
OEM USB Scanner Device Type	
RS-232 Features	
RS-232 Baud Rate	
RS-232 Number of Data Bits	
RS-232 Number of Stop Bits	
RS-232 Parity	
RS-232 Hardware Control	
RS-232 Intercharacter Delay	
RS-232 Software Flow Control	7-101
RS-232 Host Echo	
RS-232 Host Echo Quiet Interval	
RS-232 Ignore Host Commands	
RS-232 TTL	7-105
RS-232 TTL Invert	7-106
RS-232 Beep on ASCII BEL	7-107
RS-232 Beep After Weigh	7-108
RS-232 Beep on Not on File	7-109
RS-232 ACK NAK Enable	7-110
RS-232 ACK Character	7-112
RS-232 NAK Character	7-113
RS-232 Retry on ACK NAK Timeout	7-114

RS-232 ACK NAK Timeout Value	. 7-	1	15
RS-232 ACK NAK Retry Count			
RS-232 ACK NAK Error Handling			
RS-232 Label ID Control			
Single Cable RS-232 Options			
Single Cable RS-232 Scanner Only Protocol			
Single Cable RS-232 RTS CTS Selection			
Single Cable RS-232 Use BCC	. 7-	12	26
Single Cable RS-232 Use ACK/NAK			
Single Cable RS-232 Use STX	. 7-	12	28
Set Single Cable RS-232 STX Character	. 7-	12	29
Single Cable RS-232 Use ETX	. 7-	13	30
Set Single Cable RS-232 ETX Character	. 7-	1.	31
Single Cable RS-232 Datalogic Extensions	. 7-	1.	32
Symbology Programming	. 7-	1.	33
Coupon Control	. 7-	1.	33
UPC-A Enable			
UPC-A Number System Character Transmission	. 7-	1.	36
UPC-A Check Character Transmission	. 7-	13	37
Expand UPC-A to EAN-13			
UPC/EAN AIM ID	. 7-	13	39
UPC-A Label ID			
UPC-A 2-Digit Supplemental Label ID	. 7-	14	41
UPC-A 5-Digit Supplemental Label ID	. 7-	14	42
UPC-A 128 Supplemental Label ID			
UPC-E Enable			
UPC-E Number System Character Transmission			
UPC-E Check Character Transmission			
Expand UPC-E to UPC-A			
Expand UPC-E to EAN-13			
UPC-E Label ID			
UPC-E 2-Digit Supplemental Label ID			
UPC-E 5-Digit Supplemental Label ID			
UPC-E 128 Supplemental Label ID			
EAN-13 Enable			
EAN-13 First Character Transmission			
EAN-13 Check Character Transmission	. 7-	1	55

EAN-13 ISBN Conversion Enable	7-156
EAN 13 Label ID	
EAN-13 2-Digit Supplemental Label ID	
EAN-13 5-Digit Supplemental Label ID	
EAN-13 128 Supplemental Label ID	
Bookland AIM ID	
Bookland Label ID	
EAN-8 Enable	
EAN-8 Check Character Transmission	
Expand EAN-8 to EAN-13	
EAN 8 Label ID	
EAN-8 2-Digit Supplemental Label ID	
EAN-8 5-Digit Supplemental Label ID	
EAN-8 128 Supplemental Label ID	
EAN-8 Decoding Levels	
Other UPC/EAN Options	
UPC/EAN Reconstruction	
Price Weight Check	
Enable EAN Two Label	
Addons	
UPC-A and EAN-13 Decoding Levels	
GTIN Enable	
GTIN Label ID	7-185
GTIN 2-Digit Supplemental Label ID	
GTIN 5-Digit Supplemental Label ID	
GTIN Code 128 Supplemental Label ID	7-188
DataBar Omnidirectional Enable	
DataBar Omnidirectional Check Character Transmission	7-190
DataBar Omnidirectional/EAN-128 Emulation	7-191
DataBar Omnidirectional 2D Component Enable	7-192
DataBar Omnidirectional AIM ID	7-193
DataBar Omnidirectional Label ID	7-194
DataBar Expanded Enable	7-195
DataBar Expanded EAN-128 Emulation	7-196
DataBar Expanded 2D Component Enable	7-197
DataBar Expanded AIM ID	7-198
DataBar Expanded Label ID	7-199

DataBar Expanded Length Control	. 7-200
DataBar Expanded Length 1	. 7-201
DataBar Expanded Length 2	. 7-202
Code 39 Enable	. 7-203
Code 39 Start Stop Character Transmission	. 7-204
Code 39 Check Character Calculation	. 7-205
Code 39 Check Character Transmission	. 7-206
Code 39 Full ASCII	. 7-207
Code 39 AIM ID	. 7-208
Code 39 Label ID	. 7-209
Code 39 Length Control	. 7-210
Code 39 Length 1	. 7-211
Code 39 Length 2	. 7-212
Code 39 Stitching	. 7-213
Code 32 Enable	. 7-214
Code 32 Start Stop Character Transmission	. 7-215
Code 32 Check Character Transmission	. 7-216
Code 32 Label ID	. 7-217
Code 128 Enable	
Code 128 Transmit Function Characters	
Convert Code128 to Code 39	. 7-220
Code 128 AIM ID	. 7-221
Code 128 Label ID	. 7-222
Code 128 Length Control	. 7-223
Code 128 Length 1	. 7-224
Code 128 Length 2	. 7-225
Code 128 Stitching	
EAN-128 Enable	
EAN 128 AIM ID	
EAN 128 Label ID	
Interleaved 2 of 5 (I 2 OF 5) Enable	
I 2 of 5 Check Character Calculation	
I 2 of 5 Check Character Transmission	
I 2 of 5 AIM ID	
I 2 of 5 Label ID	
I 2 of 5 Length Control	
I 2 of 5 Length 1	. 7-236

12 - 45 1	7 227
12 of 5 Length 2	
12 of 5 Stitching	
Codabar Start Stop Character Transmission	
Codabar Start Stop Character Set	
Codabar Start Stop Character Match	
Codabar Check Character Calculation	
Codabar Check Character Transmission	
Codabar AIM ID	
Codabar Label ID	
Codabar Length Control	
Codabar Length 1	
Codabar Length 2	
Codabar Stitching	
Code 93 Enable	
Code 93 AIM ID	
Code 93 Label ID	
Code 93 Length Control	
Code 93 Length 1	
Code 93 Length 2	
Code 93 Stitching	
MSI/Plessey Enable	
MSI/Plessey Check Character Calculation	7-260
MSI/Plessey Number of Check Characters	
MSI/Plessey Check Character Transmission	
MSI/Plessey AIM ID	7-263
MSI/Plessey Label ID	7-264
MSI/Plessey Length Control	7-265
MSI/Plessey Length 1	7-266
MSI/Plessey Length 2	7-267
MSI/Plessey Stitching	7-268
Standard 2 of 5 Enable	7-269
Standard 2 of 5 Check Character Calculation	7-270
Standard 2 of 5 Check Character Transmission	7-271
Standard 2 of 5 AIM ID	
Standard 2 of 5 Label ID	
Standard 2 of 5 Length Control	

Standard 2 of 5 Length 1	7-275
Standard 2 of 5 Length 2	
Standard 2 of 5 Stitching	
Appendix A. LED/Beeper Indications & Controls	A-1
Controls and Indicators	
LED and Beeper Indications	A-2
Volume/Tone Push Button	A-6
Manual EAS Deactivation Push Button	A-8
Scale Zero Push Button	A-9
Calibration Switch	A-10
Appendix B. Cable Information	B-1
Introduction	B-1
General Specifications	B-1
RS-232 Cable Pinout	B-2
Scanner	B-2
Scale	B-3
IBM Cable Pinout	B-4
Scanner and Scale	B-4
OEM USB Cable Pinout	B-5
Scanner and Scale	B-5
Auxilliary Port	B-6
External Handheld Input	
Power Cable	B-7
Connector Hardware	B-7
Remote Display	B-8
Connector Hardware	
EAS Comm Port — Sensormatic	B-9
EAS Deactivator Control Box Connection	
EAS Interlock Connector — Checkpoint	
Appendix C. Keypad	C-1
Appendix D. Host Commands	D-1
Accepting Commands from an RS-232 Scanner Host	

Appendix E. Factory Defaults	E-1
Appendix F. Handheld Data Format Requirements	F-1
Handheld Data Format Requirements General	
Datalogic Handheld Data Format Requirements	F-2
AIM Formats	F-9

# **NOTES**

# **Section 1**

### Introduction

This Product Reference Guide contains comprehensive instructions on how to install the scanner or scanning-scale (either model may be termed "scanner" for the purpose of simplicity in this manual), how to program it using special programming feature barcode labels, and advanced user information as described in the following overview.

Because of differences due to multiple model types and options, the llustrations shown in this manual may vary from the model(s) in use at your location.

#### **Manual Overview**

Chapter 1, Introduction, presents the manual's contents, describes features and specifications, provides regulatory and safety information, and lists the barcode symbologies the scanner will read.

Chapter 2, Site Preparation and Installation, supplies physical dimensions for the scanner or scanning-scale and its most common accessories, and details counter preparation and installation. Cable routing, connection and testing are also explained in this section.

Chapter 3, Operation and Maintenance, describes use and maintenance; providing details about operator controls, programming and diagnostic modes, scale "zeroing" and calibration. Scanner and scale routine maintenance are outlined in this section as well.

Chapter 4, Problem Isolation, provides an outline of three scanning-scale test modes: Selftest, Operational Tests and Diagnostic Tests. Descriptions of the error indications if the scanner detects a system problem and troubleshooting flowcharts to aid in problem resolution are also presented.

Chapter 5, Calibration Procedures, Single Interval, explains scale calibration and verification procedures, including procedures for calibrating the scale in pounds as well as kilograms.

Chapter 7, Programming, details procedures and provides custom barcodes for setting programmable scanner and scanning-scale features. This section is organized by the categories: General Features, Interface Related Features and Symbology Related Features.

Appendix A, LED/Beeper Indications & Controls, lists the various functions and indications of the scanning-scale control panel features.

Appendix B, Cable Information, outlines wire requirements, connector specifications and pinout details for associated product cabling.

Appendix C, Keypad, furnishes barcodes representing the digits and characters required to enter extended programming data needed during certain programming sessions.

Appendix D, Host Commands, contains a partial listing of available host commands that can be used with a compatible host interface.

Appendix E, Factory Defaults, provides a listing of factory default settings based on the most common interface.

Appendix F, Handheld Data Format Requirements, provides additional references.

#### **How to Use This Manual**

You'll find it helpful to familiarize yourself with the first section of this manual, since it provides both a general description of the product's features and an overview of the manual's contents and organization. Reference the other sections as required for information about scanner or scanning-scale installation, operation, maintenance, calibration and barcode programming.

#### **Manual Conventions**



'NOTE' blocks contain information that is helpful and recommended. They provide information that is critical to operations and/or procedures described in this manual.



'LEGAL NOTE' blocks indicate procedures or activities which may be regulated under law by governmental agencies. It is your responsibility to ensure compliance with the regulations that govern installation of weighing devices.



'CAUTION' blocks inform you that proper handling (adherence to the procedures described) is required to avoid damage to equipment and/or property.



'WARNING' blocks alert you to potential physical harm or injury. These statements do not include potentially fatal hazards, which would be designated as 'DANGER' blocks. Use of this product does not warrant the need for a DANGER block.

### **Scanner and Scanning-Scale Nomenclature**

Controls, indicators and other nomenclature are shown in Figure 1-1 and Figure 1-1.



EAS capabilities are optional, and may or may not be enabled.


Scanner LED (Green) Volume/Tone Push Button Weighing Surface — Lean Oversize Produce Here Scale LED (Yellow) EAS LED 四 (Tri-Color) Bonnet **Vertical Window** Horizontal Window Scale Zero Push Button Manual EAS' [(((()))] **Deactivation Push** Button Produce Rail All Weighs™ Platter

Figure 1-1. Scanning-Scale Nomenclature


#### **Connectors**

The appearance of the connector panel (Figure 1-2) will vary depending upon the factory options purchased with your model. Reference two types of possible optional EAS connections in Figure 1-3a and Figure 1-3b.

Figure 1-2. Connector Panel



**Figure 1-3. Optional EAS Cable Connections** 



### **Physical Parameters**

This section provides specifications for performance, environmental and electrical parameters. Reference the second section of this manual, Site Preparation and Installation, for physical measurements of all models and some accessories.

### **Scanning**

The scanner has a scan zone between the two windows where the scanner projects laser light in order to scan items. Two separate projections, one from the horizontal window and one from the vertical window, combine to form a zone where barcode labels are read. Refer to the Operation and Maintenance section of this manual for more details about the topic: Scanning Items.

### **EAS Tag Deactivation System**

Scanners can be ordered from the factory to include an optional EAS (Electronic Article Surveillance) deactivation system. Two different EAS system types are available: Checkpoint<sup>1</sup> and Sensormatic<sup>2</sup>.

The AMB-9010 deactivation system requires connection as shown in Figure 1-3a. Reference Chapter 3, "Deactivating Security Labels" for more information about its use.

Contact Technical Support for information about installation of the Sensormatic<sup>®</sup> AMB-9010 EAS controller box. Additional details about this system can be referenced under the following topics:

- Chapter 3, "Deactivating Security Labels"
- Chapter 7, "EAS Features Sensormatic"

<sup>1.</sup> Checkpoint is a registered trademark of Checkpoint Systems, Inc.

<sup>2.</sup> Sensormatic is a registered trademark of Sensormatic Electronics Corporation.

### Weighing

Specifications for scale capacity, settling time, minimum and maximum static weight, zeroing, and warm-up time are given below. For more information regarding the topic: Proper Weighing Technique, refer to the Operation and Maintenance section of this manual.

#### **Rated Weight Capacity**

The scale's operational weight capacity is:

- 30.00 pounds, displayed in 0.01 increments
   OR
- 15.000 kilograms<sup>1</sup>, displayed in 0.005 increments.

#### **Minimum Increment**

The minimum weight that can be accurately measured by the scale is 0.02 lb. (0.005 kg).

#### **Maximum Static Weight (Overload)**

A maximum static weight of 150 pounds (68 kg) can be sustained by the scale without incurring damage or degrading performance.

#### **Automatic Zero Maintenance**

The scale's software constantly monitors and adjusts the Zero point as long as the deviation is within acceptable limits<sup>2</sup>, while compensating for any debris accumulation or removal. During power-up, the scale automatically re-zeros after verifying that all subsystems are functional. Additionally, the scale may be manually "zeroed" by pushing the Scale Zero Push Button located on the top of the vertical enclosure.

<sup>1.</sup> The scale can also be set at the factory for 9.99 kg max.

Acceptable limitis of deviation are set at -0.2 to +0.6 pounds (-0.078kg to 0.23kg), which is -0.67 to +2.0% of total capacity.

### **Warm-Up Time**

There are two pertinent warm-up times that apply to the scanning-scale:



The two warm-up periods can be performed concurrently, thereby reducing the total required warm-up time to 60 minutes.

#### **Thermal Equilibrium**

When the unit is moved from a cooler temperature (such as a storage area) to a warmer environment (such as a checkstand location), 60 minutes must be allowed to acclimate the unit to ambient conditions prior to calibration or operation.

#### **Power-up**

Once installed and powered up, a warm-up time of 15 minutes must be allowed before calibrating or performing weighing operations.


#### **User Configurable Warm-up**

The user may configure the unit for a pre-programmed warm-up time that is activated every time the scanner is powered up. During this time, the scale is viewed by the POS terminal as off-line.



Contact Technical Support to learn more about this advanced programmable feature.

**Figure 1-4. Environmental Specifications** 



### **Electrical Specifications**

Before installation, always verify that the site's electrical service meets the scanning-scale's requirements. The scanner has been engineered for compatibility with most international electrical systems operating in ranges from 100 to 240VAC at 50-60 Hz. Verify that the power source will supply "clean" electrical power to the equipment; that is, it must be free of excess electrical noise.

Check the IEC power cord shipped with the scanning-scale. If the cord will not plug into your AC power receptacle, the power cord shipped is not compatible with your electrical system. Please contact your distributor immediately to receive the necessary information and components to ensure electrical compatibility.

### **Power Supply**

The scanner utilizes a single power supply for all models. Unique installation and international connections are accomplished through selection of the proper IEC power cord

VOLTAGE 100-240VAC ±10% FREQUENCY 50-60 Hz CURRENT (RMS) 0.5 Amps @ 100V PART NUMBER 8-0761



Safe operation of your scanner or scanning-scale requires properly grounded electrical outlets. Be sure to have a qualified electrician certify the earth-ground connection on circuits which will be used to power the unit.



The scanner is powered on/off by connecting/disconnecting its AC power supply.

### **Laser and Product Safety**

Laser safety requirements are based on IEC Standard Publication 60825-1 (2007) and CDRH 21CFR, Chapter 1, Subchapter J and (CDRH) Laser Product Performance Standard, User information [1040.10(h)1]:

- User Maintenance. No user maintenance of the system other than cleaning of the scan windows is required.
- Radiant Energy. The scanner is an IEC Class 1 and CDRH IIa laser product. The system uses two embedded Class 3B Visible Laser Diodes (VLDs) operating at 650.0 nm, in an opto-mechanical scanner, resulting in less than 2.71μW radiated power as observed through a 7mm aperture and averaged over 10 seconds. Maximum emitted peak output power at the lower window is 1120μW @ 60μS pulse. No attempt should be made by the user to remove the protective housing of the scanning-scale.
- Laser Light Viewing. The horizontal and vertical scan windows are the only apertures through which laser light may be observed in this product.

Exposure to the light emitted from the scan windows has been shown not to be harmful. The safety record of barcode scanning is perfect after millions of hours of use worldwide. This safe and efficient use of laser technology has gained wide acceptance in industries throughout the world.

Operators and installers of the unit should observe the following cautions and warnings:



Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous laser light exposure.

The use of optical instruments with the scanner will increase eye hazard. (Optical instruments include binoculars, microscopes, telescopes and magnifying glasses. This does not include eyeglasses worn by the user).

CAUTION

To prevent exposure to laser light, do not remove the protective housing of the scanner. There are no user-serviceable parts inside your scanner or scanning-scale.

#### Safety precautions to be taken:



**CAUTION** 

No adjustments or alteration of the scanner or scanning-scale housing are to be attempted by the user.

The failure of the facet wheel motor while the unit is continuing to emit a laser beam causes the emission levels to exceed those for inherently safe operation. The unit has safeguards to prevent this occurrence. If, however, a stationary laser beam is ever emitted, the failing unit should be disconnected from its power supply until repaired by a qualified technician.



WARNING

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his or her own expense.


This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numerique de la classe A respecte toute les exigences du Reglement sur le material broilleur du Canada.

# Labeling

Regulatory, reference and safety labeling is shown in Figure 1-5.

Figure 1-5. Labeling



# **Agency Compliances**

The scanner and scanning-scale meets or exceeds the requirements for its device type as set forth by the following agencies and regulations:

COUNTRY	COMPLIANCE	COMMENTS
Electrical		
United States	UL60950-1	UL Approved and TÜV NRTL
Canada	CAN/CSA C22.2 No. 60950-1	TÜV NRTL
World	IEC60950 / IEC 60825-1	TÜV CB
Australia	AS 3260	AS (power adapter)
Emmisions United States	47CFR Part 15J	FCC
Canada	ICES-0003	Class B
Europe	EN 55022	Class B
Australia/N Zealand	AS/NZ 3548	Class B
Japan	VCCI	Class B
Taiwan	CNS 13438	Class B
Safety & Emissions	EMC Directive 204/108/EC	CE Mark
	LV Directive 73/23/EEC	CE Mark
Laser Safety United States	CDRH, 21CFR Part 1040	CDRH Class IIa laser device
Canada	same as CDRH	SGM-1 specification
Australia	AS 2211	
Weights & Measures United States	NIST Handbook 44 (Dept. of Commerce)	
Canada	Measurement Canada	
Australia	National Measurement Institute (NMI)	NMI R76, Parts 1 and 2
New Zealand	1987 Part 1	Reg. 4, Reg. 4A
Mexico	NOM	NOM-019-SCF1-1994
New York	New York Certificate	

Contact Datalogic® Marketing at (541) 683-5700, or your Datalogic representative for a complete listing of approvals for other countries.

### **Barcodes Supported**

The scanner can read/decode the following barcode types (symbologies):

- UPC Versions A & E
- UPC Supplementals and Add-ons (2 & 5 digit supplimentals, Coupon code and Code 128)
- Plural Stage Dual UPC Barcodes for Japan (2 label read)
- DataBar Omnidirectional, DataBar Expanded, DataBar Stacked
- EAN-8 & 13
- JAN-8 & 13
- UCC/EAN 128
- Code 39
- Code 39 full ASCII
- Code 128 (including conversion to Code 39)
- Code 93
- Interleaved 2 of 5 (I 2 of 5)
- Code 32 (Italian Pharmaceutical Code)
- Codabar
- MSI/Plessey

## **Technical Support**

### **Datalogic Website Support**

The Datalogic website (www.datalogic.com) is the complete source for technical support and information for Datalogic products. The site offers product support, product registration, warranty information, product manuals, product tech notes, software updates, demos, and instructions for returning products for repair.

### **Reseller Technical Support**

An excellent source for technical assistance and information is an authorized Datalogic reseller. A reseller is acquainted with specific types of businesses, application software, and computer systems and can provide individualized assistance.

### **Telephone Technical Support**

If you do not have internet or email access, you may contact Datalogic technical support at (541) 349-8283 or check the back cover of your manual for more contact information.

# **Section 2**

# **Site Preparation and Installation**

This section provides a reference for preparing most checkstands to receive the scanner or scanning-scale. Included are physical parameters and instructions for checkstand preparation, power and ventilation considerations, cable routing information and unit installation.


Site Preparation lists all procedures necessary to prepare the checkstand. The instructions that follow, titled Checkstand Preparation, detail steps for the three models that are available (shown in Figure 2-1 below) to facilitate easy installation into almost any checkstand application around the world:

- Model 8503 Long Scanner with Sensormatic Coil
- Model 8504 Long Scanner/Scale with Sensormatic Coil
- Model 8505 Short Scanner with Sensormatic Coil

Some models are designed to fit with little or no modification into openings cut for previously installed scanners such as other Magellan<sup>TM</sup> scanners, or NCR® scanner models 7820/24 and 7870. Other models are designed for applications with smaller footprint requirements.

Once the procedures in this section are complete, the scanner is ready for operation; with the exception that if a scanning-scale was installed, calibration will be required before placing the unit into operation. You must consult the local weights and measures authority to ensure that all legal requirements are met concerning calibration and certification. Section 5, *Calibration Procedures, Single Interval*, contains detailed procedures for calibrating the scale in either pounds or kilograms.

Figure 2-1. The Scanner/Scale Family



#### **Pre-Installation Considerations**

It should be noted that the scope of this manual does not encompass all factors related to worker safety and checkstand design. It does, however, offer a list of considerations that may be helpful in ensuring greater safety and productivity. Careful planning using these general guidelines should result in a more efficient, comfortable work environment.

The U.S. Bureau of Labor Statistics reports that the incidence of repetitive motion injuries has increased dramatically in recent years. Checkstand design and scanner installation and operation procedures can reduce the risk of repetitive motion injuries, but not eliminate it.

Although there are currently no formal guidelines for checkstand ergonomics, the Food Marketing Institute (FMI) and the National Institute of Occupational Safety (NIOSH) of the Department of Health and Human Services have released the reports listed at the end of these recommendations. These reports contain useful suggestions for ergonomic improvement of checkstand designs and scanner installation, maintenance and usage. Portions of the reports are summarized below. For copies of the complete reports, or to inquire about any modifications to the recommendations, contact FMI and NIOSH at the addresses listed at the end of these recommendations.

### **Checkstand Design**

- 1. Select a design which allows load-sharing by several muscle groups (for example designs which allow the cashier to use both hands for scanning and bagging).
- 2. Select checkstands which deliver products to the cashier on an input belt and do not require the unloading of items from a cart. These designs put less stress on the cashiers' shoulders and back.
- 3. Minimize the distance between the input and take-away conveyors (i.e., the distance the cashier has to reach to move the products).
- 4. Minimize the width of the input conveyor to reduce the cashier's reach to items on the far side of the belt; use a diverter to direct products closer to the cashier.
- Select a design which encourages the cashier to slide products
  across the scanner rather than gripping and lifting. Make sure the
  horizontal surface of the scanner is flush with all surrounding surfaces.
- 6. Choose a design which integrates the scanner and scale to eliminate extended reaches and lifts during weighing tasks.
- 7. Provide an easily accessible bag stand at a height 13 17 inches (33 43.2 cm) lower than the top surface of the checkstand to reduce stresses to the shoulders, elbows, and risks associated with lifting products into bags.
- 8. Do not position the bag stand between the cashier and the scanner, due to the increased reach involved.
- 9. Position the scanner's horizontal scanning surface 34 36 inches (86.4 91.4 cm) above the floor. Maintain a minimum of five inches (12.7 cm) clearance between elbows and work surfaces.
- 10. Provide adjustable keyboard mounting (height, tilt, and horizontal reach).
- 11. Position the printer, cash drawer, and other checkstand devices the cashier uses within easy reach (less than 18 inches/45.7 cm).
- 12. Provide adequate toe space, foot rests or rails, antifatigue mats, and where feasible, an adjustable seat or stand against which the cashiers can lean.

#### **Scanner Installation**

- 1. Mount the horizontal surface of the scanner flush with the countertop to encourage slide scanning rather than lifting.
- 2. Position the centerline of the scanner read area 8 10 inches (20.3 25.4 cm) from the edge of the checkstand (cashier side).

#### Scanner Maintenance

- 1. Keep scanner windows clean. This will improve productivity and reduce rescans.
- 2. Replace scanner glass when excessive scratches are evident.

#### References

Anonymous, 1992, "Ergonomic Improvement of Scanning Checkstand Designs",

Food Marketing Institute 800 Connecticut Ave. N.W.

Washington, D.C. 20006

Grant, Katharyn A. et al., 1992, "Ergonomic Evaluation of Checkstand Designs in the Retail Food Industry", National Institute of Occupational Safety and Health 4676 Columbia Parkway Cincinnati, Ohio 45226

### **Scanner Usage**

 Minimize handling of heavy/bulky products. Leave these items in the cart and use an alternative entry method such as key entry of short PLUs, or handheld scanning. Regularly train cashiers in proper scanning methods and ergonomics principles, such as:

Develop a smooth fluid motion during scanning, sharing work equally between hands.

Use the entire hand for grasping and lifting items.

Since the scanner reads labels on all four sides plus the top and bottom, there is no need to turn a barcode toward either of the scanner windows.

Develop efficient scanning motions, not necessarily faster hand movements. Simply slide the item across the scanner's horizontal window with as little orientation motion as necessary.

Leave items in an upright position; do not lift and tilt.

Learn how the scanner functions and where the scanning area is located.

Do not favor either the vertical or horizontal window; slide items across the scanner in their natural orientations on the checkstand as much as possible.

### **Site Preparation Overview**

Consider the following factors before installing the scanner/scanning-scale and its optional Remote Scale Display.

**Ventilation Requirements.** The scanner operates without the use of a ventilation fan. As long as there is adequate convective air flow and no major heat producing equipment in close proximity, the unit's housing provides adequate heat dissipation. The air temperature in the checkstand around the scanner must not exceed 104°F (40°C).

**Service Access Requirements.** Routine operations such as 'zeroing' and calibration do not require removal of the scanner from the checkstand or disassembly of the product. The installer should plan service access for the AC/DC Power Supply and cables.

**Recommended Power Installation.** Since the typical grocery environment includes conveyor belts and electric motors, care should be taken to ensure that the scanner has a supply of "clean" power (power without excessive electrical noise).

**Counter Preparation.** Since the majority of grocery checkout lanes are designed as "left-hand take away," the counter drawings in this section focus on this counter design. Simply reverse the layout for a "right-hand take away" requirement. The unit scans equally well in either of these two configurations.

**Liquid Drainage.** Should a liquid spill occur, ensure that moisture can flow through the checkstand without pooling.

**Leveling.** Plan ahead and provide screws/bolts in the checkstand mounts and a leveling guide (board) to allow leveling of the scanner or scanning-scale within the counter. Use a 0.375" thick board to replicate the mounting flange on the long scanner or scanning-scale, and adjust screws or bolts until the board is flush within the counter. Use a 4.0" wide board stood on its end to adjust leveling screws/bolts in rail support applications.

**Cable Routing.** Placement of the scanning-scale should be planned to allow easy access to other components as well as optimize communication between the scanner, the POS terminal and the optional Remote Scale Display. Note that cables may drop straight down from the scanner's connector panel, or may be conveniently routed along the unit's side using the hardware provided. Do not route interface cables near any electrical motors or other sources of electromagnetic interference.

**Remote Scale Display Placement.** The customer, and checker in some instances, must be able to easily view and read the Remote Scale Display. Ambient light and mounting height considerations are discussed later in this section.

**Vertical Clearance.** Provision must be made to allow adequate space above the scanner bonnet for removal and replacement of the All Weighs<sup>TM</sup> Platter (the L-shaped platter). Optimal clearance permits the platter to be grasped at its top vertical edge and lifted for removal without obstruction (such as a fixed keyboard mount or any type of enclosure).

Should such an enclosure be unavoidable, an alternate method of platter removal using two coins may be employed, however a minimum vertical clearance of 1.5" (3.8 cm) MUST be provided (reference Figure 2-2). Another consideration is that the scan zone must be kept free of obstructions such as enclosures, keyboard mounts, etc.




Figure 2-2. Vertical Clearance

## **Ventilation and Spacing**

The scanning-scale's perimeter housing has been designed to provide adequate space for convective cooling and unrestricted movement of the weighing apparatus. Figure 2-3 shows the debris chutes and ventilation slots. The checkstand design must allow:

- The ambient air temperature inside the checkstand adjacent to the scanner must not exceed 104°F (40°C).
- A source of air that provides adequate cooling by convective air flow.



DO NOT place the scanner in a close-fitting, fully enclosed checkstand. Provide a MINIMUM of 16 square inches (103.2 square centimeters) of air intake from below the installation for sufficient convective cooling.

If motors, conveyor belts, or other heat producing equipment are located near the scanner, forced air ventilation may be required. In most installations, a 30 cfm (.84 cmm) axial fan should provide sufficient air movement. If a ventilation fan is installed, one with a removable filter that may be washed or replaced is recommended.




Figure 2-3. Debris Chutes & Ventilation Slots

#### **Service Access**

The scanner and scanning-scale have been engineered to allow performance of all routine service and maintenance (such as "zeroing" and calibration) without removing the scanner from the checkstand. Additionally all cable connections made at the scanner can be connected and removed while the unit is sitting on the countertop. The installer should provide service access to all remaining cable connectors as well as the AC/DC Power Supply (if installed).

#### **Power Installation**

Plug your scanner into an electrical outlet that has been wired to meet all applicable electrical codes, laws, and regulations and has a common ground with the Point-of-Sale terminal

## Grounding

The AC/DC Power Supply should have an AC outlet with a clean earth ground. If you are not sure how to verify the amount of electrical noise (interference) on the power line, ask a qualified electrician to measure the input line voltage.

## **Checkstand Preparation**

Reference Figure 2-4. When performing a first time installation into a new checkstand, verify before cutting that room will be allowed for cabling and the AC/DC Power Supply. When making the opening, take extra care to accurately cut to the correct dimensions. Mounting may require installation of support(s), countertop routing, or other such devices. Depending upon checkstand design, you may wish to install an item diverter to direct items toward the scan window. See the instructions in this manual titled "Counter Cutout" for more details concerning the location and preparation of the opening.




Figure 2-4. Installation Overview

#### **Liquid Spills and Moisture**

Select a checkstand design which allows fluids to flow through, and directs liquids away from any electronic equipment or storage areas.

#### **Counter Cutout**

The most important consideration when planning the counter opening for the scanner is the operator's comfortable reaching distance. The ideal, ergonomically sound installation allows items to be directed within easy reach, and a scanning area requiring no lifting or special orientation of items. If you haven't already read the information at the beginning of this section titled, Pre-Installation Considerations, please do so before continuing these instructions.

The symmetrical design of the scanner permits the operator to easily pass items from one hand to the other while scanning (either from right-to-left or left-to-right). With the unique 360- scan zone, scanning is accomplished in one fluid motion. The operator simply slides the item from the conveyor belt or diverter area through the scanning area and passes the item to the other hand, which in turn bags it or places it on a take-away conveyor belt. Movement should flow naturally over the surface of the scanner.

Note that the following guidelines for preparing an existing checkstand to accept a scanner, or incorporating the unit into a new checkstand design will not be accurate for all installations. Although these guidelines will suffice for most standard installations, the installer may need to make adjustments for varying counter heights and thicknesses, support design, or other checkstand limitations.

Figure 2-5 shows a typical "left-hand-take-away" checkstand design.

Follow these basic steps to install the unit:

- Select a position for the scanner that offers a smooth product flow which best accommodates the reaching distance of the average operator.
- 2. Cut the opening in the countertop. Select the appropriate drawing from Figure 2-6, or Figure 2-9 for your model.
- 3. Install the AC/DC Power Supply, the Remote Scale Display cable and the interface cable(s) observing the following:

Interface cables (and display cable, if applicable) should be routed away from all highly inductive electrical devices, like motors and conveyor belts, and even away from the unit's power cable if possible.

Cables should be easy to remove in the event that replacement is required. A little planning now will save a lot of frustration later.

#### 4. Connect and verify all system operations.

The scanner should be installed so that leading and trailing edges of the All Weighs<sup>TM</sup> Platter are flush with the countertop to enhance smooth, slide-through scanning (reference the insert in Figure 2-5). Keep in mind that the debris chutes on both sides of the platter provide the necessary clearance for proper scale operation if you are installing a scanning-scale (you won't need to provide an additional gap for that).





Figure 2-5. Typical Checkstand Design & Cutout Location

Refer to the appropriate drawing (Figure 2-6, Model 8500; Figure 2-9, Models 8501 and 8502) for dimensional information on the model you'll be installing.

Figure 2-6. Models 8500 & 8501 (Short Scanner Models) Cutout Dimensions



← 6.95" → (17.65cm) Model 8500 Reference 6.2" **Dimensions** (15.75cm) 7.0" (17.78cm) 12.0" (30.5cm) 5.0" (12.7cm) 16.5" 41.91cm) \$ 22 lb. 11.5" (10kg) (29.21cm) Scanner Weight 7.75" (19.69cm)

Figure 2-7. Model 8500 (Short Scanner) Reference Dimensions






Figure 2-9. Models 8501, 8502, 8503 & 8504 Long Scanner or Scanning-Scale Cutout

#### **Dimensions**





Figure 2-10. Models 8501 and 8502 Long Scanner or Scanning-Scale Reference Dimensions






Figure 2-11. Models 8503 and 8504 Long Scanner or Scanning-Scale Reference Dimensions

## **Checkstand Mounting**

There are a number of things to take into account when installing the unit into a checkstand. Key factors are ergonomic/worker safety, loading capacity and stability. Consider the scanner or scanning-scale's weight when calculating the robustness of construction needed to support it as well as maximum capacity of weighed and scanned items.



**NOTE** 

If you choose to rout a countertop with a thickness of 0.75" (1.9 cm) plywood, you'll need to add a backing strip that supports the area routed out for the support flanges (see Figure 2-4). This support strip should minimally be made of 0.75" (1.9 cm) thick plywood and be approximately 4.0" (10.2 cm) wide and 14.0" (35.6 cm) long. This strip should be glued as well as screwed to the underside of the countertop.

#### **Installation Overview**

The preceding Site Preparation Overview dealt with installed location and counter preparations to accommodate the scanner or scanning-scale. Having completed those steps, physical installation of the scanner or scanning-scale can begin. The following instructions apply to all models.

This section describes:

- 1. Unpacking the unit.
- 2. Verifying operation before connecting to a POS system.
- 3. Routing and connecting cables.
- 4. Validating that your scanner communication parameters match the POS terminal's system requirements.
- 5. Confirming connection to the EAS system.
- 6. Functional testing to verify operation when connected to the POS system.

The following text describes each of these steps.

#### **Unpacking**


To unpack the unit:

- Inspect the package for signs of damage that may have occurred during shipping. If damage is found, report it to your carrier immediately.
- Lift out the accessory box containing the AC/DC Power Supply, optional Remote Scale Display and cable (if present), and the Quick Reference Guide.
- Remove the Quick Reference Guide and familiarize yourself with the unit's controls and features. Leave the guide at the checkstand when the installation is complete.
- Remove the protective packing and carefully lift the unit from the carton. Be sure to save the box and all packing material. In the event of failure, the unit must be returned to the factory in its original packaging.
- Carefully lift off the All Weighs<sup>TM</sup> Platter as shown in Figure 2-24
  and remove the protective foam pieces securing the weigh mechanism. Set the platter back in place.



For added protection during shipment, the All Weighs<sup>™</sup> Platter is covered with a tight-fitting layer of vinyl as shown in Figure 2-12. This vinyl layer MUST BE REMOVED before placing the unit into service.

Figure 2-12. Remove Protective Vinyl



• Proceed to the Operational Verification instructions below.

## **Operational Verification**

Follow these steps to ensure that your unit has arrived undamaged and is fully functional before installing it in the counter and connecting it to your POS system.

- 1. If the unit is a scanning-scale, connect the Remote Scale Display to the proper connector on the unit's connector panel (refer to Figure 2-16). Note that if the Remote Scale Display is not connected, a scanner power-up Selftest will sound a long, low beep, and the number "8" will appear on the 7-segment display indicating a remote display error. Power-down, connect a known-good Remote Display to the appropriate port, and restart to correct this problem. Alternatively, you can disable the Remote Display using programming barcodes (see Chapter 7, Programming, for more information).
- 2. Connect the power cable at the scanner then at the AC outlet.

When power is applied to the unit, the normal indicator sequence is:

- The green light will be lit (dim) steadily.
- [EAS models ONLY] The EAS indicator (bottom-most, tri-color LED) will flash ON/OFF during power-up. Additionally, the 7-segment display will flash the number '9'. indicating the EAS system is being initialized.
- If the Selftest detects a problem, the 7-segment display will display a number code. Refer to Chapter 4, Problem Isolation, for a description of failure codes and problem isolation procedures.



Scale calibration may be necessary to obtain a zero reading on the display on rare occasions.

3. The unit should be permitted to reach thermal equilibrium before proceeding to the next steps. (Reference the topic Warm-Up Time in Chapter 1.) When the unit is moved from a cooler temperature (such as a storage area) to a warmer environment (such as a checkstand location), a period of 60 minutes must be allowed to acclimate the unit to ambient conditions. Once installed and powered up, a "power-up" warm-up period of 15 minutes must

- be allowed before calibrating or performing weighing operations. These two warm-up periods may run concurrently.
- 4. Verify that the scanner or scanning-scale passes an operational test by observing the following:

**Scanner.** Pass UPC/EAN barcode labels in front of the scanner's windows. Since the interface cable is not yet connected to the POS terminal, the scanner may be limited to reading only one or two labels (see the note that follows). The scanner indicates when each label has been successfully read by flashing the green scanner light and emitting a good read tone (beep).



When not connected to the host, the scanner may be limited to reading only one or two labels. (This limitation is dependent upon the interface type.) To scan multiple labels without connecting to the host, place the unit in Scanner Diagnostic Mode by pressing the Volume/Tone Push Button for four seconds.

**EAS System.** The way in which EAS tags are deactivated is dependent upon the way the scanner is currently programmed with regard to EAS Mode. (See "EAS Mode" on page 7-42.) To test EAS system function...

- Coupled Mode Pass an item containing both a barcode and an active EAS tag over the scanner. Successful deactivation is indicated by the bottom-most LED flashing first red, then orange, then returning to green. The beeper will sound a good read beep. If you have enabled the manual deactivation function available for Coupled Mode (see "Manual EAS Deactivation Push Button" on page 7-48), test the function bbarcodey pressing the bottom push button. A ticking sound will be heard which should cease upon deactivating an EAS tag.
- Decoupled Mode In this mode, items do not require a barcode to be scanned to arm the deactivation function. Simply pass an active EAS tag over the scanner in the same direction you would scan a barcode. The bottom-most LED will flash red to indicate deactivation. No beep is sounded to indicate deactivation in this mode.
- Hybrid Mode In Hybrid Mode, the scanner must be enabled, however EAS deactivation in this mode also takes place without

needing to scan an item's barcode. Pass an active EAS tag over the scanner in the same direction you would scan a barcode. The bottom-most LED will flash red, then orange, then return to green. The beeper may be configured to sound a high frequency beep to announce successful deactivation.

**Scale.** If the Yellow LED is not lit, press the Scale Zero Push Button momentarily. If the scale is operating correctly, the yellow LED will illuminate and remain on steady, and the display will show a reading of 0.00 lb (0.000 kg for metric). If the display is blank or a \_\_\_\_\_\_ is displayed, it may be necessary to calibrate the scale before continuing. Refer to Chapter 5, Calibration Procedures, Single Interval, for calibration procedures.

**Remote Scale Display.** Check to verify that 0.00 lb (0.000 kg for metric) is displayed, then place an item on the weighing platter. Verify that the display shows a weight and that the yellow LED goes out. Remove the item and observe that Remote Scale Display shows 0.00 lb (0.000 kg for metric) and that the yellow LED is On.

5. Unplug the AC power cord from the outlet and disconnect the power cord and Remote Scale Display cable from the scanner's connector panel.

After you have verified that the scanner and scale (if present) are completely functional, continue with the following procedures to complete the installation.

#### **Diagnostic Modes**

Two diagnostic modes are available which allow you to initiate scanner or scale diagnostic tests, as well as verify the scanner's ability to read barcodes.

#### **Scanner Diagnostic Mode**

While in Scanner Diagnostic Mode, continuous scanning of labels is allowed, permitting the user to scan an unlimited number of barcodes while troubleshooting problems. Under normal operation, the scanner stores label data, awaiting the signal which transmits it to the host. When the scanner is not connected to a host, it may read and store only up to two labels, then quit reading until power is cycled (clearing the memory). This mode of operation removes this limitation.

To place the scanner in Scanner Diagnostic Mode, press the Volume/Tone Push Button for approximately four seconds. While pressing the button, the scanner will first sound three tones, wait a few seconds, then sound six rapid tones; after which you should immediately release the button.

While in Scanner Diagnostic Mode, identification numbers for interface<sup>1</sup> type, firmware and configuration will scroll continually across the scanner's 7-segment FRU (Field Replaceable Unit) display. This is useful information for field diagnostics. See Figure 4-1 for the location of the display. For example, if the dual cable RS-232 interface (type 05) were enabled, the firmware designation was R96-1234, and the configuration was R96-5593, the following would be shown (slowly, with blanking between each of the items):

IF-05 r96-1234 r96-5593.

To exit Scanner Diagnostic Mode, cycle power to the unit or press and hold the Volume/Tone Push Button for eight seconds to reset the scanner. See the topic, Scanner and Scale Reset in Chapter 3 for more information about unit resets.

#### **Scale Diagnostic Mode**

To enter Scale Diagnostic Mode, press the Scale Zero Push Button for approximately four seconds. Six rapid tones will be sounded, indicating the unit is leaving normal operation and entering Scale Diagnostic Mode. The Remote Display will flash a '1' across the display while the dignostic routine is being run. When diagnostics are completed successfully, the dis-

A listing of scanner interface identification numbers is available in Section 7, under the topic, Interface Type.

play will indicate that the unit has passed the diagnostic test by displaying PASS. Next, the display shows a listing of how many times the unit has been calibrated and zeroed in the form of: C XXX where x equals the number of times the scale has been calibrated. Next, the unit will display XXXX where x is the number of times the scale has been zeroed. Finally, all segments will be displayed in the form of: 18.8.88 to allow visual verification of display function.

If the diagnostics routine is not completed successfully, the scanner will sound a series of tones and the Remote Display will show an error code. Turn to Chapter 4, Problem Isolation for a description of error codes.

Press the Scale Zero Push Button once more to reset the unit and exit Scale Diagnostic Mode. See the topic, Scanner and Scale Reset in Chapter 3 for more information about unit resets.

#### **Cables & Connections**

Considerations when routing the power and interface cables for the scanner and scanning-scale are:

- Ensure that cables are not pinched, kinked or pierced.
- Do not route interface cables in close proximity to electrical motors or other sources of electromagnetic interference.
- Cables can drop directly from their connectors on the scanner, or, alternatively, can be routed along the scanner's side to the back (see Figure 2-13).

Do not plug the AC power cord into the outlet at this time. It is a good practice to always connect the power cable to the scanner first before plugging it into the AC receptacle. The procedures titled, Set-Up, provided later in this section will instruct you to connect the power cord at that time. Figure 2-13 illustrates the basic cable routing scheme.




Figure 2-13. Cable Routing

Figure 2-14 provides physical dimensions for the AC/DC Adapter (part number 8-0599).

2.3" (5.8 cm) 3.1" (7.8 cm)

Figure 2-14. Physical Measurements: AC/DC Adapter

## Remote Scale Display Placement/Installation

When installing the optional Remote Scale Display, consider both the customer's viewing angle and the amount of daily ambient light conditions anticipated at this installation site. Figure 2-15 shows available adjustment for the display head.

## **Lighting Considerations**

The display(s) will be easily readable unless placed in direct sunlight or other very strong light sources. Light interference will not be a factor in most installations. For best viewing, the display head(s) can each be rotated up to 180° around the post and/or tilted 15° backward or forward.


## **Viewing Angle**

The optimum display angle is directly facing the viewer. Tilt and rotatioin adjustments can be made for the Remote Display models is shown in Figure 2-15. To ensure that displays are easily readable for customers/cashiers of average height, display heads should be between 48" to 60" (122 to 152 cm) from the floor.



Check with local Weights and Measures authorities regarding proper positioning of scale displays used in retail trade.

Figure 2-15. Modular/Adjustable Remote Scale Display



## **Remote Display Cabling**

Your installation should also take into account the routing of Remote Display cabling. Ensure that distance and obstacles spanned by the routed cable will not kink, pinch or stretch it. Also keep in mind you may need to drill a hole through which to route it.



The Remote Scale Display connector end may be secured with a rubber band during shipping to prevent damage to the "locking tabs". After routing the cable, remove this rubber band before connecting. Failure to remove the band will keep the connector from latching properly.

## Model 8300RD: Placing and Installing the Remote Display

Reference Figure 2-17 while performing these procedures.

- 1. Determine where you want to install the Remote Scale Display based on your counter design, the viewing angle, lighting considerations and cable routing discussed previously. Reference Figure 2-16 for the display's physical dimensions. Optimally, the display(s) should be approximately eye level to the viewer(s).
- 2. Use the appropriate template provided in Figure 2-18 for 8300RD model to mark locations of the mounting screw and cable routing holes.
  - For the 8300RD model, the mounting screw holes are on 3-1/2" (85.1 mm) centers. The cable can either be routed through a <sup>3</sup>/4" (19 mm) diameter hole directly under the mounting base or through the cutout in the back of the base (see Figure 2-17).
- 3. Drill the mounting screw holes using a drill bit of the appropriate diameter for your mounting screws or bolts.
- 4. Drill the cable routing hole using a 3/4" (19 mm) drill bit (optional).




Figure 2-16. Model 8300RD Physical Measurements

- 5. Feed the entire length of the Remote Scale Display interface cable through the cable routing hole so that the assembled Remote Scale Display can be positioned over the mounting screw holes.
- 6. If present, remove the rubber band from the connector end.
- 7. Install mounting screws or bolts to complete the installation of the Remote Scale Display. Take care not to pinch or pierce the interface cable while securing the Remote Scale Display to the checkstand.





Figure 2-17. Model 8300RD Remote Scale Display Mounting

Figure 2-18. Model 8300RD Remote Scale Display Mounting Template



## Model 960RD: Placing and Installing the Remote Scale Display

#### (Short Pedestal Base ONLY)

- Determine where you want to install the Remote Scale Display based on your counter design, the viewing angle and lighting considerations discussed previously. Reference Figure 2-16 for the display's physical dimensions.
- 2. Use the short pedestal base template provided in Figure 2-18 to mark locations of the mounting screw and cable routing holes. The mounting screw holes are on 3 <sup>3</sup>/8" (8.57 cm) centers.



Before drilling, ensure the holes in your base match with the holes indicated on the template.

- 3. The cable can either be routed through a <sup>3</sup>/4" (19 mm) diameter hole directly under the mounting base or through the cutout in the back of the base (see Figure 2-20).
- 4. Drill the mounting screw holes using a drill bit of the appropriate diameter for your mounting screws or bolts.
- 5. Drill the cable routing hole using a <sup>3</sup>/4" (19 mm) drill bit (optional).

It may be necessary to shorten the stalk that supports the display head so that the display is installed at eye level.

14.2 cm

14.2 cm

15.6"

14.2 cm

2.75"

7.0 cm

Minimum

5.3"

(13.5 cm)

Maximum

11.5"

(29.2 cm)

3.375"

0.953 cm

4.5"

31.6 cm

Figure 2-19. Model 960RD: Physical Measurements: Remote Display (Short Base)


- 6. Cut the stalk to fit your installation (if required).
- 7. Route the cable through the base/stalk so that you can plug the connector into the display head.
- 8. Remove the rubber band from the connector and attach the connector to the display head.
- 9. Slip the display head onto the stalk/base.
- 10. Feed the entire remaining length of the Remote Scale Display interface cable through the cable routing hole so that the assembled Remote Scale Display can be positioned over the mounting screw holes.
- 11. Install mounting screws or bolts to complete the installation of the Remote Scale Display. Take care not to pinch or pierce the

interface cable while securing the Remote Scale Display to the checkstand.

Mounting Display Head Example Display Stalk Cable end after rubberband 48 - 60" (122 - 152cm) is removed. Cable Connector Display Base (optional Interface cable Cable routing)

Figure 2-20. Model 960RD: Remote Scale Display Components

Figure 2-21. Model 960RD: Remote Scale Short Base Display Mounting Template



## **Changing Weighing Modes**

Your scanning-scale has been programmed for weighing in either pounds or kilograms depending upon the initial operating environment that was specified when you ordered your scanning-scale. If you need to change from pounds to kilograms or vice-versa, call Technical Support.

You can verify that the scale is set correctly for your country's requirements by observing that the Remote Scale Display shows the appropriate measurement symbol (lb or kg) when the power-up Selftest is completed.



Any time the scale weighing mode is changed, the scale must be re-calibrated before commercial use.

## **Set-Up & Installation**

These setup and installation procedures assume that you have already prepared your checkstand to receive the scanner or scanning-scale. If you have not already made the counter cutout and routed power and interface cables, do so now as described in the previous instructions. If your checkstand has been prepared, proceed as follows:


#### Set-up

- Place the unit on the checkstand next to the counter cutout.
- 2. Route the cables up through the cutout and connect the scanner and scale interface cable(s), and Remote Scale Display cable (optional) to the scanner. Some POS terminals require two interface cables; one for the scanner interface and one for the scale interface. Refer to Figure 2-22 for cable connection locations. The appearance of the connector panel will vary depending upon the factory options purchased with your model.


If you have a scanner with no scale, there will be only one interface cable to the POS terminal.

Connect the power cord to the scanner and route the other end down through the checkstand to the AC power outlet. DO NOT plug the power cord in at this time. 4. OPTIONAL — Route your EAS antenna cable down through the checkstand cutout. (Reference your EAS controller's set-up instructions for proper EAS antenna installation.)

Figure 2-22. Connecting Cables to the Scanner/Scale




**Figure 2-23. Optional EAS Cable Connections** 



#### Installation

- 1. Make sure that all cables are firmly attached (except that the AC/DC power supply should not be connected to the AC outlet yet).
- 2. Remove the All Weighs<sup>TM</sup> Platter to gain access to the lift handles. Grasp the platter as shown in Figure 2-24 and gently lift it from the scanner. If the top edge of the platter is blocked, you may find it easier to grasp the platter vertical bezel as shown in Figure 2-24b.

Figure 2-24. Removing the All Weighs™ Platter



3. Depending upon the model type, the method used to lift the unit will vary. For the first model type, hook the fingers of both hands into the lift handles located along the insides of the scanner walls, just above the debris chutes as shown in a. Other models contain lift handles that must be rotated up into position for use as shown in b. DO NOT attempt to lift the unit using the plastic edges, scale frame, or any features other than the lift handles.




Figure 2-25. Using the Lift Handles

- 4. Lower the unit into the counter opening, ensuring that none of the cables are pinched, pierced or crimped.
- 5. View the bubble level (if present¹) located on the scanner's spider assembly to ensure the scanner is level. As shown in the insert of Figure 2-26, the air bubble should appear fully within the circle indicated. The air bubble can touch the circle, but must not overlap it. Apply shims beneath the scanner bottom or adjust the shelf to allow level installation.

<sup>1.</sup> The bubble level is present only on certain models.

OK OK NO

Bubble Level

Figure 2-26. Using the Bubble Level

6. Reinstall the All Weighs<sup>TM</sup> Platter and verify that it is flush or just below flush with the countertop. This is necessary to provide smooth scanning from either direction. Make adjustments as needed to align the platter with the counter by moving support rails up or down, or consider installing screws in positions that will allow their use in adjusting the unit's position. Ensure that leveling is maintained if adjustments are made.



**NOTE** 

Failure to install a scanning-scale in a stable and level position will inhibit weighing, calibration and zeroing operations. The platter MUST make unobstructed contact with all of its supports for proper weighing operation.

7. Once installation is complete, proceed with the Operational Verification procedures that follow.

## **System Power-Up Recap**

The System Power-Up procedure may vary depending upon the requirements of your POS system. It is generally a good practice to power-down (switch off) all equipment prior to connecting cables. Check with your System Supervisor and/or refer to your POS terminal manual for proper power-down and power-up procedures and interface requirements when connecting any peripheral device.

If you have not identified any specific requirements for your POS system, follow these steps.

- Power-down the POS terminal.
- 2. Ensure that power is disconnected from the scanner.
- Connect the scanner and scale interface cables to your POS terminal. This connection may use one or two cables depending upon your POS terminal interface.
- 4. Connect the Remote Display cable if your model is a scanning-scale and make any connections to optional equipment, such as EAS<sup>1</sup> or a handheld scanner.
- 5. Power-up the scanner or scanning-scale by connecting the power cord to an AC power outlet. Wait for the unit to complete the Selftest routine (10 seconds maximum).
- 6. Power-up the POS terminal.
- 7. Verify that both scanning and weighing data are properly communicated between the scanner and your POS system. (Weigh, deactivate<sup>2</sup> and scan a few items.) If problems are encountered, refer to Chapter 4, Problem Isolation.
- 8. You have now completed installation and system integration of the scanner or scanning-scale. At this point, the scale must be calibrated and certified in accordance with the requirements of your state and/or local requirements. Refer to Chapter 5, Calibration Procedures, Single Interval, for calibration procedures.

Some peripheral equipment must be connected or powered on in a specific order. Check the
equipment instructions to verify the correct sequence.

<sup>2.</sup> Test EAS deactivation only if applicable for your model.

# **NOTES**

# **Section 3**

# **Operation and Maintenance**

The information contained in this section describes how to operate and maintain the scanner, scale and EAS system. Topics include "how to's" on scanning, EAS tag deactivation, weighing, re-zeroing the scale, removing the top cover and cleaning the upper and lower windows.

#### **Scanning Items**

To scan items using the scanner, slide or push them through the scan zone as shown in Figure 3-1. The scanner will work equally well with either a left-to-right or right-to-left motion through the scan zone. There is no need to reorient an item's barcode since the scanner can "see" the left, right, front and back side, as well as the top and bottom of an item.



"Limited Scanning Mode" is entered by default by interfaces such as USB and IBM until a Point Of Sale (POS) terminal enables scanning. Labels are "chirped" while in this mode.

Vertical Window Scan Zone

Horizontal Window Scan Zone

Horizontal Window Scan Zone

Checker Side Scan Zone

(Models vary)

Figure 3-1. Scan Zone

#### **Proper Scanning Technique**

The scanner was designed to provide the ultimate in ergonomic enhancements for Point-Of-Sale (POS) scanning. To take advantage of these advancements:

Practice the techniques below to improve scanning efficiency:

- Move the product across the horizontal window (See Figure 3-1).
- Since the scanner reads labels on all four sides plus the top and bottom, don't favor either the horizontal or vertical scan windows. Keep items in their natural orientation.
- Remember to slide or push items rather than picking them up. By avoiding any gripping, twisting and rotation of your hands and wrists, you can prevent repetitive motion injuries. This technique also relieves you from lifting possibly thousands of pounds per day.
- Develop a smooth fluid motion during scanning, sharing work equally between hands.
- Use the entire hand for grasping and lifting items.
- Develop efficient scanning motions, not necessarily faster hand movements.
- Learn typical locations for barcodes on packages; avoid "flipping" or rotating the items during scanning.
- Learn how the scanner functions and where the scanning area is located.

## **Deactivating Security Labels**



Two different types of Electronic Article Surveillance (EAS) systems can be optionally enabled for certain scanner models. Your system may or may not be equipped with EAS deactivation functionality.

#### Checkpoint

Checkpoint<sup>®</sup> systems require a wired connection as shown in Figure 1-3**a**. When this system is armed, Checkpoint EAS-tagged items are automatically deactivated as they are slid over the scanner's platter area during scanning.

#### Sensormatic

Sensormatic<sup>®</sup> Ultra-Max<sup>®</sup>, Ultra-Strip<sup>®</sup> II and III EAS tags can be detected and deactivated by a system that is equipped to do so. This is accomplished by means of an AMB-5190 deactivation antenna mounted under the scanner platter. EAS tags should be brought within five inches of the antenna to be deactivated.

#### **EAS Deactivation Modes**

Three modes of initiating deactivation are selectable via scanner programming (reference Chapter 7, "EAS Mode" in this manual):

- Coupled Mode Deactivation occurs only after item barcodes are read by the scanner.
- Decoupled Mode Deactivation is independent of the scanning function
- Hybrid Mode EAS system is armed whenever the scanner is enabled and the deactivation beep is sounded when an EAS tag is deactivated...



The EAS system must be functional to implement any of the EAS Modes. If the EAS system is not active, error code 9 will be displayed in the 7-segment LED display (see Figure 4-1).

#### **EAS Deactivation Indicators**

The scanner can be programmed to beep in acknowledgement of deactivation or upon deactivation failure. Additionally, the tri-color indicator (the bottom-most LED) displays deactivation status. (For more information about Beeper and LED indications, see the LED/Beeper Indications & Controls section of this manual. Also reference the programming section for their configurable features.) By general default, LED indications are:

- Green means the system is ready (standing by).
- Red signifies the system has detected an EAS tag.
- Orange indicates an EAS tag is being deactivated.

#### **Manual EAS Deactivation Push Button**

The bottom-most push button is reserved for use in rare instances where EAS tagged items are not automatically deactivated when brought through the scan zone. This button is not intended for regular use. In instances where deactivation is not automatically triggered, hold the EAS tag directly downstream from the horizontal window, and press and release the Manual EAS Deactivation Push Button. This manual deactivation feature is optional, and can be enabled/disabled via the barcodes located in the programming section of this manual.

The item will be deactivated and a message to store management that this has occurred will be sent.



In a case where an item's barcode is damaged or obscured by an EAS tag or other obstruction, the operator will need to key enter the barcode number and use the Manual EAS Deactivation Push Button to manually deactivate the EAS tag.

#### **Deactivating the EAS System when failed**

In cases of EAS system failure or malfunction, a scanner can be enabled to operate independent of the EAS deactivation function. This is accomplished by pressing and holding the EAS Manual Deactivation Push Button for three seconds. The scanner will sound three high-pitched beeps upon bypassing the EAS function in this manner. When in this state, the scanner's EAS LED will flash slowly red, as well as the FRU Status LED, which will slowly flash error nine (9).

# **Proper Weighing Technique**

1. The L-shaped All-Weighs™ platter allows you to place items anywhere on its surface, including leaning against its vertical section, to be weighed accurately. The raised "Produce Rail" also provides a convenient way to ensure items do not rest on the counter or other non-weighing surfaces. (Reference Figure 3-2.)



It is important that items rest entirely on the platter for their full weight to be accurately recorded.




Figure 3-2. L-Shaped Platter & Item Placement

- 2. Once weighed items are in place, enter PLU (price Look-Up) data as described in your POS system instructions. Item weight is displayed on the Remote Display and/or the host display.
- 3. Remove the item from the weigh platter.

# **Operational Controls**

The function of scanner and scale controls and indicators is listed in Appendix A, *LED/Beeper Indications & Controls*. Turn to that appendix for full details.

# **Operational Modes**

The scanner or scanner/scale features a number of modes that are important to both the user and the system support personnel. These modes can be combined into three groups: pre-operational, operational, and additional functions. The following text describes these modes, what they mean, and how and when they are seen.

# Power-Up/Selftest & Pre-Operation

Pre-Operation describes those steps that must be successfully completed before the scanner sounds the initial good read tone and illuminates the lamps indicating the scanner and/or scale are ready for operation. These steps include Power-Up Selftest, Error Reporting, and Operational Configuration.

### **Power-Up/Selftest**

Power-Up Selftest begins when power is applied. The scanner's software immediately begins the testing sequence to verify that all systems are functioning properly. This routine, which only takes a few seconds, checks all the functions of the scanner, EAS deactivation system, scale, remote scale display and interface prior to indicating that it is ready for operation.



A tone indicating Selftest is complete is a configurable feature. See the Chapter 7, "Power-up Beep Control" in this manual.

#### **Error Reporting**

If a fatal error is detected during Selftest or operation, the unit will not advance to Normal Operation Mode. Selftest diagnostics will cause the unit to sound a long, low tone and/or display an error message on the 7-segment display indicating where the failure occurred. These messages are coded to assist the repair technician in identifying the failed component. If the error is with the EAS deactivation system, the bottom-most LED will flash red. If an error is indicated, make note of it and contact your supervisor or technical support representative. A table containing descriptions of these error codes is included in Chapter 4, Problem Isolation.

If a non-fatal<sup>1</sup> error is detected (such as the loss of one of the two lasers, or EAS deactivation system error), the unit will sound a long, low tone and display a number on the 7-segment display. The unit will advance to Normal Operating Mode, but performance may be affected until a correction or repair is made.

#### **Operational Configuration**

Once Selftest diagnostics have been successfully run, a tone is emitted (if configured to do so, and the unit enters an operational configuration state. The scanner or scanner/scale will automatically load your specific interface settings which are required to communicate with the host system. There are two conditions that must be met before the unit can enter Operating Mode:

- No barcode label can be in the scan volume while the unit is in this state. Progress is halted until the label has been removed, thereby ensuring that no extraneous barcode data is send to the host.
- If your scanner has a scale, the scale cannot be in motion (usually caused by excessive vibration in the checkstand) for this test to succeed. A "Scale in Motion" status will be indicated by displaying a period and the applicable weight unit (lb or kg kg) that is selected.
- The scale must be able to "capture" zero weight. The
  display will be seen if there is a weight on the platter

Scanner behavior under non-fatal error conditions is configurable. See Chapter 7, Programming for more details.

at power-up. Removing the weight or pressing the Scale Zero Push Button should allow the scale to find zero.

When the scanner or scanner/scale completes its Selftest successfully, it emits a tone (when configured to do so) and enters Operating Mode.

## **Operating Mode**

Operating Mode includes Normal Operation (scanning, EAS deactivation and weighing) and Sleep Mode. These two modes are most commonly observed by the user/operator.

#### **Normal Operation**

This condition is indicated by the scanner green LED and the EAS deactivation LED both being on dim and steady. For scanner/scale models, the scale yellow LED indicates that the scale senses a weight of zero on the platter. If you have a scanner without scale model, the yellow lamp will not be lit when the scanner is ready for scanning.



Yellow and Green LED indications are configurable. Your scanner may not be programmed to operate in the standard manner described above.

Once the scanner enters Normal Operation, it begins a countdown sequence. If there is no activity during a preset period of time (also called time-out<sup>1</sup>), the unit will shut off the laser and/or motor in order to prolong the life of the electrical and mechanical components. Once the scanner has timed out, it enters Sleep Mode.

 <sup>&</sup>quot;Timeout" and "Sleep Mode" time delays are programmable features that can be selected through use of the programming labels included in Chapter 7, Programming.

#### **Sleep Mode**

After the scanner has been left idle for a preset period of time, the laser and/or motor automatically turns off (goes to sleep). This state is called Sleep Mode, and is indicated by a "slow" blink of the green light (blinking at a 2-second rate). To wake up the unit, press anywhere on the weigh platter (scanner/scale models only), press the Volume Selection switch or wave your hand in front of the vertical window. The unit will recognize any of these signals as a wake-up call and instantly return to Normal Operation.

### **Additional Functions**

Additional scanner and scale functions include programming, running scanner or scale diagnostics, initiating a reset, zeroing the scale, and calibrating the scale.

# **Programming**

When your scanner or scanner/scale is shipped from the factory it is configured to work with the POS system interface at your store and read the barcode symbologies you designated. If you need to change this configuration information for any reason, Chapter 7, Programming, contains special barcode labels for changing the unit's settings.

## **Diagnostic Mode**

Refer to Chapter 2, Diagnostic Modes, for details about running scanner and scale diagnostics. Turn to Chapter 4, Problem Isolation, for a description of error codes resulting from diagnostics.

### **Scanner and Scale Reset**

The reset procedures and indicators are identical for scanner and scanner/ scale models. As with any electronic equipment, it is sometimes necessary to reset the electronics. The reset procedure allows you to initiate a reset command to the scanner. This may be necessary if the POS terminal has been switched off or the store system has been reset while the unit is on. Reset can also be used to initiate and run the unit's internal Selftest routine.

Pressing and holding the Volume/Tone Push Button for approximately eight seconds initiates a reset, which is sounded by a rapid number of beeps. If the motor had been spinning, the lamps will blink while the motor spins down. At that point, the motor will spin back up and the scanner will continue to run the Selftest diagnostics. For more information, see the topic, Power-Up/Selftest & Pre-Operation earlier in this section.

## **Scale Adjustments**

The scale allows two user adjustments: zeroing and calibration. The first, and most frequently performed, is 'zeroing' the scale. This operation resets the scale's "at rest" reading to zero which must be within the range of - 0.2 pounds (- 1.25 grams) to +0.6 pounds (0.27kg) since the last calibration. While the 'at rest' reading remains within the zero range, the scale will automatically adjust itself to true zero. The scale also automatically zeros itself on power-up if the weight present on the scale is within these defined limits.

#### **Zeroing the Scale**

The zeroing operation may be performed by checkers and other store personnel. Pressing and releasing the Scale Zero Push Button should return the scale to Normal Operation. If the zero point moves out of the zero range due to debris accumulation or other causes, pressing the Scale Zero Push Button will not reset the zero point. In this case the weigh platter must be cleaned, debris chutes cleared of debris or the scale must be recalibrated.

With the scanner/scale powered-up and at operating temperature:

- 1. Remove everything from the weighing surface of the scanner/ scale.
- 2. Press the Scale Zero Push Button. (See Figure 1-1).
- 3. The Zero<sup>1</sup> light will turn on and the display will show 0.00 lb (0.000 kg). If it does not, see Chapter 4, Problem Isolation.
- 4. You have completed the scale zeroing function.

<sup>1.</sup> Zero light operation is configurable.

#### **Calibrating the Scale**

The second adjustment, calibration, defines and sets a standard reference weight range against which all product weights are compared. If your scale is set for weighing in pounds, this range is 0 - 30 pounds, and, if your scale is set for weighing in kilograms, the range is 0 - 15 kilograms. The scale must be calibrated upon initial installation, whenever the scale cannot be zeroed, when the scale diagnostics indicate a calibration error, when the weighing measure (pounds or kilograms) is changed, or when the scale module has been replaced.

Normally, once the scale has been calibrated, the calibration must be verified and/or approved by a local regulatory body. In many areas of the United States, the scale calibration switch must be sealed before being placed into service. Consult the agency responsible for regulating weighing devices in your area to ensure that you are meeting all legal and regulatory requirements. Chapter 5, Calibration Procedures, Single Interval, describes the calibration sequence and verification process.

Calibration can only be performed if the tamper seal that secures access to the Calibration Switch is broken and the switch cover is removed. Breaking the seal may *legally* render the scale inoperable until it has been recertified and a new seal attached. Consult your local regulations before removing the calibration seal if you are unsure of the legal requirements. Although the scale will physically continue to weigh products, a broken seal may require recertification by a proper authority as designated by your local laws.

# **Operational Maintenance**

The scanner or scanner/scale will provide dependable service for many years. The following maintenance procedures will keep your scanner or scanner/scale operating at peak performance.

Cleaning the Weigh Platter and Scan Windows. Clean the exterior surfaces of the horizontal and vertical scan windows at least twice daily with a nonabrasive, mild, water-based glass cleaner and paper towels or lint-free cleaning tissues. The textured plastic surfaces and stainless steel can also be cleaned using the same cleaning agents.

Cleaning the Air Gap/Debris Chutes & Drip Rail. Daily, clear the debris chutes between the platter and the outer housing. Most items can be cleared from the debris chutes by carefully running a thin stiff object like a credit card along all sides of the weighing surface. If necessary, remove the top cover to clear the debris chutes and drip rail.

# **Vertical Scan Window Replacement**

The Vertical Scan Window enclosed in the All Weighs™ Platter is a replaceable part. Follow these instructions to remove and replace the window:

To remove the Vertical Scan Window:

 Grasp the platter as shown in Figure 3-3 and gently lift it from the scanner.

(Models vary) 00000 **Obstruction** b **Vertical Bezel** 

Figure 3-3. Platter Removal

2. If the top edge of the platter is blocked, you may find it easier to grasp the platter vertical bezel as shown in Figure 3-3b.



**NOTE** 

Use caution to avoid damage to the now exposed horizontal and vertical scan windows. If cleaning of these windows is necessary, use a nonabrasive, mild, water-based glass cleaner and paper towels or lint-free cleaning tissues and take care to avoid scratching these windows (damage to the windows can degrade scanning performance).

3. The vertical scan window is held in place by two tabs each on its top and bottom edges. To remove it, carefully push out on the top as shown in Figure 3-4 and lift it out. Carefully dispose of any damaged glass.

Vertical Scan Window

Figure 3-4. Vertical Scan Window Removal/Replacement

- 4. Fully seat the new vertical scan window into the window channel within its bottom retention tabs. Tilt the window in to engage the two tabs at the top of the retainer and carefully snap the window to secure it in place.
- 5. Clean both sides of the new vertical scan window using a paper towel or lint free cleaning tissues dampened with a mild, water-based glass cleaner. DO NOT use abrasive cleaners or pads.
- 6. Reinstall the platter. Vertical scan window replacement is now complete.

# **Horizontal Scan Window Replacement (DLC)**

Diamond-Like Coated (DLC) horizontal scan windows are replaceable. Depending upon your model, use the appropriate instructions below.



Sapphire glass does not require replacement, so it is permanently fastened in place. Do not attempt to remove Sapphire glass from the platter.

#### **Slide-in Window Models**

- 1. Remove the All Weighs<sup>TM</sup> Platter from the scanner as shown in Figure 3-3.
- 2. Turn the platter upside down on a clean, dry surface and remove the four screws shown in Figure 3-5. Retain all screws for later reinstallation.
- 3. Once the vertical bezel is freed from the platter, the DLC window can be slid from its channel as shown. Carefully dispose of any damaged glass.
- 4. Slide a new horizontal window fully into the channel.
- 5. Reinstall the vertical bezel using the original four screws.
- 6. Clean both sides of the new horizontal window using a paper towel or lint free cleaning tissues dampened with a mild, water-based glass cleaner. DO NOT use abrasive cleaners or pads.
- 7. Reinstall the platter. Slide-in horizontal window replacement is now complete.

Slide DLC Window Out

Remove Vertical Bezel


Figure 3-5. Removing/Replacing the Slide-in DLC Window

#### **Gasketed Models**

- 1. Remove the All Weighs<sup>TM</sup> Platter from the scanner as shown in Figure 3-3.
- 2. Turn the platter upside down on a clean, dry surface and remove the two screws and two nuts shown in Figure 3-6a. Retain all screws and nuts for later reinstallation.
- 3. Lift the edge of the retainer shown in Figure 3-6b and remove it from the assembly.
- 4. Take note of how the gasket is seated, then gently peel it away from the assembly as shown in Figure 3-6c. Retain the gasket for reinstallation.
- 5. The window can now be removed (see Figure 3-6d). Carefully dispose of any damaged glass.
- 6. While carefully holding it by its edges, tilt a new horizontal window fully into position as shown in Figure 3-6d.
- 7. Fit the gasket into its channel as shown in Figure 3-6c and press around its entire perimeter to ensure it is fully seated.
- 8. Reinstall the retainer in the orientation shown in Figure 3-6b, aligning both holes with their studs.
- 9. Secure the retainer using the original two screws and two nuts as shown in Figure 3-6a.
- 10. Clean both sides of the new horizontal window using a paper towel or lint free cleaning tissues dampened with a mild, water-based glass cleaner. DO NOT use abrasive cleaners or pads.

Reinstall the platter. Gasketed horizontal window replacement is now complete.





# **Section 4**

## **Problem Isolation**

In the event of a suspected functional problem, use the troubleshooting references provided in this section. This useful information will help you to identify and resolve the cause of the problem.

The scanner/scale has a number of features that indicate when a scanner, EAS deactivation system, or scale problem occurs. The unit may:

- emit a series of tones
- light the 7-segment (FRU status) display
- flash its indicator LEDs
- display error codes on the Remote Display (if installed)

Three error reporting modes are used: Power-Up Selftest, Operational tests and Diagnostic tests. These test sequences are explained on the following pages.

#### **Power-Up Selftest**

The Power-up Selftest is a pre-operational series of tests that must be successfully completed before the scanner indicates readiness for operation. This pre-operational period is the time between power-up and normal operation during which the motor comes up-to-speed and software, firmware and hardware are being tested. These tests ensure that all subsystems are fully functional before turning on the Visible Laser Diode (VLD). Refer to the Section 3 subsection titled, Operational Modes for a more detailed description of this and other scanner and scale modes.

#### **Operational Tests**

These are the tests that run continually during Normal Operation and Sleep Mode. Firmware checks all subsystems, accessory connections and the POS interface to verify everything is operating normally. If a problem is detected at any time, a long, low tone is sounded, an error code is shown on the 7-segment display, and operation may be halted. If you press the Volume/Tone Push Button at that time, a series of tones will be sounded that matches the error code displayed.

#### **Diagnostic Tests**

See Chapter 2, Diagnostic Modes, for details about running diagnostic tests for the scanner and/or scale. If a problem is discovered during diagnostics, the scanner will provide feedback about the source of the problem. The remainder of this section describes these failure indications and includes troubleshooting flowcharts to help isolate the problem.

# **Diagnostic Procedures**

Your Point-Of-Sale (POS) system may contain many components that operate as a system. Since almost all scanner or scale problems are caused by either the scanner, scale, POS terminal or communication links between them, these troubleshooting flowcharts focus on these components. Additionally, the optional Remote Scale Display, AC/DC Power Supply and their cables are potential problems addressed in this section.

The flowcharts provided in this section walk you through a diagnostic process that will isolate the failed component and instruct as to the corrective action required. Since internal scanner and scale components cannot be replaced by an operator or installer, most functional errors will require the assistance of a trained Technical Support person. However, if the problem is caused by faulty cable, power supply or remote display, you can fix the problem by replacing the defective component and complete the installation.

### **Error Codes**

If an error is detected, the scanner will sound a long low tone (for three seconds) and alternately flash its LEDs, indicating a failure. When this occurs, press the Volume/Tone Push button to display the error code on the 7-segment display (refer to Figure 4-1). If it is configured to do so, the scanner will also sound a series of beeps corresponding to the error code. The table below describes what these codes mean and what action should be taken for each.



When troubleshooting, always remember to check all cable connections first before proceeding with other problem isolation steps.

**Table 4-1. Error Codes and Corrective Action** 

Error Code	Probable Cause	Corrective Action	
0 Blinking	Configuration	No POS interface has been selected (Null interface). See Chapter 7, "Interface Type" to select the required interface using programming barcodes.	
1	Configuration Error	See Chapter 7, Programming, for details about configuring the scanner using programming barcodes.	
2	Interface Board	Unplug unit and call technical support personnel.	
3	Motor	Unplug unit and call technical support personnel.	
4	Horizontal Laser <sup>a</sup>	Call technical support personnel.	
5	Vertical Laser <sup>a</sup>	Call technical support personnel.	
6	Digital Board	Unplug unit and call technical support personnel.	
7	Scale	See the topic Scale Error Reporting in this section for problem identification and corrective actions.	
8	Remote Display	Connect the Remote Display. If necessary, replace display or cable. Alternatively, you can disable the Remote Display using the programming procedures described in Chapter 7.	
9	EAS Error	No EAS communication. Check EAS cable connections. Call technical support personnel.	
Α	Button Module	Call technical support personnel.	
b	Hardware ID	Call technical support personnel.	
С	Scale Calibration	Proceed to scale calibration procedure.	
Е	CPLD ID	Call technical support personnel.	
Decimal Point	3.3 V Present	If not lit, call technical support personnel.	

a. If only one laser is non-functional, the scanner may continue to work (this is a configurable feature); however, the 7-segment display will show the error code indicating the failed laser. If both lasers have failed, the 7-segment display will display either a 4 or a 5, and the scanner will cease to function until serviced. No alternate blinking of lamps will occur if only one laser has failed.




Figure 4-1. 7-Segment LED Display

# **Scale Error Reporting**

Scale diagnostics uses the Remote Scale Display and the Zero Status lamp to communicate specific scale failures. The following chart shows the Remote Display messages, the Scale Status lamp indication, the problem that the scale is experiencing and what action should be taken. When troubleshooting, always remember to check all cable connections first before proceeding with other problem isolation steps.

**Table 4-2. Scale Error Reporting** 


Remote Display	Scale Status Lamp	Problem Description	Action Required	
E_1	Flash, pause, 1 blink, long pause, repeat sequence.	Too much motion at power- up.	Check for stable installation. Change scale motion filter using the labels found in Section 7; restart. If problem persists, scale may require calibration.	
E_2	Flash, pause, 2 blinks, long pause, repeat sequence.	Calibration lost.	Call technical support personnel. Recalibrate; restart; recertify (if required).	
E_3	Flash, pause, 3 blinks, long pause, repeat sequence.	Scale communication lost. Internal scanner/scale prob- lem.	Call technical support personnel; report error.	
E4	Flash, pause, 4 blinks, long pause, repeat sequence.	Scale module failure.	Call technical support personnel; report error.	
E5	Flash, pause, 5 blinks, long pause, repeat sequence.	Internal software fault.	Call technical support personnel; report error.	
Other Scale Reporting				
- 0 -	Off	Cannot zero at power- up or weight remains on scale for more than 4 minutes or weight has not returned to zero between POS weight requests <sup>a</sup> .	- Check debris chutes Verify that the weigh platter moves freely Remove item(s) from scale - Press Scale Zero Push Button - for more information If the scale still fails to zero, recalibrate the scale.	

a. This is a configurable feature.

### **Flowcharts**

The problem isolation flowcharts on the following pages allow you to identify and troubleshoot problems with your system.

Figure 4-2. Problem Isolation: Start







Figure 4-3. Problem Isolation: Selftest

Figure 4-4. Problem Isolation: Poor/No Reading






Figure 4-5. Problem Isolation: No Transmit to POS

If this is a new installation. **SCALE START** make sure any foam packing pieces have been removed from the scale cavity before proceeding. Lift off the platter View the Remote to verify, then set the platter **Call Tech Support** Display and/or the back into position. Yellow scale status LED for the scale error code. Reference the topic. YFS Scale Error Reporting in Section 4 for more Is the information. YES NO motion filter problem DONE at its maximum fixed setting Check for debris under platter. shown on YES NO Verify that the weigh platter RemoteDisplay/ moves freely. Increase the scale Yellow Remove item(s) from scale. motion filter setting by LED off Press Scale Zero Button 1. Reference Section 6 If the scale still fails to zero. for more information. NO recalibrate the scale. NO Problem is too much shown on ls YES YES Remote Display motion at power-up. problem **DONE** Yellow LED Correct excess vibration fixed Flash once in counter if possible. NO NO Problem is calibration shown on Will the YES YES lost. Recalibrate the scale Remote Display scale DONE using the procedures in Yellow LED calibrate Flash twice Section 5. NO For this error, the 7-segment display may also show a 'C'. Problem is scale shown on YES YES communication lost. RemoteDisplay/ problem **DONE** Verify cable connections Yellow LED Flash fixed to/from the scale. 3 times NO \_4 shown on Remote Display/Yellow LED Flash **Call Tech Support** 4 times. Problem is Scale Load Cell failure.

Figure 4-6. Problem Isolation: Scale

Figure 4-7




Figure 4-8. Problem Isolation: Remote Display

**NO EAS DEACTIVATION** Ensure operator has been **START** trained in proper EAS system use (reference Chapter 3). Verify programmable parameters using the information and programming barcodes provided in Chapter 6. Check EAS options, and other configurable features. Check all EAS If possible, retest the system substituting Does the NO cable connections. EAS Antenna deactivate known-good EAS cable and/or controller box. labels YES Does the NO EAS Antenna deactivate Does the YES labels EAS Antenna **DONE** deactivate YES labels NO DONE Call Tech Support.

Figure 4-1. Problem Isolation: EAS System

# **NOTES**

# **Section 5**

# **Calibration Procedures, Single Interval**



This section applies to scanner/scale models with single interval ONLY.

A number of situations require the scale to be calibrated. They are:

- at initial installation of the scanner/scale
- if the scale cannot be re-zeroed
- if you change the weight measure from pounds to kilograms or vice-versa
- if diagnostics indicate a calibration error
- the weigh module has been replaced

Follow the procedures on the following pages to ensure that the scanner/scale will meet Weights and Measurement requirements.

**LEGAL NOTE** 

Certification of the scanner/scale's weighing apparatus is subject to Federal, State and Local Weights and Measures statutes and is restricted to authorized government agencies and/or duly registered agents thereof. Anytime a scale is calibrated, it should be properly sealed with a lead and wire or paper seal before being placed into service.

It is your responsibility to check with the appropriate authorities in your area to ensure compliance with pertinent regulations before removing any official seals or placing a newly calibrated scanner/scale into service.

# **Description of Calibration Sequence**

The Calibration Sequence sets the scale to an accurate reference point for weighing. This process involves the use of a Field Standard Weight Set (31.5-pounds) for calibration in pounds, (18.5-kilograms) for Metric. Once calibration has been successfully completed, the scanner/scale uses the certified weight as a reference for subsequent weighing activities.

These verification procedures follow the *U.S. National Institute of Standards and Technology 44 Handbook* guidelines for bench/counter scale installations.

If any of these tests fail to meet the required weight indications, you must calibrate the scanner/scale. Refer to the calibration procedures in this section for the proper procedures.

You may be required by state and/or local regulations to have procedures other than these performed by a certified technician or verification official.

Access to the calibration switch should be restricted with a paper or a wire and lead seal after the calibration has been performed if required by your local regulatory agency.



NOTE

The Calibration Sequence must be performed without removing the scanner/ scale from its installed position.

The following tools and supplies will be required to perform the calibration process:

- 31.5 pound Field Standard Weight Set<sup>1</sup>. (English calibration only).
- 18.5 kilogram Field Standard Weight Set<sup>2</sup>. (Metric calibration only).
- Lead/Wire or Paper Seal (as required by law).
- NOTE: Throughout the calibration procedures, specified weights may be achieved by using a combination of weights from this set. eg. 20 lbs may be made up of one 10.00 lb. weight and two 5.00 lb. weights.
- NOTE: Throughout the calibration procedures, specific weights may be achieved by using a combination of weights from this set. eg. 10 kgs. may be made up of one 5.00 kg. and five 1.00 kg. weights.

#### **Motion Test**

This test verifies that the scale will not 'zero' when the weighing surface of the scanner/scale is in motion.

- 1. Verify that the Yellow LED<sup>1</sup> is on and the Remote Display reads 0.00 pounds, 0.000 pounds or 0.000 kilograms.
- 2. Press lightly on the weigh platter of the scanner/scale with one hand and at the same time press and release the Zero Push Button on the operator's panel. The Yellow LED should turn Off and the Remote Display should not display 0.00 pounds, 0.000 pounds or 0.000 kilograms.
- Remove your hand from the weighing platform and verify that the Yellow LED is On and the Remote Display reads 0.00 pounds, 0.000 pounds or 0.000 kilograms.

# **Automatic Zero Tracking Test**

This test verifies that the scanner/scale automatic zero tracking mechanism is operating correctly.

 Place 0.006 pounds (3 grams for metric) on the center of the weighing platform. The entire weight must be placed on the weighing platform at once for this test to be valid. The Yellow LED should go Off and the Remote Display should read 0.01 pounds (0.005 kilograms).



NOTE

The scanner/scale has an adaptive zero capture mechanism that re-zeros the scale over time if there is a slow change in the zero level; thus if all the weight is not placed on the weighing surface at one time, the Yellow LED will remain On and the Remote Display will read 0.00 pounds (0.000 kilograms). When the weight is removed, the Yellow LED will turn off and the display will show a minus sign \_\_\_\_\_\_\_ Press the Zero Push Button to re-zero the scale.

Yellow LED indications can be configured via feature programming and may not be enabled for certain functions.

# **Preparing the Scanner/Scale for Calibration**

- 1. Assure that the scanner/scale is stable, secure and properly installed. (Refer to Section 2, *Site Preparation and Installation* for instructions on the proper installation of the scanner/scale).
- 2. Power-up the scanner/scale.
- 3. Allow the unit to reach temperature equilibrium for at least one hour. If the scanner/scale is already at room temperature, allow at least 15 minutes for acclimatization.
- 4. Before performing the calibration, the scanner/scale must be prestressed with a weight of more than 30 pounds (15kg). With power turned on, place the entire weight set (including the case) on the weighing surface of the scale. The display should show an underscore and three hyphens \_\_\_\_\_\_, which is the overweight indication.
- 5. Remove all weight from the weighing surface and ensure that there are no obstructions in the debris chutes of the scanner/scale. See Figure 2-3.

# **Calibrating the Scale (Pounds & Kilograms)**

- 1. Before proceeding, ensure that the scanner/scale has been prepared for this process by performing the preceding steps titled, Preparing the Scanner/Scale for Calibration.
- 2. Remove the weigh platter and make sure that there are no obstructions in the debris chutes.
- Locate the calibration switch access cover. Since the position of this cover varies depending upon the model, Figure 5-1a and Figure 5-1c illustrates the two possible locations it can be found.
- 4. If one is present, cut and remove the seal securing the calibration switch access cover. The seal may not be present if this is the initial installation of the scanner/scale.



To protect static sensitive circuitry, follow Electro-Static Discharge (ESD) procedures when exposing internal scanner-scale components.

#### **ESD ALERT**


- 5. Expose the calibration switch. Depending upon the model type, either remove the calibration switch access cover by removing the screw as shown in Figure 5-1a, or slide the cover to reveal the switch as shown in Figure 5-1c.
- 6. Press and release the Calibration Switch to place the scanner/scale in Calibration Mode (See Figure 5-1b and Figure 5-1c). The scanner/scale will sound a tone indicating that it is in Calibration Mode. If the motor was spinning when you initiated Calibration Mode, the motor will stop and the Yellow LED will begin flashing indicating the scale is in Calibration Mode. The display will show the message "ESCL" (empty scale).
- 7. Reinstall the weigh platter.

- 9. When the scale is ready, the Yellow LED will begin blinking again and the display will show the message "Ad20 (add twenty pounds)" or "Ad10 (add ten kilograms)." The scanner/scale will also sound one tone if the scale is weighing in kilograms or two tones for pounds. Place the correct weight (twenty pounds for calibration in pounds, or ten kilograms for metric calibration) from the Field Standard Weight set on the center of the weighing area and press the Zero Push Button again.
- 10. The Yellow LED will extinguish for approximately 10 seconds and the Remote Display will alternately display \_\_\_\_ and until the scale is ready to proceed.
- 11. If the calibration was successful, the speaker sounds a single tone, the Scale Status LED begins blinking again, and "End-" appears in the Remote Display.
- 12. If the calibration was not successful, the speaker will sound five tones indicating a scale failure, and the Scale Status LED will blink twice, strobe (fast blinks) and then continually repeat this sequence until reset. Remove all weight from the Weigh Platter, and repeat the procedure starting with step 9.
- 13. Press the Zero Push Button again to permanently store the calibration data and exit Calibration Mode. You have completed the calibration of the scanner/scale. The unit's calibration must now be verified as required by state and/or local weights and measures regulations. The verification procedure must be performed to assure that a scale will pass Weights and Measures requirements before it is placed into commercial/retail service.

You have completed the scale calibration procedure. You must now continue with the calibration verification tests to complete the scale's calibration. If you are weighing in pounds, continue with the following procedures to verify that the scale was successfully calibrated and that it weighs properly. If you are weighing in kilograms, turn to the instructions titled, Calibration Verification (Kilograms), later in this section.

Figure 5-1. Calibration Cover & Switch

or...



#### **Calibration Verification (U.S. Pounds)**

Once you have completed the calibration sequence, you may be required to perform these step-by-step verification procedures. These procedures follow the *National Institute of Standards and Technology Handbook-44* guidelines for grocery scale installations. You may be required by state or local law to have these procedures performed by a certified technician or verified by a proper official.

These calibration verification procedures cover five different tests:

- Increasing-Load Test
- Shift Test
- Blanking Test
- Decreasing-Load Test
- Return to Zero Test

#### **Increasing-Load Test (Phase 1)**

This test checks Scale operation with five, ten and fifteen pound weights.

- 1. Check that the display reads 0.00 lb. when at rest with nothing on the weighing surface. (The Yellow LED is steadily lit).
- 2. Place a five-pound weight on the center of the weighing surface and check that the display reads 5.00 lb.
- 3. Place an additional five pounds on the center of the weighing surface and check that the display reads between 9.99 and 10.01 lb.
- 4. Place an additional five pounds on the center of the weighing surface and check that the display reads between 14.99 and 15.01. Remove the weights and verify that the display reads 0.00.
- 5. You have completed the Increasing-Load Test (Phase 1).

#### **Shift Test**

The Shift Test checks to ensure that items placed anywhere on the weighing surface of the scanner/scale are weighed properly. Refer to Figure 5-2 when performing this test.

- 1. Place and remove in succession, a ten-pound load on the center of each of the four quadrants (1, 2, 3, and 4 in Figure 5-2) of the scanner/scale's weigh platter. Verify that a reading of between 9.99 and 10.01 lb registers under load and that the display returns to 0.00 between each load.
- 2. After verifying the accuracy of each quadrant of the weighing surface, remove all weight from the scale. You have completed the Shift Test.




Figure 5-2. Shift Test

#### **Increasing-Load Test (Phase 2)**

After completing the Shift Test, you must complete the Increasing Load Test using 20.0, 25.0 and 30.0 pounds of weight.



NOTE

The upper limit of the scale is configurable according to POS interface type and may not necessarily be set at 30 pounds, which is the standard setting. For this test, continue to place weights in five pound increments only up to the upper weight limit set for your scale.

- 1. With the scale starting at zero, place 20.0 pounds in the center of the weighing surface and check that the display reads between 19.99 and 20.01 lb.
- 2. Place an additional five pounds in the center of the weighing surface, increasing the load to 25.0 pounds and check that the display reads between 24.99 and 25.01 lb.
- 3. Place an additional five pounds in the center of the weighing surface increasing the load to 30.0 pounds and check that the display reads between 29.99 and 30.01 lb.
- 4. Remove the weights and verify that the display reads 0.00.

#### **Blanking Test**

This test ensures that the scanner/scale will indicate its weighing capability has been exceeded if a weight greater than 0.05 pounds over its maximum upper weight limit is placed upon the unit.

- 1. Place weights that total the upper weight limit plus 0.51 pounds on the scale. For example: If the upper limit is set at 30 pounds, place weights equaling 30.051 pounds.
- 2. Verify that the display shows a dash and three hyphens (\_ - -). This is the overweight indication.



NOTE

The scanner/scale may blank (show an underscore and three hyphens) at any weight greater than its upper limit, but must blank when the upper limit plus 0.051 pounds are set upon the weighing surface.

#### **Decreasing-Load Test**

This test ensures that the scanner/scale responds properly when a heavy object is followed by a significantly smaller object.

1. Place a 30.0-pound load on the scale and verify that the display shows between 29.99 and 30.01 pounds.



If the upper weight limit for your scale is not set at 30 pounds, begin by placing weight equaling your upper limit setting.

- 2. Remove weights to leave 20 pounds on the scale. Check that the display shows between 19.99 and 20.01.
- 3. Remove another 15.0 pounds from the scale and check that the scale reads 5.00 lb.
- 4. You have completed the Decreasing Load Test.

#### **Return to Zero Test**

This test ensures that, after all other tests have been completed successfully, the scanner/scale returns to zero. Remove all weights from the scale and verify that the scale reads 0.00 lb.

After completing this test, close the calibration access cover and seal per local Weights and Measures requirements. This final step must agree with the legal requirements of your state or local government.

You have completed the calibration and verification process for weighing in pounds.

If the scanner/scale passes all these tests,

- 1. Remove the weigh platter, install the calibration switch cover and install a seal (if required).
- 2. Reinstall the weigh platter.

If the scanner/scale fails any of these tests, it should be serviced by a qualified technician.

# **Calibration Verification (Kilograms)**

Once you have completed the calibration sequence, you may be required to perform these step-by-step verification procedures. These procedures follow the *National Institute of Standards and Technology Handbook-44* guidelines for grocery scale installations. You may be required by state or local law to have these procedures performed by a certified technician or verified by a proper official.

These calibration verification procedures cover five different tests:

- Increasing-Load Test
- Shift Test
- Blanking Test
- Decreasing-Load Test
- Return to Zero Test

#### **Increasing-Load Test (Phase 1)**

This test checks Scale operation for increasing loads from 0.100 kg and 7.50 kg.

- 1. Check that the display reads 0.000 kg when at rest with nothing on the weighing surface. (The Yellow LED is steadily lit).
- 2. Place a 100 gram weight on the center of the weighing surface and check that the display reads 0.100 kg.
- 3. Place an additional 200 grams on the center of the weighing surface and check that the display reads 0.300 kg.
- 4. Place an additional 200 grams on the center of the weighing surface and check that the display reads 0.500 kg.
- 5. Place an additional 100 grams on the center of the weighing surface and check that the display reads 0.600 kg.
- 6. Place an additional 100 grams on the center of the weighing surface and check that the display reads 0.700 kg.
- 7. Place an additional 100 grams on the center of the weighing surface and check that the display reads 0.800 kg.
- 8. Place an additional 200 grams on the center of the weighing surface and check that the display reads 1.000 kg.

- 9. Increase the weight on the scale to 7.50 kg on the center of the weighing surface and check that the display reads between 7.495 and 7.505 kg.
- 10. Remove the weights and verify that the display reads 0.000 kg. You have completed the Increasing-Load Test (Phase 1).

#### **Shift Test (Metric)**

The Shift Test checks to ensure that items placed anywhere on the weighing surface of the scanner/scale are weighed properly. Refer to Figure 5-3 when performing this test.

- 1. Place and remove in succession, a 5.0 kilogram load on the center of each of the four quadrants (2, 3, 4, and 5 in Figure 5-3) and in the center (1) of the scanner/scale's weighing platform. Verify that the display shows a reading of between 4.995 and 5.005 kg for each quadrant/center test and that the display returns to 0.000 between each load.
- 2. After verifying the accuracy of each quadrant and the center of the weighing surface, remove all weight from the scale. You have completed the Shift Test.

(Models vary)

Figure 5-3. European Shift Test (Metric)

#### **Increasing-Load Test (Phase 2)**

After completing the Shift Test, you must complete the Increasing Load Test using 10.00, 12.50 and 15 kilograms of weight.



NOTE

The upper limit of the scale is configurable according to POS interface type and may not necessarily be set at 15 kilograms, which is the standard setting. For this test, continue to place weights in 2.50 kilgram increments only up to the upper weight limit set for your scale.

- 1. Place 10.00 kilograms in the center of the weighing surface and check that the display reads between 9.990 kg and 10.010 kg.
- 2. Place an additional 2.50 kilograms in the center of the weighing surface and check that the display reads between 12.490 kg and 12.510 kg.

- 3. Place an additional 2.50 kilograms in the center of the weighing surface and check that the display reads between 14.990 kg and 15.010 kg.
- 4. Remove the weights and verify that the display reads 0.000 kg.
- 5. You have completed phase two of the increasing load test.

#### **Blanking Test**

This test ensures that the scanner/scale will indicate its weighing capability has been exceeded if a weight greater than 0.82 kg. over its maximum upper weight limit is placed upon the unit.

- 1. Place weights that total the upper limit plus 0.82 kilograms on the weigh platter. For example: If the upper limit is set at 15 kilograms, place weights equaling 15.82 kilograms.
- 2. Verify that the display shows a dash and three hyphens ( \_ - -). This is the overweight indication.



The scanner/scale may blank (show an underscore and three hyphens) at any weight greater than its upper limit, but must blank when the upper limit plus 0.82 kilograms are set upon the weighing surface.

#### **Decreasing-Load Test**

This test ensures that the scanner/scale responds properly when a heavy object is followed by a significantly smaller object.

1. Place weights that total 15.8 kilograms.



If the upper weight limit for your scale is not set at 15 kilograms, begin by placing weight equaling your upper limit setting plus 0.8 kilograms.

NOTE

- 2. Remove weights to leave 10 kilograms on the scale and verify that the display shows between 9.990 and 10.010 kilograms.
- 3. Remove an additional 9.00 kilograms from the scale and check that the scale reads 1.000 kg.
- 4. You have completed the Decreasing Load Test.

#### **Return to Zero Test**

This test ensures that, after all other tests have been completed successfully, the scanner/scale returns to zero. Without any weight on the weigh platter, verify that the scale reads 0.000 kg.

You have completed the calibration and verification process for weighing in kilograms.

If the scanner/scale passes all these tests,

- 1. Remove the weigh platter, install the calibration switch cover and install a seal (if required).
- 2. Reinstall the weigh platter.

If the scanner/scale fails any of these tests, it should be serviced by a qualified technician.

# **Section 6**

# **Calibration Procedures, Dual Interval**



This section applies to scanner/scale models with dual interval ONLY.

NOTE

A number of situations require the scale to be calibrated. They are:

- at initial installation of the scanner/scale
- if the scale cannot be rezeroed
- when changing the weight measure from pounds to kilograms or vice-versa
- if diagnostics indicate a calibration error
- when removing/replacing any scale assembly or the Main Board
- when required by local regulations

Follow the procedures on the following pages to ensure that the scanner/scale will meet Weights and

Measurement requirements.

LEGAL NOTE

Certification of the scanner/scale's weighing apparatus is subject to Federal, State and Local Weights and Measures statutes and is restricted to authorized government agencies and/or duly registered agents thereof. Anytime a scale is calibrated, it should be properly sealed with a lead and wire or paper seal before being placed into service.

It is your responsibility to check with the appropriate authorities in your area to ensure compliance with pertinent regulations before removing any official seals or placing a newly calibrated scanner/scale into service.

# **Description of Calibration Sequence**

The Calibration Sequence sets the scale to an accurate reference point for weighing. This process involves the use of a Field Standard Weight Set (31.5-pounds) for calibration in pounds, (18.5-kilograms) for Metric calibration. Once calibration has been successfully completed, the scanner/scale uses the certified weight as a reference for subsequent weighing activities.

These verification procedures follow the *U.S. National Institute of Standards and Technology 44 Handbook* guidelines for bench/counter scale installations.

If any of these tests fail to meet the required weight indications, you must calibrate the scanner/scale. Refer to the calibration procedures in this section for the proper procedures.

You may be required by state and/or local regulations to have procedures other than these performed by a certified technician or verification official.

Access to the calibration switch should be restricted with a paper or a wire and lead seal after the calibration has been performed if required by your local regulatory agency.



NOTE

The Calibration Sequence must be performed without removing the scanner/scale from its installed position.

The following tools and supplies will be required to perform the calibration process:

- 31.5 pound Field Standard Weight Set<sup>1</sup>. (English calibration only).
- 18.5 kilogram Field Standard Weight Set<sup>2</sup>. (Metric calibration only).

NOTE: Throughout the calibration procedures, specified weights may be achieved by using a combination of weight from this set. e.g. 20 lbs may be made up of one 10.00 lb. weight and two 5.00 lb. weights.

NOTE: Throughout the calibration procedures, specified weights may be achieved by using a combination of weights from this set. e.g. 10 kgs. may be made up of one 5.00 kg. and five 1.00 kg. weights.

• Lead wire or paper seal (as required by law).

#### **Motion Test**

This test verifies that the scale will not 'zero' when the weighing surface of the scanner/scale is in motion.

- 1. Verify that the Zero lamp is On and the Remote Display reads 0.00 pounds, 0.000 pounds or 0.000 kilograms.
- Press lightly on the weigh platter of the scanner/scale with one hand and at the same time press and release the Zero switch on the operator's panel. The Zero lamp should turn Off and the Remote Display should not display 0.00 pounds, 0.000 pounds or 0.000 kilograms.
- 3. Remove your hand from the weighing platform and verify that the Zero lamp is On and the Remote Display reads 0.00 pounds, 0.000 pounds or 0.000 kilograms.

# **Automatic Zero Setting Test**

This test verifies that the scanner/scale automatic zero setting mechanism is operating correctly.

1. Place 0.0035 pounds (1.6 grams for metric) on the center of the weighing platform. The entire weight must be placed on the weighing platform at once for this test to be valid. The Zero lamp should go Off and the Remote Display should read 0.005 pounds (0.002 kilograms).



NOTE

The scanner/scale has an adaptive zero capture mechanism that re-zeros the scale over time if there is a slow change in the zero level; thus, if all the weight is not placed on the weighing surface at one time, the Zero lamp will remain On and the Remote Display will read 0.00 pounds or 0.000 pounds (0.000 kilograms). When the weight is removed, the Zero lamp will turn off and the display will show a minus sign \_\_\_\_\_\_\_\_. Press the Zero switch to rezero the scale.

# **Preparing the Scanner/Scale for Calibration**

- Assure that the scanner/scale is stable.
- 2. Power-up the scanner/scale.
- 3. Allow the unit to reach temperature equilibrium for at least one hour. If the scanner/scale is already at room temperature, allow at least 15 minutes to acclimate.
- 4. Before performing the calibration, the scanner/scale must be prestressed with a weight of more than 30 pounds (15kg). With power turned on, place the entire weight set (including the case) on the weighing surface of the scale. The display should show an underscore and three hyphens (\_---), which is the overweight indication.
- 5. Remove all weight from the weighing surface and ensure that there are no obstructions in the debris chutes of the scanner/scale.

# **Calibrating the Scale (Pounds & Kilograms)**


- 1. Before proceeding, ensure that the scanner/scale has been prepared for this process by performing the preceding steps titled, Preparing the Scanner/Scale for Calibration.
- 2. Verify that there are no obstructions under the weigh platter. Remove the weigh platter (L-Platter) and make sure that there are no obstructions in the debris chutes (see Figure 2-3).
- 3. Cut and remove the seal that secures the Calibration Switch Cover to the Scale Mounting Bracket.
- 4. Slide the cover to reveal the switch as shown in Figure 6-1.
- 5. Press and release the Calibration Switch (see Figure 6-1) to place the scanner/scale in Calibration Mode. The scanner/scale will sound a tone indicating that it is in Calibration Mode. If the motor was spinning when you initiated Calibration Mode, the motor will stop and the Scale Status (yellow LED) will flash, indicating the scale is in Calibration Mode. The Remote Display shows the message "ESCL" (empty scale).
- 6. Reinstall the weigh platter.
- 7. Press the Scale Zero Button. The Scale Status (yellow LED) will go out for approximately 10 seconds (or less) and the Remote Display will alternately display ---- and \_\_\_\_ until the scale is ready to proceed.
- 8. When the scale is ready, the Scale Status (yellow LED) begins blinking again, and the display shows the message "Ad20 (add twenty pounds)" or "Ad10 (add ten kilograms)." The scanner/scale will also sound one tone if the scale is weighing in kilograms or two tones for pounds if you don't have a Remote Display.
- 9. Place the correct weight (twenty pounds for calibration in pounds, or ten kilograms for metric calibration) from the Field Standard Weight set, onto the center of the weighing area. Press the Scale Zero Button again.
- 10. The Scale Status LED extinguishes for approximately 10 seconds and the Remote Display alternately displays ---- and \_\_\_\_ until the scale is ready to proceed.

- 11. If the calibration was successful, the speaker sounds a single tone, the Scale Status LED begins blinking again, and "End-" appears in the Remote Display.
- 12. If the calibration was not successful, the speaker sounds five tones indicating a scale failure, and the Scale Status LED will blink twice, strobe (fast blinks), and then continually repeat this sequence until reset. Remove all weight from the Weigh Platter, and repeat the procedure starting with step 8.
- 13. Press the Scale Zero Button again to permanently store the calibration data and exit Calibration Mode. You have completed the calibration of the scale. The unit's calibration must now be verified as required by state and/or local weights and measures regulations. The verification procedure must be performed to assure that a scale will pass Weights and Measures requirements before it is placed into commercial/retail service.

You have completed the scale calibration procedure. Before replacing the Calibration Switch Cover and sealing the scale, you must now continue with the calibration verification tests to complete the scale's calibration. If you are weighing in pounds, continue with the following procedures to verify that the scale was successfully calibrated and that it weighs properly. If you are weighing in kilograms, turn to the instructions titled, .

Figure 6-1. Calibration Cover and Switch Location

or...



#### **Calibration Verification (Pounds)**

Once you have completed the calibration sequence, you may be required to perform these step-by-step verification procedures. These procedures follow the *National Institute of Standards and Technology Handbook-44* guidelines for grocery scale installations. You may be required by state or local law to have these procedures performed by a certified technician or verified by a proper official.

These calibration verification procedures cover five (5) different tests:

- Increasing-Load Test
- Shift Test
- Blanking Test
- Decreasing-Load Test
- Return to Zero Test



If the scale fails any of the following tests, go to Section 4, Problem Isolation, of this manual and follow the troubleshooting procedures for SCALE FAILURE.

# **Increasing-Load Test (Phase 1)**

This test checks Scale operation with two, four and six pound weights.

- 1. Check that the display reads 0.00 lb. when at rest with nothing on the weighing surface. (The Zero Status LED is on steady).
- Place a two-pound weight on the center of the weighing surface. Verify that the Remote Display reads 2.00 lb.
- 3. Place an additional two pounds (four pounds total) on the center of the weighing surface. Verify that the Remote Display reads between 3.995 and 4.005 lb.
- 4. Place an additional two pounds (six pounds total) on the center of the weighing surface. Verify that the Remote Display reads

between 5.995 and 6.005. Remove the weights and verify that the display reads 0.00.

5. You have completed the Increasing-Load Test (Phase 1).

# **Shift Test (6 Pounds)**

The Shift Test checks to ensure that items placed anywhere on the weighing surface of the scanner/scale are weighed properly. Refer to Figure 6-2 when performing this test.

- 1. Place and remove, in succession, a six-pound load on the center of each of the four quadrants: 1, 2, 3, and 4, (as shown in Figure 6-2) of the scanner/scale's weigh platter. Verify that a reading of between 5.995 and 6.005 lb. registers, under load, in each quadrant tested. Check that the display returns to 0.00 between each load.
- After verifying the accuracy of each quadrant of the weighing surface, remove all weight from the scale. This completes the Shift Test.




Figure 6-2. Shift Test

# **Increasing-Load Test (Phase 2)**

After completing the Shift Test, you must complete the Increasing Load Test using 8.0, 10.0 and 12.0 pounds of weight.



The upper limit of the scale is configurable according to the POS interface type and may not necessarily be set at 30 pounds, which is the standard setting. For this test, continue to place weights in two pound increments only up to the upper weight limit set for your scale.

- 1. With the scale starting at zero, place 8.0 pounds in the center of the weighing surface and check that the display reads between 7.995 and 8.005 lb.
- 2. Place an additional two pounds (10 pounds total) in the center of the weighing surface. Check that the display reads between 9.995 and 10.005 lb.
- 3. Place an additional two pounds in the center of the weighing surface increasing the load to 12.0 pounds and check that the display reads between 11.995 and 12.01 lb.
- 4. Place an additional five pounds (fifteen pounds total) on the center of the weighing surface. Verify that the Remote Display reads between 14.99 and 15.01. Remove the weights and verify that the display reads 0.00.
- 5. You have completed the Increasing-Load Test (Phase 3).

# **Shift Test (10 Pounds)**

The Shift Test checks to ensure that items placed anywhere on the weighing surface of the scanner/scale are weighed properly. Refer to Figure 6-2 when performing this test.

1. Place and remove, in succession, a ten-pound load on the center of each of the four quadrants: 1, 2, 3, and 4, (as shown in Figure 6-2) of the scanner/scale's weigh platter. Verify that a reading of between 9.99 and 10.01 lb. registers, under load, in each quadrant tested. Check that the display returns to 0.00 between each load.

2. After verifying the accuracy of each quadrant of the weighing surface, remove all weight from the scale. This completes the Shift Test.

# **Increasing-Load Test (Phase 3)**

After completing the Shift Test, you must complete the Increasing Load Test using 20.0, 25.0 and 30.0 pounds of weight.



The upper limit of the scale is configurable according to the POS interface type and may not necessarily be set at 30 pounds, which is the standard setting. For this test, continue to place weights in five pound increments only up to the upper weight limit set for your scale.

- 1. With the scale starting at zero, place 20.0 pounds in the center of the weighing surface and check that the display reads between 19.99 and 20.01 lb.
- 2. Place an additional five pounds (25 pounds total) in the center of the weighing surface. Check that the display reads between 24.99 and 25.01 lb.
- 3. Place an additional five pounds in the center of the weighing surface increasing the load to 30.0 pounds and check that the display reads between 29.99 and 30.01 lb.

Remove the weights and verify that the display reads 0.00.

# **Blanking Test**

This test ensures that the scanner/scale will indicate its weighing capability has been exceeded if a weight greater than 0.05 pounds over its maximum upper weight is placed upon the unit.

1. Place weights that total the upper weight limit plus 0.051 pounds on the scale. For example: If the upper limit is set at 30 pounds, place weights totaling 30.051 pounds on the scale.

2. Verify that the display shows a dash and three hyphens (\_ - - -). This is the overweight indication.



The scanner/scale may blank (show an underscore and three hyphens) at any weight greater than its upper weight limit, but <u>must</u> blank when the upper weight limit plus 0.051 pounds are set upon the weighing surface.

# **Decreasing-Load Test**

This test ensures that the scanner/scale responds properly when a heavy object is followed by a significantly smaller object.

1. Place a 30.0-pound load on the scale and verify that the display shows between 29.99 and 30.01 pounds.



NOTE

If the upper weight limit for your scale is set to other than 30 pounds, begin by placing weight equaling your upper limit setting.

- 2. Remove enough weights to leave 20 pounds on the scale. Check that the display shows between 19.99 and 20.01.
- 3. Remove 8.0 pounds and verify the display reads between 11.995 and 12.01 pounds.
- 4. Remove 4.0 pounds and verify the display reads between 7.995 and 8.005 pounds.
- 5. Remove another 6.0 pounds from the scale and check that the scale reads 2 lbs.

You have completed the Decreasing Load Test.

#### **Return to Zero Test**

This test ensures that, after all other tests have been completed successfully, the scanner/scale returns to zero. Remove all weights from the scale and verify that the scale reads 0.00 lb.

After completing this test, close the calibration access cover and seal per local Weights and Measures requirements. This final step must agree with the legal requirements of your state or local government.

You have completed the calibration and verification process for weighing in pounds.

If the scanner/scale passes all these tests:

- 1. Remove the weigh platter, install the calibration switch cover and install a seal (if required).
- 2. Replace the weigh platter.

If the scanner/scale fails any of these tests, it should be serviced by a qualified technician.

# **Calibration Verification (Kilograms)**

Once you have completed the calibration sequence, you may be required to perform these step-by-step verification procedures. These procedures follow the *National Institute of Standards and Technology Handbook-44* guidelines for grocery scale installations. You may be required by state or local law to have these procedures performed by a certified technician or verified by a proper official.

These calibration verification procedures cover five (5) different tests:

- Increasing-Load Test
- Shift Test
- Blanking Test
- Decreasing-Load Test
- Return to Zero Test



If the scale fails any of these tests, go to the topic Scale Error Reporting in Section 4, Problem Isolation, of this manual.

# **Increasing-Load Test (Phase 1)**

This test checks scale operation for increasing loads from 0.050 kg and 3 kg.

- 1. Check that the display reads 0.000 kg when at rest with nothing on the weighing surface. (The Zero Status LED is on steady).
- 2. Place a 50 gram weight on the center of the weighing surface and check that the Remote Display reads 50 grams.
- 3. Place an additional 100 grams on the center of the weighing surface (.0300 kg. total) and check that the Remote Display reads 150 grams.
- 4. Place an additional 100 grams on the center of the weighing surface and check that the Remote Display reads 250 grams.
- 5. Place an additional 50 grams on the center of the weighing surface and check that the display reads 300 grams.
- 6. Place an additional 50 grams on the center of the weighing surface and check that the display reads 350 grams.
- 7. Place an additional 50 grams on the center of the weighing surface and check that the display reads 400 grams.
- 8. Place an additional 100 grams on the center of the weighing surface and check that the display reads 500 grams.
- 9. Increase the weight on the center of the weighing surface to 2.5 kg and check that the display reads between 2.998 and 3.002 kg.
- 10. Remove the weights and verify that the display reads 0.000 kg. You have completed the Increasing-Load Test (Phase 1).

# Shift Test (Metric — 2 Kilogram)

The Shift Test checks to ensure that items placed anywhere on the weighing surface of the scanner/scale are weighed properly. Refer to Figure 6-3 when performing this test.

- 1. Place and remove, in succession, a 2 kilogram load on the center of each of the four quadrants: 2, 3, 4, and 5, and in the center (1) of the scanner/scale's weighing platform (see Figure 6-3). Verify that the Remote Display shows a reading of between 1.998 and 2.002 kg for each quadrant/center test. Check that the display returns to 0.000 between each load.
- 2. After verifying the accuracy of each quadrant and the center of the weighing surface, remove all weight from the scale. This completes the Shift Test (Metric 2 Kilogram).




Figure 6-3. Metric Shift Test

# **Increasing-Load Test (Phase 2)**

After completing the Shift Test, you must complete the Increasing Load Test using 4, 5 and 6 kilograms of weight.



The upper limit of the scale is configurable according to POS interface type and may not necessarily be set at 15 kilograms, which is the standard setting. For this test, continue to place weights in 1 kilogram increments only to the upper weight limit set for your scale.

- 1. Place 4 kilograms in the center of the weighing surface and check that the Remote
  Display reads between 3.998 kg and 4.002 kg.
- 2. Place an additional 1 kilogram in the center of the weighing surface and check that the display reads between 4.998 kg and 5.002 kg.
- 3. Place an additional 1 kilogram in the center of the weighing surface and check that the display reads between 5.998 kg and 6.005 kg.
- 4. Increase the weight on the center of the weighing surface to 7.50 kg and check that the display reads between 7.495 and 7.505 kg.
- 5. Remove the weights and verify that the display reads 0.000 kg. You have completed the Increasing-Load Test.

# **Shift Test (Metric – 5 Kilograms)**

The Shift Test checks to ensure that items placed anywhere on the weighing surface of the scanner/scale are weighed properly. Refer to Figure 6-3 when performing this test.

- 1. Place and remove, in succession, a 5.0 kilogram load on the center of each of the four quadrants: 2, 3, 4, and 5, and in the center (1) of the scanner/scale's weighing platform (see Figure 6-3). Verify that the Remote Display shows a reading of between 4.995 and 5.005 kg for each quadrant/center test. Check that the display returns to 0.000 between each load.
- 2. After verifying the accuracy of each quadrant and the center of the weighing surface, remove all weight from the scale. This completes the Shift Test (Metric 5 Kilograms).

# **Increasing- Load Test (Phase 3)**

After completing the Shift Test, you must complete the Increasing Load Test using 10.00, 12.50 and 15 kilograms of weight.



The upper limit of the scale is configurable according to POS interface type and may not necessarily be set at 15 kilograms, which is the standard setting. For this test, continue to place weights in 2.50 kilograms increments only to the upper weight limit set for your scale.

- Place 10.00 kilograms in the center of the weighing surface and check that the Remote Display reads between 9.990 kg and 10.010 kg.
- 2. Place an additional 2.50 kilograms in the center of the weighing surface and check that the display reads between 12.490 kg and 12.510 kg.
- 3. Place an additional 2.50 kilograms in the center of the weighing surface and check that the display reads between 14.990 kg and 15.010 kg.
- 4. Remove the weights and verify that the display reads 0.000 kg.

You have completed Phase 4 of the Increasing Load Test.

# **Blanking Test**

This test ensures that the scanner/scale will indicate its weighing capability has been exceeded if a weight greater than 0.82 kilograms over its maximum upper weight limit is placed upon the scale platter.

1. Place weights that total the upper limit plus 0.82 kilograms on the weigh platter. For example: If the upper limit is set at 15 kilograms, place weight totaling 15.82 kilograms.

2. Verify that the display shows a dash and three hyphens (\_---). This is the overweight indication.



The scanner/scale may blank (show an underscore and three hyphens) at any weight greater than its upper limit plus 0.82 kilograms are set upon the weighing surface.

#### **Decreasing-Load Test**

This test ensures that the scanner/scale responds properly when a heavy object is followed by a significantly smaller object.

1. Place weights that total 15.8 kilograms.



If the upper weight limit for your scale is not set at 15 kilograms, begin by placing weight equaling your upper limit plus 0.8 kilograms.

NOTE

- 2. Remove weights to leave 10 kilograms on the scale and verify that the display shows between 9.990 and 10.010 kilograms.
- 3. Remove an additional 4 kilograms from the scale and check that the scale reads between 5.998 and 6.005 kg.
- 4. Remove an additional 2 kilograms from the scale and check that the scale reads between 3.998 and 4.002 kg.
- 5. Remove an additional 3 kilograms from the scale and check that the scale reads 1 kg.
- 6. You have completed the Decreasing Load Test.

#### **Return to Zero Test**

This test ensures that, after all other tests have been completed successfully, the scanner/scale returns to zero. Without any weight on the weigh platter, verify that the scale reads 0.000 kg.

You have completed the calibration and verification process for weighing in kilograms.

If the scanner/scale passes all these tests:

- 1. Remove the weigh platter, install the calibration switch cover and install a seal (if required).
- 2. Reinstall the weigh platter.

If the scale fails any of these tests, turn to Section 4, Problem Isolation and follow the troubleshooting procedures for Scale Failures.

# **NOTES**

# **Section 7**

# **Programming**

# **Introduction to Label Programming**

The programming barcode labels contained in this manual will allow you to customize and configure features and settings for your scanner (scanner/scale). To ensure full compatibility and proper function, use only the programming barcodes in this manual and other product-specific publications to program scanner features.

This manual has been developed to make it quick and easy for users of all levels to find the information needed to understand and configure features. The following descriptions will help you to determine where to go from here.

# **Understanding the Basics**

If you have little or no prior experience with programming using barcode labels, you should review the first few pages of this section to familiarize yourself with the basics of scanner programming before performing any changes to your configuration.

# Integrating the Scanner With Your Host System

Your scanner MUST be equipped with the correct hardware (interface board, cable, etc.) to properly communicate with your host system. Contact your dealer for information if you have questions about your scanner's hardware compatibility.

You may also want to contact the dealer or your system administrator if you have no record of how your scanner was pre-programmed at the factory. Scanners are typically programmed with the default settings for specific interface types (see Appendix E, *Factory Defaults* for more information); however, your scanner may have been custom configured with settings that are unique to your company or application.

Once you know the scanner's current settings, you can determine what changes will be required to allow communication with your host system and/or optional features you choose to modify to customize your installation. After recording the modifications needed, finish reading this section, then turn to the appropriate page and follow the instructions to program the scanner.

When all scanner features are programmed to your satisfaction, the scanner is ready to be placed into operation.

#### **Customizing Your Scanner's Operation**

Most scanner programming falls within three general categories:

- General Scanner and Scale Features are features common to all interface types. Examples include beeper adjustments such as volume and length, read verification settings, etc.
- Interface Related Features are the mandatory settings necessary to allow communication with your host terminal. Examples of these settings are: RS-232 baud rate and parity.



It is possible, via programming barcodes, to change the interface type (for example: from RS-232 to IBM Port 17). Great care should be taken to select the correct interface type, since you can cause damage to the scanner and/or POS terminal by attempting to change to an incompatible interface. ALWAYS make interface selections with the host cable DISCONNECTED.



**NOTE** 

Ensure that your planned modifications are compatible with the current interface. For example, baud rate selections are only valid in the RS-232 interface. The scanner will sound an error tone when scanning programming labels for features invalid to the current interface group.

• Symbology Programming - gives the scanner the capability to autodiscriminate as few as one, and as many as all available symbologies. For optimal scanner performance enable only those symbologies required. Additionally the scanner may be programmed with the standard options available for the various symbologies, such as check digit, minimum label length, fixed and variable length barcodes, etc. If you experience difficulties, have questions or require additional information, contact your local distributor, or call your dealer or sales representative.

# **Programming Overview**

The scanner's programmable feature settings can be modified to accommodate your system's unique requirements. These settings can be communicated to the scanner in one of two ways:

- Commands can be sent directly from the host. A limited set of host commands are available. Refer to Appendix D for more details or contact Tech Support.
- Programming barcode labels can also be used to modify the scanner's programmable settings. This manual provides the barcode labels and instructions necessary to configure the scanner's features and options.



When you program the scanner using any of the methods above, the scanner will store the changes until reprogrammed or returned to factory defaults.

#### **Programming via Handheld Device**

The scanner can also accept programming via its auxiliary port using a handheld scanning device. Eligible handheld devices must have the ability to transmit Code 128 function codes such as the programming barcodes presented in this manual. Datalogic<sup>TM</sup> models QuickScan® 1000 and QuickScan® 6000 support this functionality. Handheld data format requirements (baud rate, parity, etc.) are presented in Appendix F of this manual. Additionally the programmable feature, *Aux Port Mode*, must be set to "External Handheld Input" to allow operation.

#### What Is Programming Mode?

Programming Mode is a state in which the scanner must be placed in order to accept commands via programming barcode labels. When programming using the barcode labels in this manual, the scanner is typically placed in Programming Mode by scanning the SWITCH label.

While in the Programming Mode, the scanner only recognizes the special programming barcodes contained in this programming guide. See Appendix A for information about scanner indications while in the Programming Mode.

#### **Entering and Exiting Programming Mode.**

Use the barcode label below to enter and exit ('switch" into and out of) Programming Mode.



SWITCH LABEL

#### **Programming Session**

A typical programming session is conducted as follows:

- Scan the SWITCH barcode to place the scanner in Programming Mode. Depending upon its current programming, the scanner may emit a beep or beeps, indicating it has read the barcode and the green LED will flash on and off slowly while the scanner remains in Programming Mode. Normal scanning functions are disabled.
- 2. Scan the programming barcode(s) that is (are) specially encoded to make the desired changes. With few exceptions<sup>1</sup>, the scanner will emit a triple beep each time you scan a valid programming barcode.



Not all features are available for all interfaces and the scanner will sound an error tone when scanning programming barcodes for features invalid to the current interface. Only features supported by the currently active interface will be implemented.



If a barcode is scanned that changes the scanner's interface, all previous configuration items scanned in the programming session are lost.

Additionally, when programming a feature requiring you to scan single digits to set a multi-digit number, such as Minimum Label Length, scanning the SWITCH barcode (or any item tag/item value barcode) before completing all input will result in an error tone and cause the scanner to exit Programming Mode. Under these circumstances, the current feature you were trying to set is thrown out; any previous barcodes scanned during the session will take effect.

Some features, such as Minimum Label Length, require you to select the label's length by scanning a series of single-digit barcodes. A single 'good read' beep is sounded when scanning these single digits in Programming Mode. Only the final required digit in the sequence will produce a triple beep when scanned, indicating a successfully programmed feature.



NOTE

It is recommended that programming sessions be limited to one feature at a time. Should you make a mistake in the programming sequence, it can be difficult to discover where an error has been made if several features are programmed at once. Additionally, it can be confusing to determine which features may or may not have been successfully set following such a session.

3. Scan the SWITCH barcode to save any new settings and exit Programming Mode. The scanner will sound a beep and reset upon exiting Programming Mode, and the green LED will return to its usual state (on steady or off).

The scanner will exit Programming Mode under the following conditions:

- the programming sequence has been completed or the SWITCH barcode is scanned
- five minutes have passed without scanning activity. Any data programmed during the current session will be ignored<sup>1</sup>, and the scanner will reset and revert to its condition previous to initiating the exited session.
- power is disconnected. Disconnecting power during Programming Mode, before scanning the SWITCH barcode, will cause all new settings to be ignored. On power-up, the scanner will return to previous settings.
- 4. Maintain a good record of all changes made to ensure that you know if the original factory settings have been changed.

Exception: If an interface barcode had been read while in Programming Mode, the scanner will
operate on the default settings for the new interface.

### **Programming Sequence**

To modify a scanner feature (item), the programming barcodes contained in this manual must be scanned in a given sequence depending upon the feature being programmed (as shown in Table 7-1). There are three possible programming sequences:




If the scanner's interface type must be changed, always be sure that interface configuration is the FIRST item scanned during a programming session. (Selecting an interface type resets ALL other configuration items to the factory default for that interface type.)

- A. Programming sample A (the most commonly used format) demonstrates how three barcodes are scanned in sequence to do the following:
  - 1. Place the scanner in Programming Mode (SWITCH barcode).
  - 2. Scan the Item Tag<sup>1</sup> that will enable the new feature.
  - 3. End the programming session and reset the scanner (SWITCH barcode).
- B. Sample B provides an example of a programming feature requiring the entry of a range value. Like sample A, the scanner is placed in Programming Mode and an Item Tag¹ is scanned. Then, a value must be entered before ending the programming session. In the example, three digits must be scanned from the number pad in Appendix C. This type of format, requiring several barcodes, is necessary to allow flexible programming for item values with larger numeric ranges.
- C. The programming sequence shown in example C requires scanning of a single, extended length barcode. This special programming barcode contains all the data necessary to enter Programming Mode, set the Item Tag¹ and Item Value, and exit Programming Mode (all in one step).

An "Item Tag" is a term used to describe an assigned number, which is encoded in a programming barcode, that toggles (selects, enables, disables, etc.) a specific programming feature.

**Table 7-1. Programming Sequence** SET **ITEM TAG** ITEM VALUE



# **LED and Beeper Indicators**

The scanner provides a set of indicators that verify/announce the various scanner functions.

### If You Make a Mistake...

If, during a programming session, you find that you are unsure of the scanner's settings or wish to reset the scanner's configuration, use the Return to Factory Settings label below to return the scanner's configuration to the factory settings. Scanning this label will also reset any changes made during previous programming sessions.

## **Return to Factory Settings**

Scan this barcode to return the scanner to the default settings configured at the factory for the currently active interface. This barcode is typically used to return the scanner to a "known" operating state when the present programming status is not known, faulty, or suspect.



Use this barcode with caution, since it will reset ALL features that may have been programmed since the scanner's installation.



DO NOT scan the SWITCH barcode before and after scanning this barcode.



RETURN TO FACTORY SETTINGS

### **Test Mode**

Use this feature to place the scanner into a testing, or "demo" mode. This special mode disables the scanner interface, meaning that barcode data is not sent out to the host via the scanner interface. This allows the barcode to be scanned continuously without requiring a response from the POS terminal.

To return the scanner to normal function, scan the *TEST MODE* = *DIS-ABLE* barcode below.



DO NOT scan the SWITCH barcode before and after scanning the barcodes on this page.

Scanning the  $TEST\ MODE = DISABLE$  barcode sets the Double Read Timeout to 600ms.



TEST MODE = DISABLE



TEST MODE = ENABLE

### **General Scanner and Scale Features**

#### **Double Read Timeout**

The Double Read Timeout feature sets a time limit that determines how much time must pass before reading the same label again (e.g. two identical items in succession).

To set the Double Read Timeout:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



If the incidence of multiple reads is not acceptable, increase the Double Read Timeout setting to a higher value.



DOUBLE READ TIMEOUT = 400ms



DOUBLE READ TIMEOUT = 600ms

# **Double Read Timeout — continued**



DOUBLE READ TIMEOUT = 800ms



DOUBLE READ TIMEOUT = 1 SECOND

### **Laser Timeout**

The laser timeout feature sets the time for switching the visible laser diodes (VLDs) off if the scanner is idle. Using this feature can prolong the life of the VLDs.

To set the Laser Timeout:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



LASER TIMEOUT = 5 MINUTES

# **Laser Timeout — continued**



LASER TIMEOUT = 10 MINUTES



LASER TIMEOUT = 15 MINUTES

### **Motor Timeout**

The Motor Timeout feature sets the time for automatically switching the motor off when the scanner is not in use.



Laser safety requires that the laser switch off before the motor. If you set the motor timeout shorter than the laser timeout, the motor and the laser will both shut off when the motor timeout expires.

To set the Motor Timeout:

- Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



MOTOR TIMEOUT = 5 MINUTES

# **Motor Timeout — continued**



MOTOR TIMEOUT = 10 MINUTES



MOTOR TIMEOUT = 15 MINUTES

# **Motor Timeout — continued**



MOTOR TIMEOUT = 30 MINUTES



MOTOR TIMEOUT = 60 MINUTES

### **Green LED Idle State**

This feature specifies the state of the green scanner LED when the scanner is idle and ready to read a label. Options are:

- Off
- On dim

To set the LED Idle State:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



GREEN LED IDLE STATE = OFF



GREEN LED IDLE STATE = ON DIM

### **Scanner Button Options**

Configure the scanner volume button to one of the following modes of operation:

- Enable all functions: Volume, tone, diagnostics and reset.
- Enable only volume, tone and reset.
- Enable reset only.
- Disable all button functions

To set the desired Scanner Button Option:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



SCANNER BUTTON OPTION = ENABLE ALL FUNCTIONS



SCANNER BUTTON OPTION = ENABLE ONLY VOLUME/TONE/RESET

# **Scanner Button Options — continued**



SCANNER BUTTON OPTION = ENABLE RESET ONLY



SCANNER BUTTON OPTION = DISABLE ALL BUTTON FUNCTIONS

## **Power-up Beep Control**

Specifies the type of audible indication that is made when entering scanner-active mode on power-up. Choices are:

- No beep
- One beep

To set the Power-up Beep:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



POWER-UP BEEP = OFF



POWER-UP BEEP = ONE BEEP

## **Good Read Beep Control**

This feature enables/disables scanner beep upon successfully decoding of a label.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the two barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



GOOD READ BEEP = DISABLE



GOOD READ BEEP = ENABLE

## **Good Read Beep Frequency**

Adjusts the scanner's good read beep to sound at low, medium, or high frequency (controls the beeper's pitch/tone).

- Low = 660 Hz
- Medium = 860 Hz
- High = 1050 Hz

To set the Good Read Beep Frequency:

- Scan the SWITCH barcode.
- 2. Scan your selection from the three barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.




GOOD READ BEEP FREQUENCY = LOW

# **Good Read Beep Frequency — continued**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



GOOD READ BEEP FREQUENCY = MEDIUM



GOOD READ BEEP FREQUENCY = HIGH

## **Good Read Beep Length**

Specifies the duration of a good read beep.

To set the good read beep length:

- Scan the SWITCH barcode.
- 2. Scan the barcode, SET GOOD READ BEEP LENGTH. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired good read beep length setting. The selectable range is 1-255, which is the timeout in 10-millisecond increments. Pad all single and double digit numbers with leading zeroes to yield a three-digit entry (001-255). Examples:

001 = 10 ms

005 = 50 ms

040 = 400 ms

250 = 2,500 ms (2.5 seconds)

4. The scanner will automatically exit Programming Mode when the appropriate amount of digits have been scanned



SET GOOD READ BEEP LENGTH

## **Good Read Beep Volume**

Selects the beeper volume upon a good read beep. There are four selectable volumes, with each volume increment adding approximately five decibels to the previous level:

- 0 = Lowest Volume
- 1 = Low Volume
- 2 = Medium Volume
- 3 = High Volume


To set the Good Read Beep Volume:

- 1. Scan the SWITCH barcode.
- Scan your selected volume barcode from this or the following pages. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



GOOD READ BEEP VOLUME = LOWEST

# **Good Read Beep Volume — continued**



GOOD READ BEEP VOLUME = LOW



GOOD READ BEEP VOLUME = MEDIUM

# **Good Read Beep Volume — continued**



GOOD READ BEEP VOLUME = HIGH

#### **Good Read When to Indicate**

This feature specifies when the scanner will provide indication (beep and/ or flash its green LED) upon successfully reading a barcode.

Good Read = Indicate after decode



For scanner models having intelligent integrated EAS, label transmission (and hence the good read beep) is completed after the EAS logic executes.

- Good Read = Indicate after transmit
- Good Read = Indicate after CTS goes inactive, then active



The "Indicate after CTS goes inactive..." mode applies to RS-232 STD and RS-232 WN interfaces only. If set to this mode in other interfaces, "Indicate after decode" mode will be implemented.

Good Read = Indicate after each output structure proofed



NOTE

When beeping after each output structure decoded, if there are multiple output structures, there is a delay after the beep has finished. This delay is equal to the Good Read Beep Length.

To set the Good Read When to Indicate feature:

- Scan the SWITCH barcode.
- 2. Scan the desired mode barcode from the following pages. You'll need to cover any unused barcodes on facing pages to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.

# Good Read When to Indicate - continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



GOOD READ = INDICATE AFTER DECODE



GOOD READ = INDICATE AFTER TRANSMIT

# Good Read When to Indicate - continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



GOOD READ = INDICATE AFTER CTS GOES INACTIVE, THEN ACTIVE (RS-232 ONLY)



GOOD READ = INDICATE AFTER EACH OUTPUT STRUCTURE PROOFED

### **Scale Enable**

Use this feature to enable or disable scale operation.



**NOTE** 

Recalibration/recertification may be required when adding scale functionality. Consult your local Weights and Measures authority.

If this feature is enabled the scanner will expect that it is to function as a scanner-scale, and will indicate an error if it is not a scale-equipped unit. See *Error Codes* in Section 4 for more information.

#### To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the two barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



SCALE = DISABLE



SCALE = ENABLE

#### **Scale Enforced Zero Return**

This feature enables/disables the enforced zero return of the scale. Three settings are available for this feature:

- Disable
- Scale Must Return to Zero Weight Within Four Minutes Scale will require re-zeroing if a non-zero weight is left on for more than 4 minutes
- Scale Must Return to Zero Weight Between Weight Requests —
  Re-zeroing required if weight doesn't return to zero between
  weight requests from the POS, plus scale will require re-zeroing if
  a non-zero weight is left on for more than 4 minutes.

#### To set this feature:

- Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan. The strategy is to select the lowest possible filter level needed that allows normal scale operation.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



SCALE ENFORCED ZERO RETURN = DISABLE

# Scale Enforced Zero Return — continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



SCALE ENFORCED ZERO RETURN = SCALE MUST RETURN TO ZERO WEIGHT WITHIN 4 MINUTES



SCALE ENFORCED ZERO RETURN = SCALE MUST RETURN TO ZERO WEIGHT BETWEEN WEIGHT REQUESTS

## **Scale Interface Type**

Use this feature to select the scale interface type for RS-232 Standard and RS-232 Wincor/Nixdorf POS interfaces. Choices are:

- No Scale Interface
- RS-232 SASI
- RS-232 ICL

To set the Scale Interface Type:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



SCALE INTERFACE TYPE = NO SCALE INTERFACE



SCALE INTERFACE TYPE = RS-232 — SASI

# Scale Interface Type — continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



SCALE INTERFACE TYPE = RS-232 — ICL

## **Remote Display — Enable/Disable**

The scanner-scale can be configured to operate with or without a Remote Display.



Recalibration/recertification may be required when adding a Remote Display. Consult your local Weights and Measures authority.

NOTE

If this feature is enabled the scanner-scale will expect that it is connected to a Remote Display, and will indicate an error if one is not. See *Error Codes* in Section 4 for more information.



REMOTE DISPLAY = DISABLE



REMOTE DISPLAY = ENABLE

### **Aux Port Mode**

Selects the usage for the scanner's optional auxiliary port. The choices listed below are mutually exclusive (only one option can be active at a time).

- Disabled Port is inactive
- External Handheld Input Supports Datalogic<sup>™</sup> handheld scanners (QuickScan 1000, QuickScan 6000, PowerScan) as well as other models such as the Symbol<sup>®</sup> HotShot. Call your dealer for more information about supported devices.



Cable pinout information for the Aux Port is provided in Appendix B of this manual. A connected handheld scanner must be configured to transmit data as outlined in Appendix F.

PIR/CT — PIR (Productivity Index Reporting) allows the scanner to provide information to an external computer indicating how easy the label was to read. CT (Cashier Training) allows the scanner to provide feedback to the cashier on how to scan in a more ergonomic fashion.

#### To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



AUX PORT MODE = DISABLE

# **Aux Port Mode — continued**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



AUX PORT MODE = EXTERNAL HANDHELD INPUT



AUX PORT MODE = PIR/CT

### **Laser Failure Mode**

This configuration item selects whether the scanner should continue operating if only one laser is functional. (The scanner has two lasers: One for the horizontal window, and one for the vertical window.) Options for this feature are:

- Single Laser Failure OK The scanner can still operate even if
  one laser is no longer functional. In this mode the scanner will
  read only from the window associated with the operational laser.
  This provides the user the ability to continue working until the
  unit is serviced. The 7-segment display will show the error code
  for the failed laser (reference *Error Codes* in Section 4), but the
  scanner will continue to function.
- Single Laser Failure Fatal If it is desirable to have maximum
  performance or nothing at all, Laser Failure Mode should be
  selected as fatal. Upon single laser failure, the scanner will sound
  an error tone and cease scanning functions until serviced.

#### To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



LASER FAILURE MODE = SINGLE LASER FAILURE OK



LASER FAILURE MODE = SINGLE LASER FAILURE FATAL

## **Productivity Index Reporting (PIR)/Cashier Training (CT)**

When PIR/CT is enabled, label quality data is appended to decoded data before being presented to the POS. The PIR feature allows the scanner to provide information to an external computer indicating how easy the label was to read. CT allows the scanner to provide feedback to the cashier on how to scan in a more ergonomic fashion.

#### To set this feature:

- 1. Scan the SWITCH barcode.
- Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



PIR/CT = DISABLE



PIR/CT = ENABLE

### **EAS Features — Sensormatic**



**NOTE** 

These features control the Sensormatic® AMB-9010 EAS controller box. This orderable option is installed at the time of manufacture. See EAS Features — Checkpoint on page 54 to set options for the Checkpoint® EAS system.

#### **EAS Mode**

This controls the mode of operation for interfacing with the Sensor-matic<sup>®</sup> AMB-9010 EAS controller box. Choices are:

- Disabled = EAS deactivation turned off.
- Coupled Mode = EAS tag is deactivated only upon successful scanning of an item's barcode or via manual push button.
- Decoupled Mode = EAS deactivation is performed independently of barcode scanning.
- Hybrid Mode = EAS system is armed whenever the scanner is enabled and the deactivation beep is sounded when an EAS tag is deactivated.
- Host Mode = Fundamental controls and notification of various EAS events are provided to the POS system.



NOTE

Deactivation can only be initiated manually if the manual EAS deactivation push button is armed to do so. Reference the feature, Manual EAS Deactivation Push Button for more information.

#### To set this feature:

- Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.

# **EAS Mode** — continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



EAS MODE = DISABLE



EAS MODE = COUPLED MODE

# **EAS Mode** — continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



EAS MODE = DECOUPLED MODE



EAS MODE = HYBRID MODE

# **EAS Mode** — continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



EAS MODE = HOST MODE

## **EAS Beep Duration**

Sets the duration of the EAS successful deactivation beep, specified in 10ms increments. The beep only occurs if EAS mode is not disabled.

To set the EAS Beep Duration:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET EAS BEEP DURATION below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired EAS Beep Duration. The selectable range is 0-255, which is the timeout in 10-millisecond increments. Pad all single and double digit numbers with leading zeroes to yield a three-digit entry (000-255).

Examples:

000 = EAS beep disabled

001 = 10 ms

005 = 50 ms

040 = 400 ms

250 = 2,500 ms (2.5 seconds)

4. Complete the programming sequence by scanning the SWITCH barcode.



SET EAS BEEP DURATION

## **EAS Retry Count**

This feature sets the number of times the deactivation sequence (defined by the feature, "EAS Deactivation Duration — Retry") is restarted after a failed deactivation attempt.

To set the EAS Retry Count:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET EAS RETRY COUNT* below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired number. The selectable range is 0-15 resets. Pad all single and double digit numbers with leading zeroes to yield a two-digit entry (00-15).



A setting of zero specifies no deactivation retries upon failed deactivation attempt.

NOTE

4. Complete the programming sequence by scanning the SWITCH barcode.



SET EAS RETRY COUNT

#### **Manual EAS Deactivation Push Button**

This feature is for use in Coupled Mode<sup>1</sup>. When it is enabled, EAS deactivation can be manually initiated by placing the item with the EAS tag downstream<sup>2</sup> of the horizontal scan window and pushing the Manual EAS Deactivation Push Button.



The scanner emits a clicking sound while in deactivation state.

Duration of deactivation state is determined by the feature, EAS Deactivation Duration — Manual.

NOTE

#### Options are:

- DISABLE Manual EAS Deactivation Push Button disabled.
- ENABLE ALWAYS —The Manual EAS Deactivation Push Button is always enabled.
- ENABLE ONLY WHEN SCANNER ENABLED The Manual EAS Deactivation Push Button is only available when the scanner is enabled and running.



NOTE

Statistics are collected each time the Manual EAS Deactivation Push Button is used to deactivate an EAS tag.

<sup>1.</sup> See "EAS Mode" on page 42. for more information about Coupled Mode.

<sup>&</sup>quot;Downstream" in this case is defined as being the downstream side of the scan window from the direction of product flow, or scanning direction.

## Manual EAS Deactivation Push Button — continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



MANUAL EAS DEACTIVATON PUSH BUTTON = DISABLE



MANUAL EAS DEACTIVATON PUSH BUTTON = ENABLE ALWAYS

# Manual EAS Deactivation Push Button — continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



MANUAL EAS DEACTIVATON PUSH BUTTON = ENABLE ONLY WHEN SCANNER ENABLED

## **EAS Deactivation Duration — Coupled**

Specifies the amount of time EAS deactivation is operative once the function has been initiated following a barcode read.



NOTE

This setting pertains only to units configured for EAS Coupled Mode. Reference the EAS Mode description for more information about Coupled and Decoupled EAS operation.

To set the EAS Deactivation Duration — Coupled:

- Scan the SWITCH barcode.
- Scan the barcode, SET EAS DEACTIVATION DURATION COUPLED below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired duration. The selectable range is 1-255, which is the duration in 10-millisecond increments. Pad all single and double digit numbers with leading zeroes to yield a three-digit entry (001-255).

Examples:

005 = 50 ms

040 = 400 ms

250 = 2,500 ms (2.5 seconds)

4. The scanner will automatically exit Programming Mode when the appropriate amount of digits have been scanned.



SET EAS DEACTIVATION DURATION — COUPLED

## **EAS Deactivation Duration — Retry**

Specifies the amount of time EAS deactivation is operative once the function has been initiated following EAS tag detection (prior to barcode read)..



NOTE

This setting pertains only to units configured for EAS Coupled Mode. Reference the "EAS Mode" description for more information about Coupled and Decoupled EAS operation. Also reference "EAS Retry Count."

To set the EAS Deactivation Duration — Retry:

- 1. Scan the SWITCH barcode.
- Scan the barcode, SET EAS DEACTIVATION DURATION RETRY below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired duration. The selectable range is 1-255, which is the duration in 10-millisecond increments. Pad all single and double digit numbers with leading zeroes to yield a 3-digit entry (001-255). Examples:

005 = 50 ms

040 = 400 ms

250 = 2,500 ms (2.5 seconds)

The scanner will automatically exit Programming Mode when the appropriate amount of digits have been scanned



SET EAS DEACTIVATION DURATION — RETRY

#### **EAS Deactivation Duration — Manual**

Specifies the amount of time EAS deactivation is operative upon pushing the Manual EAS Deactivation Push Button.



NOTE

This setting pertains only to units configured for EAS Coupled Mode. Reference the "EAS Mode" description for more information about Coupled and Decoupled EAS operation. Also reference "EAS Retry Count."

To set the EAS Deactivation Duration — Manual:

- 1. Scan the SWITCH barcode.
- Scan the barcode, SET EAS DEACTIVATION DURATION MANUAL below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired duration. The selectable range is 1-255, which is the duration in 50-millisecond increments. Pad all single and double digit numbers with leading zeroes to yield a 3-digit entry (001-255). Examples:

001 = 50 ms

008 = 400 ms

050 = 2,500 ms (2.5 seconds)

The scanner will automatically exit Programming Mode when the appropriate amount of digits have been scanned



SET EAS DEACTIVATION DURATION — MANUAL

# **EAS Features — Checkpoint**

The features in this section apply only to Checkpoint® EAS systems. See EAS Features — Sensormatic on page 42 to set options for that system.

#### **EAS Active State**

Specifies the active state polarity of EAS (Electronic Article Survellance); the inactive state is its opposite polarity. EAS output goes active during the good read of a barcode, allowing the EAS device to deactivate a tag on the product.

To set the EAS Active State:

- 1. Scan the SWITCH barcode.
- Scan barcode below representing the desired setting. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



EAS ACTIVE STATE = ACTIVE LOW



EAS ACTIVE STATE = ACTIVE HIGH

#### **EAS Timeout**

Specifies the amount of time that an EAS (Electronic Article Survellance) signal is held in its active state for a good read.

To set the EAS Timeout:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET EAS TIMEOUT below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired EAS Timeout duration. The selectable range is 0-255, which is the timeout in 10-millisecond increments. Pad all single and double digit numbers with leading zeroes to yield a three-digit entry (000-255).

Examples:

000 = EAS timeout disabled

001 = 10 ms

005 = 50 ms

040 = 400 ms

250 = 2,500 ms (2.5 seconds)



A setting of 0 (000) disables this feature.

4. The scanner will automatically exit Programming Mode when the appropriate amount of digits have been scanned



SET EAS TIMEOUT

## **Interface Related Features**

# **Interface Type**

Specifies the current scanner interface. Selections are:

INTERFACE (I/F) TYPE	I/F I.D. NUMBER <sup>a</sup>
RS-232 Standard	05
RS-232 Wincor-Nixdorf	12
RS-232 Single Cable	20
OEM USB	45
IBM Port 17	04
IBM Port 5B	08
IBM Port 9B	23
USB Keyboard	35
NOT USER-SELECTABLE	
Null Interface	7-segment FRU display indicates 0 at start-up (accompanied by trill beep for approx. 2 seconds)

INTERFACE (I/F) TYPE	I/F I.D. NUMBER <sup>a</sup>
Keyboard Wedge A	25
Keyboard Wedge B	26
Keyboard Wedge C	27
Keyboard Wedge D	28
Keyboard Wedge E	29
Keyboard Wedge F	2A
Keyboard Wedge G	31
Keyboard Wedge H	32
Keyboard Wedge I	33
Keyboard Wedge J	34

a. To access a scanner's interface identification number, place the scanner in Scanner Diagnostic Mode and view the 7-segment FRU display (reference Chapter 2, Diagnostic Modes, for more information).

# **Interface Type — continued**



NOTE

A new scanner may have been shipped from the factory with a Null Interface (no interface type selected) to ensure system compatibility at installation. In this case, the correct Interface Type programming barcode must be scanned first before the scanner can be used with a POS system.



If the scanner's interface type must be changed, always be sure that interface configuration is the FIRST item scanned during a programming session. (Selecting an interface type resets ALL other configuration items to the factory default for that interface type.)

To select the desired interface:



**CAUTION** 

Great care should be taken to select the correct interface type, since you can cause damage to the scanner and/or POS terminal by attempting to change to an incompatible interface. ALWAYS make interface selections with the host cable DISCONNECTED.



NOTE

When an interface is selected, the scanner loads the factory configuration for that interface as the selection is made, erasing any and all custom configuration that may have previously been done.

- 1. Disconnect current interface cable(s) if currently connected.
- 2. Scan the SWITCH barcode
- Scan the barcode representing the appropriate interface located on the following pages. You'll need to cover any unused barcodes adjacent to and on any facing pages to ensure the scanner reads only the barcode you intend to scan.

# **Interface Type — continued**

4. Complete the programming sequence by scanning the SWITCH barcode.



**NOTE** 

Once the correct interface has been set, it will be necessary to proceed to the appropriate pages in this manual that select parameters and options for that interface. For example, if RS-232 is selected, turn to the pages in this manual headed as features specific to the RS-232 interface.

5. Connect new interface cable(s).

#### **RS-232 Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





#### **RS-232 Wincor-Nixdorf Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





#### **RS-232 Single Cable Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



**CAUTION** 

Great care should be taken to select the correct interface type, since you can cause damage to the scanner and/or POS terminal by attempting to change to an incompatible interface. ALWAYS make interface selections with the host cable DISCONNECTED.



NOTE

Single cable installations require connection at the POS Terminal (host) port. The Scale Host port connection is not used for this interface.



#### **OEM USB Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



**CAUTION** 

Great care should be taken to select the correct interface type, since you can cause damage to the scanner and/or POS terminal by attempting to change to an incompatible interface. ALWAYS make interface selections with the host cable DISCONNECTED.



NOTE

Single cable installations require connection at the POS Terminal (host) port. The Scale Host port connection is not used for this interface.



#### **IBM Port 17 Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



**CAUTION** 

Great care should be taken to select the correct interface type, since you can cause damage to the scanner and/or POS terminal by attempting to change to an incompatible interface. ALWAYS make interface selections with the host cable DISCONNECTED.



NOTE

Single cable installations require connection at the POS Terminal (host) port. The Scale Host port connection is not used for this interface.



#### **IBM Port 5B Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





#### **IBM Port 9B Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





## **USB Keyboard Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





#### **Keyboard Wedge A Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





#### **Keyboard Wedge B Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





#### **Keyboard Wedge C Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





#### **Keyboard Wedge D Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





#### **Keyboard Wedge E Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





#### **Keyboard Wedge F Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





#### **Keyboard Wedge G Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





#### **Keyboard Wedge H Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





## **Keyboard Wedge I Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





#### **Keyboard Wedge J Interface Selection**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.





## **Maximum Host-Transmitted Message Length**

Specifies the maximum number of data characters allowed in messages transmitted to the host.

To set the Maximum Host-Transmitted Message Length:

- 1. Scan the SWITCH barcode.
- Scan the barcode, SET MAXIMUM HOST-TRANSMITTED
  MESSAGE LENGTH below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads
  only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired maximum host-transmitted message length. The selectable range is 0-249 data characters. (Labels that are longer than this length are not read.) Pad all single and double digit numbers with leading zeroes to yield a three-digit entry (000-249).



If this configuration item is set to 0 (000), there is no general length limit imposed on data being transmitted to the host.

4. The scanner will automatically exit Programming Mode when the appropriate amount of digits have been scanned



SET MAXIMUM HOST-TRANSMITTED MESSAGE LENGTH

#### **Number of Host Transmission Buffers**

Specifies the number of host transmission(s) that may be buffered. By buffering data from a barcode, the scanner can continue to read a new barcode while the old one is being transmitted to the host. Selecting BUF-FERS = 1 means that the first barcode must be transmitted before a new one can be read. A selection of BUFFERS = 2 means that a new barcode can be read while data from the first barcode is transmitted. When the feature, *Good Read Beep Control*, is enabled, the scanner will beep when the data is placed in a transmission buffer.

When a DISABLE SCANNER command is received from the host, the scanner will continue to transmit all data that is buffered.

To select the Number of Host Transmission Buffers:

- 1. Scan the SWITCH barcode.
- 2. Scan barcode below representing the desired setting. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



NUMBER OF HOST TRANSMISSION BUFFERS = 1



NUMBER OF HOST TRANSMISSION BUFFERS = 2

#### **Global Prefix**

This feature applies to RS-232 interfaces (Standard, Wincor-Nixdorf, and Single Cable). It specifies the prefix that is added to beginning of label transmission.

To specify the Global Prefix Character(s):

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET GLOBAL PREFIX* below. You'll need to cover any unused barcodes to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate characters/digits from the keypad in Appendix C that represent the hex designation for the desired character(s). A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF. Up to 20 hex pairs can be designated.



To specify "no Global Prefix," scan 00.

- 4. If designating the full 20 hex pairs, the scanner will automatically exit Programming Mode when the appropriate amount of digits have been scanned. If designating less than 20 hex pairs, you can end the programming sequence early by scanning the *TERMI-NATE SEQUENCE* barcode.
- 5. Complete the programming sequence by scanning the SWITCH barcode.

# **Global Prefix — continued**



**SET GLOBAL PREFIX** 



TERMINATE SEQUENCE

### **Global Suffix**

This feature applies to RS-232 interfaces (Standard, Wincor-Nixdorf, and Single Cable). It specifies the suffix that is added to end of a label transmission. Three standard options are available below. Contact your dealer for other alternate settings for this feature.

- No Global Suffix
- CR Carriage Return
- CR LF Carriage Return, Line Feed

To set the Global Suffix:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



GLOBAL SUFFIX = NO GLOBAL SUFFIX

# **Global Suffix — continued**



GLOBAL SUFFIX = CR



GLOBAL SUFFIX = CR LF

### **IBM Features**

## **IBM Interface Options**

IBM interfaces offer specific control over interaction with certain devices.



The OEM USB interface provides its own set of options. Refer to the feature, OEM USB Interface Options, in this section.

Options for this feature are as follows:

- FULL host interface support Accepts scanner and scale configuration host commands.
- Ignore host interface configuration of scanner and scale Ignores all scanner and scale configuration host commands.

#### To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



IBM INTERFACE OPTION = FULL HOST INTERFACE SUPPORT



IBM INTERFACE OPTION = IGNORE HOST I/F CONFIG OF SCANNER & SCALE

### **IBM Scale Address**



This feature applies to IBM Port 17 ONLY.

**NOTE** 

Specifies IBM scale address for IBM Port 17. The following three addresses are available:

- 6A
- 6B
- 6E

To set the IBM Scale Address:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode below or from the following page that represents the desired scale address designation.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



IBM SCALE ADDRESS = 6A

# IBM Scale Address — continued



IBM SCALE ADDRESS = 6B



IBM SCALE ADDRESS = 6E

#### **IBM Transmit Labels in Code 39 Format**

This feature enables/disables scanner's ability to set a symbology identifier for a specified label to Code 39 before transmitting that label data to an IBM host. This applies to: Code 128, Code 93 and Codabar for IBM Port 5B; Code 93 and Codabar for IBM Port 9B; Code 128, Code 93 and Codabar for OEM-USB.



When enabled, this feature has no effect on IBM Port 17.

**NOTE** 

To enable/disable the IBM Transmit Labels in Code 39 Format feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



IBM TRANSMIT LABELS IN CODE 39 FORMAT = DISABLE



IBM TRANSMIT LABELS IN CODE 39 FORMAT = ENABLE

## **OEM USB Interface Options**

The OEM-USB interface offers specific control over interaction with certain devices. Options for this feature are as follows:

- FULL host interface support Accepts scanner and scale configuration host commands.
- Compatible with Magellan SL host interface support Uses Magellan SL host interface support.
- Ignore host interface configuration of scanner and scale Ignores all scanner and scale configuration host commands.



This feature applies only to the OEM USB interface. For other IBM interfaces, refer to the feature, IBM Interface Options, earlier in this section.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



OEM USB INTERFACE OPTION = FULL HOST INTERFACE SUPPORT

# **OEM USB Interface Options — continued**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



OEM USB INTERFACE OPTION = COMPATIBLE W/MAGELLAN SL HOST I/F SUP-PORT



OEM USB INTERFACE OPTION = IGNORE HOST I/F CONFIG OF SCANNER & SCALE

### **OEM USB Scanner Device Type**

The OEM-USB protocol allows for the scanner to be identified as one of two different types of barcode scanners. Depending on what other scanners you may already have connected to a USB POS, you may need to change this setting to enable all scanners to communicate. Options are:

- Table Top Scanner
- Handheld Scanner

#### To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



OEM USB SCANNER DEVICE TYPE = TABLE TOP SCANNER



OEM USB SCANNER DEVICE TYPE = HANDHELD SCANNER

## **RS-232 Features**

#### **RS-232 Baud Rate**

This feature selects the baud rate required for sending and receiving data.



Single cable interfaces are limited to Baud Rate selections up to 19200. They cannot communicate at Baud Rates of 38400 and up.

To specify the RS-232 Baud Rate:

- 1. Scan the SWITCH barcode.
- 2. Scan the desired baud rate from the barcodes below and on the immediately following pages. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



RS-232 BAUD RATE = 1200



RS-232 BAUD RATE = 2400

# RS-232 Baud Rate — continued



RS-232 BAUD RATE = 4800



RS-232 BAUD RATE = 9600

## RS-232 Baud Rate — continued



RS-232 BAUD RATE = 19200



RS-232 BAUD RATE = 38400

# RS-232 Baud Rate — continued



RS-232 BAUD RATE = 57600



RS-232 BAUD RATE = 115200

### **RS-232 Number of Data Bits**

Specifies number of data bits required for sending and receiving data.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode below representing the desired Data Bit setting. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



RS-232 NUMBER OF DATA BITS = 7



RS-232 NUMBER OF DATA BITS = 8

## **RS-232 Number of Stop Bits**

Specifies number of stop bits required for sending and receiving data.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode below representing the desired Stop Bit setting. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



RS-232 NUMBER OF STOP BITS = 1



RS-232 NUMBER OF STOP BITS = 2

## **RS-232 Parity**

Specifies parity required for sending and receiving data.

Options for this setting are:

- RS-232 PARITY = NONE
- RS-232 PARITY = EVEN
- RS-232 PARITY = ODD

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode below or on the following pages representing the desired Parity setting. You'll need to cover any unused barcodes, as well as facing pages to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



**RS-232 PARITY = NONE** 

# **RS-232 Parity** — continued



RS-232 PARITY = EVEN



RS-232 PARITY = ODD

#### **RS-232 Hardware Control**

Enables/disables use of the RS-232 CTS signal for flow control and/or scan control.

#### Options are:

- Disable The scanner transmits to the host regardless of any activity on the CTS line.
- Enable CTS Flow Control The CTS signal controls transmission of data to the host.
- Enable CTS Scan Control The CTS line must be active for scanner to read and transmit data. While the CTS line is inactive, scanner remains in a host- disabled state; following a successful label transmission, the CTS signal must transition to inactive and then to active to enable scanning for the next label.

- 1. Scan the SWITCH barcode.
- 2. Scan barcode below or from the following page for the desired setting. You'll need to cover any unused barcodes on facing pages to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



RS-232 HARDWARE CONTROL = DISABLE

## **RS-232 Hardware Control — continued**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



RS-232 HARDWARE CONTROL = ENABLE CTS FLOW CONTROL



RS-232 HARDWARE CONTROL = ENABLE CTS SCAN CONTROL

## **RS-232 Intercharacter Delay**

Specifies delay between the end of one character and the beginning of the next in 10-millisecond increments.

To set the RS-232 Intercharacter Delay:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode below, *SET RS-232 INTERCHARACTER DELAY*. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired delay. The selectable range is 0-100, which is the delay in 10-millisecond increments. Pad all single and double digit numbers with leading zeroes to yield a three-digit entry (000-100).

Examples:

001 = 10 ms

005 = 50 ms

040 = 400 ms

100 = 1,000 ms (1 second)

4. The scanner will automatically exit Programming Mode when the appropriate amount of digits have been scanned.



SET RS-232 INTERCHARACTER DELAY

### **RS-232 Software Flow Control**

Enables/disables RS-232 Flow Control using XON/ XOFF characters. .



This item will be ignored when the feature, *RS-232 NAK Character*, is enabled

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



RS-232 SOFTWARE FLOW CONTROL = DISABLE



RS-232 SOFTWARE FLOW CONTROL = ENABLE

#### **RS-232 Host Echo**

When enabled, this feature passes all data through the scanner to the host as it comes in. This feature is used for applications where "daisy chaining" of RS-232 devices onto the same cable is necessary. If, for example, one of the devices in the chain is a terminal where someone is entering data while another person is simultaneously scanning a barcode requiring transmission to the host, the scanner will wait for the RS-232 channel to be quiet for a specified period of time (set via *RS-232 Host Echo Quiet Interval*). The scanner can be set to observe this delay before sending its data in order to avoid RS-232 transmission conflicts.



When RS-232 Host Echo is enabled, the following features are ignored: *RS-232 Software Flow Control* and *RS-232 ACK NAK Enable* as well as all other ACK/ NAK related operations, plus processing of RS-232 host commands.

To enable/disable this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



RS-232 HOST ECHO = DISABLE



RS-232 HOST ECHO = ENABLE

### **RS-232 Host Echo Quiet Interval**

This setting specifies the time interval of RS-232 channel inactivity which must transpire before the scanner will break the host echo loop to transmit the barcode data that has just been scanned to the host.

• 0 - 100 = Time in 10-millisecond increments.

To set the Host Echo Quiet Interval:

- Scan the SWITCH barcode.
- 2. Scan the barcode below, *SET RS-232 HOST ECHO QUIET INTERVAL*. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired timeout. The selectable range is 0-100, which is the timeout in 10-millisecond increments. Pad all single and double digit numbers with leading zeroes to yield a three-digit entry (000-100).

Examples: 001 = 10ms

005 = 50 ms

040 = 400 ms

100 = 1,000 ms (1 second)

4. The scanner will automatically exit Programming Mode when the appropriate amount of digits have been scanned.



SET RS-232 HOST ECHO QUIET INTERVAL

## **RS-232 Ignore Host Commands**

When set to ignore host commands, the scanner will ignore all host commands except for the minimum set necessary to keep the interface active, transmit labels, and transmit scale information. For normal operation of the interface, disable this feature.

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



RS-232 IGNORE HOST COMMANDS = DISABLE



RS-232 IGNORE HOST COMMANDS = ENABLE

#### RS-232 TTL

Specifies whether RS-232 interface provides TTL levels on the output pins TxD and RTS.

#### Choices are:

- Normal RS-232 levels
- TTL levels

- 1. Scan the SWITCH barcode.
- Scan the barcode below which represents the desired setting for this feature. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



RS-232 LEVELS = NORMAL RS-232



RS-232 LEVELS = TTL

### **RS-232 TTL Invert**

Enables/disables inversion of TTL.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode below which represents the desired setting for this feature. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



RS-232 TTL INVERT = DISABLE



RS-232 TTL INVERT = ENABLE

### **RS-232 Beep on ASCII BEL**

Enables/disables ability of scanner to beep (sound a good read tone) on receiving an ASCII BEL (07 hex).

- Disable
- Enable

To enable/disable this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



RS-232 BEEP ON ASCII BEL = DISABLE



RS-232 BEEP ON ASCII BEL = ENABLE

## **RS-232 Beep After Weigh**

Enables/disables the ability of the scanner to beep after weight data is transmitted to the host. Scale interfaces that support this item are: RS-232 ICL, RS-232 SASI, and RS-232 Single Cable.

To enable/disable the Beep After Weigh feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



BEEP AFTER WEIGH = DISABLE



BEEP AFTER WEIGH = ENABLE

## **RS-232 Beep on Not on File**

Select for the host to beep (or not) when a not-on-file condition is detected by the host. This feature is also applicable to single cable RS-232.



RS-232 BEEP ON NOT ON FILE = DISABLE



**ENABLE** 

#### **RS-232 ACK NAK Enable**

This enables/disables the ability of the scanner to support the RS-232 ACK/NAK protocol. When configured, the scanner and/or host sends an "ACK" when it receives data properly, and sends "NAK" when the data is in error. Selections for this option are:

- Disable
- Label Transmission the scanner expects an ACK/NAK response from the host when a label is sent)
- Host Acknowledgement Enabled for Host Commands (the scanner will respond with ACK/NAK when the host sends a command)
- Label & Host Enabled for both Label Transmission & Host Commands

To select the option for RS-232 ACK NAK Enable:

- 1. Scan the SWITCH barcode.
- 2. Scan the desired option from barcodes below and on the following page. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



RS-232 ACK NAK = DISABLE



RS-232 ACK/NAK = LABEL TRANSMISSION

# RS-232 ACK NAK Enable — continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



RS-232 ACK/NAK = HOST ACKNOWLEDGEMENT



RS-232 ACK/NAK = LABEL & HOST

### **RS-232 ACK Character**

This feature specifies which ASCII character will be used as an ACK character.



DO NOT set this feature to use previously defined characters such as XON, XOFF or host commands as this will conflict with normal operation of these characters. 8-bit data is not recognized when the feature, *RS-232 Number of Data Bits*, is set to 7 data bits.

To specify the RS-232 ACK Character:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET RS-232 ACK Character* below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the hex designation for the desired character. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for the desired character. For example, if ASCII "A" were the desired ACK character, you would scan the digits "4", then "1" (the ASCII corresponding hex value).
- 4. The scanner will automatically exit Programming Mode when the appropriate amount of digits/characters have been scanned.



SET RS-232 ACK Character

#### **RS-232 NAK Character**

This feature specifies which ASCII character will be used as a NAK character.



DO NOT set this feature to use previously defined characters such as XON, XOFF or host commands as this will conflict with normal operation of these characters. 8-bit data is not recognized when the feature, *RS-232 Number of Data Bits*, is set to 7 data bits.

To specify the RS-232 NAK Character:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET RS-232 NAK Character below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the hex designation for the desired character. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for the desired character. For example, if ASCII "A" were the desired NAK character, you would scan the digits "4", then "1" (the ASCII corresponding hex value).
- 4. The scanner will automatically exit Programming Mode when the appropriate amount of digits/characters have been scanned.



SET RS-232 NAK Character

## **RS-232 Retry on ACK NAK Timeout**

This option specifies the action scanner performs on expiration of the RS-232 ACK NAK Timeout Value.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



RS-232 RETRY ON ACK NAK TIMEOUT = DISABLE



RS-232 RETRY ON ACK NAK TIMEOUT = ENABLE

#### RS-232 ACK NAK Timeout Value

This item specifies the time the scanner will wait for an ACK character from the host following a label transmission.

- 0 = Infinite timeout
- 1 75 = Timeout in 200-millisecond increments

To set the ACK NAK Timeout Value:

- 1. Scan the SWITCH barcode.
- Scan the barcode below, SET RS-232 ACK NAK TIMEOUT VALUE.
   You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired timeout. A setting of 0 specifies an infinite timeout. The remaining selectable range is 1-75, which is the timeout in 200-millisecond increments. Pad all single digit numbers with a leading zero to yield a two-digit entry (00-75). Examples:

00 = Infinite timeout

01 = 200 ms

05 = 1,000 ms (1 second)

40 = 8,000 ms (8 seconds)

75 = 15,000 ms (15 seconds)

4. The scanner will automatically exit Programming Mode when the appropriate amount of digits have been scanned.



SET RS-232 ACK NAK TIMEOUT VALUE

# **RS-232 ACK NAK Retry Count**

This feature sets the number of times for the scanner to retry a label transmission under a retry condition.

To set the RS-232 ACK NAK Retry Count:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET RS-232 ACK NAK RETRY COUNT* below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired number. The selectable range is 0-255 resets. Pad all single and double digit numbers with leading zeroes to yield a three-digit entry (000-255).



A setting of 255 specifies "retry forever."

4. The scanner will automatically exit Programming Mode when the appropriate amount of digits have been scanned.



SET RS-232 ACK NAK RETRY COUNT

### **RS-232 ACK NAK Error Handling**

This item specifies the method the scanner will use to handle errors detected while waiting to receive the ACK character from the host. Errors include unrecognized host commands and communication errors such as parity or framing errors.

- Ignore Errors (recommended setting)
- Assume ACK (risk of lost label data)
- Assume NAK (risk of duplicate label)

To select the option for RS-232 ACK NAK Error Handling:

- 1. Scan the SWITCH barcode.
- 2. Scan the desired option from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



RS-232 ACK NAK ERROR HANDLING = IGNORE ERRORS

# RS-232 ACK NAK Error Handling — continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



RS-232 ACK NAK ERROR HANDLING = ASSUME ACK



RS-232 ACK NAK ERROR HANDLING = ASSUME NAK

### **RS-232 Label ID Control**

This feature specifies whether or not Label IDs are transmitted to the host and if so, whether to attach them as a prefix or suffix.



RS-232 LABEL ID CONTROL = DISABLE



RS-232 LABEL ID CONTROL = ENABLE AS PREFIX

# **RS-232 Label ID Control** — continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



RS-232 LABEL ID CONTROL = ENABLE AS SUFFIX

# **Single Cable RS-232 Options**

The RS-232 Single Cable interface shares some configuration options with other RS-232 interfaces. Rather than repeat them in this section as Single Cable options, please find them referenced as follows:

- RS-232 Baud Rate on page 90
- RS-232 Number of Data Bits on page 94
- RS-232 Number of Stop Bits on page 95
- RS-232 Parity on page 96
- RS-232 Software Flow Control on page 101
- RS-232 Beep After Weigh on page 108
- RS-232 Beep on Not on File on page 109
- RS-232 Label ID Control on page 119

# **Single Cable RS-232 Scanner Only Protocol**

This sets the type of interface protocol that will be used in Single Cable RS-232.

### Options are:

- Scanner/scale RS-232 protocol
- Scanner only RS-232 protocol

#### To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode below representing the desired option. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



SINGLE CABLE RS-232 PROTOCOL = SCANNER/SCALE



SINGLE CABLE RS-232 PROTOCOL = SCANNER ONLY

### Single Cable RS-232 RTS CTS Selection

Specifies how RTS and CTS are used to control the data flow. RTS is controlled by the Scanner and can be continuously held high/low, or can be asserted during label transmission. The scanner looks at CTS, as the configuration values state, to determine when to send label data.

#### Choices are:

- Option 0 = RTS is held in low state and CTS is ignored
- Option 1 = RTS is held in high state and CTS is ignored
- Option 2 = Assert RTS and wait for CTS to be asserted
- Option 3 = Assert RTS and ignore CTS
- Option 4 = RTS held low, wait for CTS to be asserted
- Option 5 = RTS held high, wait for CTS to be asserted

- Scan the SWITCH barcode.
- Scan a barcode below or on the following pages representing the desired option. You'll need to cover any unused barcodes, as well as facing pages to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



RTS CTS SELECTION = OPTION 0



RTS CTS SELECTION = OPTION 1

# Single Cable RS-232 RTS CTS Selection — continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



RTS CTS SELECTION = OPTION 2



RTS CTS SELECTION = OPTION 3

# Single Cable RS-232 RTS CTS Selection — continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



RTS CTS SELECTION = OPTION 4



RTS CTS SELECTION = OPTION 5

### Single Cable RS-232 Use BCC

Enables/disables the ability of the scanner to use BCC.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



SINGLE CABLE RS-232 USE BCC = DISABLE



SINGLE CABLE RS-232 USE BCC = ENABLE

### Single Cable RS-232 Use ACK/NAK

Enables/disables the ability of the scanner to use ACK/NAK.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



SINGLE CABLE RS-232 USE ACK/NAK = DISABLE



SINGLE CABLE RS-232 USE ACK/NAK = ENABLE

### **Single Cable RS-232 Use STX**

Enables/disables the ability of the scanner to use STX.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



SINGLE CABLE RS-232 USE STX = DISABLE



SINGLE CABLE RS-232 USE STX = ENABLE

### **Set Single Cable RS-232 STX Character**

This feature selects the STX character.

To specify the STX Character:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET SINGLE CABLE RS-232 STX CHARAC-TER below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate characters/digits from the keypad in Appendix C that represent the decimal designation for the desired character. A table containing the *ASCII Character Set* and their corresponding decimal values is available in the inside back cover of this manual. ASCII parameters must be input by scanning decimal digits for each character. Pad all numbers with leading zeroes to yield a three-digit entry (001-127). Thus, to set a single character value of A, barcodes containing the digits '0', '6' and '5' must be scanned. The selectable range for this option is any decimal value from 001 to 127.
- 4. The scanner will automatically exit Programming Mode when the appropriate amount of digits have been scanned.



SET SINGLE CABLE RS-232 STX CHARACTER

### **Single Cable RS-232 Use ETX**


Enables/disables the ability of the scanner to use ETX.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



SINGLE CABLE RS-232 USE ETX = DISABLE



SINGLE CABLE RS-232 USE ETX = ENABLE

### **Set Single Cable RS-232 ETX Character**

Allows selection of the ETX character.

To specify the ETX Character:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET SINGLE CABLE RS-232 ETX CHARAC-TER below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate characters/digits from the keypad in Appendix C that represent the decimal designation for the desired character. A table containing the *ASCII Character Set* and their corresponding decimal values is available in the inside back cover of this manual. ASCII parameters must be input by scanning decimal digits for each character. Pad all numbers with leading zeroes to yield a three-digit entry (001-127). Thus, to set a single character value of A, barcodes containing the digits '0', '6' and '5' must be scanned. The selectable range for this option is any decimal value from 001 to 127.
- 4. The scanner will automatically exit Programming Mode when the appropriate amount of digits have been scanned.



SET SINGLE CABLE RS-232 ETX CHARACTER

### **Single Cable RS-232 Datalogic Extensions**

When Datalogic<sup>1</sup> extensions are enabled, scale calibration mode information is communicated to the host. Contact Customer Support for the format of this information. Choices for this feature are:

- Standard Protocol
- Support Datalogic Extensions to Protocol

#### To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



SINGLE CABLE RS-232 DATALOGIC EXTENSIONS = STANDARD PROTOCOL



SINGLE CABLE RS-232 DATALOGIC EXTENSIONS = SUPPORT DATALOGIC EXTENSIONS TO PROTOCOL

<sup>1.</sup> Depending upon when your scanner was purchased, this could be termed, a "PSC extension."

# Symbology Programming



If the scanner's interface type must be changed, always be sure that interface configuration is the FIRST item scanned during a programming session. (Selecting an interface type resets ALL other configuration items — including symbology programming — to the factory default for that interface type.)

# **Coupon Control**

This feature is used to control the method of processing coupon labels. For the puposes of this feature, coupon labels are defined as:

- 1. UPC-A labels that start with a '5'
- 2. GS1 DataBar Expanded labels that start with '8110'

The options for this setting are:

- **Disable** Coupon Control is turned off.
- Enable UPC-A Coupons UPC-A coupon labels will decode but GS1 DataBar Expanded coupon labels will not. GS1 DataBar Expanded labels that are not coupon labels will decode and all UPC-A labels will decode.
- Enable GS1 DataBar Expanded Coupons GS1 DataBar Expanded coupon labels will decode but UPC-A coupon labels will not.
   UPC-A labels that are not coupon labels will decode and all GS1 DataBar Expanded labels will decode.

- 1. Scan the SWITCH bar code.
- 2. Scan your choice from the Coupon Control selections below. You'll need to cover any unused bar codes on this and the facing page to ensure that the scanner reads only the bar code you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH bar code.



COUPON CONTROL = DISABLE

# **Coupon Control - continued**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.

COLIDON CONTROL FINANCE LING A CO



COUPON CONTROL = ENABLE GS1 DATABAR EXPANDED COUPONS

## **UPC-A Enable**

Enables/disables the ability of the scanner to decode UPC-A labels.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



UPC-A = DISABLE



UPC-A = ENABLE

### **UPC-A Number System Character Transmission**

Enables/disables transmission of a UPC-A number system character.



This feature MUST be enabled for IBM interfaces for proper function.

This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



UPC-A NUMBER SYSTEM CHARACTER TRANSMISSION = DISABLE



UPC-A NUMBER SYSTEM CHARACTER TRANSMISSION = ENABLE

### **UPC-A Check Character Transmission**

Enables/disables transmission of a UPC-A check character.



This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



UPC-A CHECK CHARACTER TRANSMISSION = DISABLE



UPC-A CHECK CHARACTER TRANSMISSION = ENABLE

### **Expand UPC-A to EAN-13**

Enables/disables expansion of UPC-A labels to EAN/JAN-13.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



EXPAND UPC-A TO EAN/JAN-13 = DISABLE



EXPAND UPC-A TO EAN/JAN-13 = ENABLE

### **UPC/EAN AIM ID**

This feature enables/disables transmission of the UPC/EAN AIM symbology identifier.

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



UPC/EAN AIM ID = DISABLE



UPC/EAN AIM ID = ENABLE

### **UPC-A Label ID**

This feature specifies a UPC-A label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET UPC-A LABEL ID* below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET UPC-A LABEL ID

### **UPC-A 2-Digit Supplemental Label ID**

This feature specifies a UPC-A 2-Digit Supplemental label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- Scan the barcode, SET UPC-A 2-DIGIT SUPPLEMENTAL LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET UPC-A 2-DIGIT SUPPLEMENTAL LABEL ID

### **UPC-A 5-Digit Supplemental Label ID**

This feature specifies a UPC-A 5-Digit Supplemental label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET UPC-A 5-DIGIT SUPPLEMENTAL LABEL ID* below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET UPC-A 5-DIGIT SUPPLEMENTAL LABEL ID

### **UPC-A 128 Supplemental Label ID**

This feature specifies a UPC-A 128 Supplemental label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- Scan the SWITCH barcode.
- Scan the barcode, SET UPC-A 128 SUPPLEMENTAL LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET UPC-A 128 SUPPLEMENTAL LABEL ID

## **UPC-E Enable**

Enables/disables the ability of the scanner to decode UPC-E labels.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



UPC-E = DISABLE



UPC-E = ENABLE

### **UPC-E Number System Character Transmission**

Enables/disables transmission of a UPC-E number system character.




This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



UPC-E NUMBER SYSTEM CHARACTER TRANSMISSION = DISABLE



UPC-E NUMBER SYSTEM CHARACTER TRANSMISSION = ENABLE

### **UPC-E Check Character Transmission**

Enables/disables transmission of a UPC-E check character.



This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



UPC-E CHECK CHARACTER TRANSMISSION = DISABLE



UPC-E CHECK CHARACTER TRANSMISSION = ENABLE

### **Expand UPC-E to UPC-A**

Enables/disables expansion of UPC-E labels to UPC-A.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



EXPAND UPC-E TO UPC-A = DISABLE



EXPAND UPC-E TO UPC-A = ENABLE

### **Expand UPC-E to EAN-13**

Enables/disables expansion of UPC-E labels to EAN/JAN-13.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



EXPAND UPC-E TO EAN/JAN-13 = DISABLE



EXPAND UPC-E TO EAN/JAN-13 = ENABLE

### **UPC-E Label ID**

This feature specifies a UPC-E label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET UPC-E LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET UPC-E LABEL ID

### **UPC-E 2-Digit Supplemental Label ID**

This feature specifies a UPC-E 2-Digit Supplemental label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET UPC-E 2-DIGIT SUPPLEMENTAL LABEL ID* below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET UPC-E 2-DIGIT SUPPLEMENTAL LABEL ID

## **UPC-E 5-Digit Supplemental Label ID**

This feature specifies a UPC-E 5-Digit Supplemental label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- Scan the SWITCH barcode.
- Scan the barcode, SET UPC-E 5-DIGIT SUPPLEMENTAL LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET UPC-E 5-DIGIT SUPPLEMENTAL LABEL ID

## **UPC-E 128 Supplemental Label ID**

This feature specifies a UPC-E 128 Supplemental label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET UPC-E 128 SUPPLEMENTAL LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET UPC-E 128 SUPPLEMENTAL LABEL ID

## **EAN-13 Enable**

Enables/disables the ability of the scanner to decode EAN/JAN-13 labels. To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



EAN-13 = DISABLE



EAN-13 = ENABLE

### **EAN-13 First Character Transmission**

Enables/disables transmission of EAN/JAN-13 first character.



This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



EAN-13 FIRST CHARACTER TRANSMISSION = DISABLE



EAN-13 FIRST CHARACTER TRANSMISSION = ENABLE

### **EAN-13 Check Character Transmission**

Enables/disables transmission of an EAN/JAN-13 check character.



This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



EAN-13 CHECK CHARACTER TRANSMISSION = DISABLE



EAN-13 CHECK CHARACTER TRANSMISSION = ENABLE

### **EAN-13 ISBN Conversion Enable**

Enables/disables conversion of EAN/JAN-13 labels starting with 978 to Bookland ISBN labels.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



EAN-13 ISBN Conversion= DISABLE



EAN-13 ISBN Conversion = ENABLE

#### **EAN 13 Label ID**

This feature specifies an EAN 13 label ID to be added to barcode data.

To set this feature:



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET EAN 13 LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the ASCII Character Set and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET EAN 13 LABEL ID

## **EAN-13 2-Digit Supplemental Label ID**

This feature specifies an EAN-13 2-Digit Supplemental label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- Scan the barcode, SET EAN-13 2-DIGIT SUPPLEMENTAL LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET EAN-13 2-DIGIT SUPPLEMENTAL LABEL ID

## **EAN-13 5-Digit Supplemental Label ID**

This feature specifies an EAN-13 5-Digit Supplemental label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- Scan the SWITCH barcode.
- Scan the barcode, SET EAN-13 5-DIGIT SUPPLEMENTAL LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET EAN-13 5-DIGIT SUPPLEMENTAL LABEL ID

## **EAN-13 128 Supplemental Label ID**

This feature specifies an EAN-13 128 Supplemental label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET EAN-13 128 SUPPLEMENTAL LABEL ID = DISABLE below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET EAN-13 128 SUPPLEMENTAL LABEL ID = DISABLE

### **Bookland AIM ID**

This feature enables/disables transmission of the Bookland AIM symbology identifier.

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



BOOKLAND AIM ID = DISABLE



BOOKLAND AIM ID = ENABLE

### **Bookland Label ID**

This feature specifies a Bookland label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET BOOKLAND LABEL ID* below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the ASCII Character Set and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET BOOKLAND LABEL ID

## **EAN-8 Enable**

Enables/disables the ability of the scanner to decode EAN/JAN-8 labels.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



EAN-8 = DISABLE



EAN-8 = ENABLE

### **EAN-8 Check Character Transmission**

Enables/disables transmission of an EAN/JAN-8 check character.



This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



EAN-8 CHECK CHARACTER TRANSMISSION = DISABLE



EAN-8 CHECK CHARACTER TRANSMISSION = ENABLE

## **Expand EAN-8 to EAN-13**

Enables/disables expansion of EAN/JAN-8 labels to EAN/JAN-13.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



EXPAND EAN/JAN-8 TO EAN/JAN-13 = DISABLE



EXPAND EAN/JAN-8 TO EAN/JAN-13 = ENABLE

#### **EAN 8 Label ID**

This feature specifies an EAN 8 label ID to be added to barcode data. To set this feature:



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET EAN 8 LABEL ID* below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET EAN 8 LABEL ID

## **EAN-8 2-Digit Supplemental Label ID**

This feature specifies an EAN-8 2-Digit Supplemental label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- Scan the SWITCH barcode.
- Scan the barcode, SET EAN-8 2-DIGIT SUPPLEMENTAL LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET EAN-8 2-DIGIT SUPPLEMENTAL LABEL ID

## **EAN-8 5-Digit Supplemental Label ID**

This feature specifies an EAN-8 5-Digit Supplemental label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- Scan the barcode, SET EAN-8 5-DIGIT SUPPLEMENTAL LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET EAN-8 5-DIGIT SUPPLEMENTAL LABEL ID

## **EAN-8 128 Supplemental Label ID**

This feature specifies an EAN-8 128 Supplemental label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- Scan the SWITCH barcode.
- 2. Scan the barcode, SET EAN-8 128 SUPPLEMENTAL LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET EAN-8 128 SUPPLEMENTAL LABEL ID

## **EAN-8 Decoding Levels**

Decoding levels allow the decoder to be set to perform at one of four selectable levels:

- Very Conservative Slower scan time, virtually eleminates misreads. The most secure setting.
- Slightly More Aggressive Faster scanning, more aggressive, yet minimizes misreads.
- Moderately Aggressive Even faster scanning, even more aggressive.
- Very Aggressive Fastest scan speed, most aggressive.



Use caution when setting this feature, as the aggressive settings for this feature allow a higher potential for misreads.

To set this feature:

- Scan the SWITCH barcode.
- 2. Scan the barcode representing the desired option on the following pages. You'll need to cover any unused barcodes on facing pages to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



NOTE

It is important to note that the default for this feature is the "Slightly More Aggressive" setting. For default settings for other features, see Appendix E.

## **EAN-8 Decoding Levels — continued**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



EAN-8 DECODING LEVELS = VERY CONSERVATIVE



EAN-8 DECODING LEVELS = SLIGHTLY MORE AGGRESSIVE

## **EAN-8 Decoding Levels — continued**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



EAN-8 DECODING LEVELS = MODERATELY AGGRESSIVE



EAN-8 DECODING LEVELS = VERY AGGRESSIVE

# **Other UPC/EAN Options**

The following pages contain other selectable features for UPC/EAN symbologies:

- UPC/EAN Reconstruction
- Price Weight Check
- Enable EAN Two Label
- Addons
- UPC-A and EAN-13 Decoding Levels

#### **UPC/EAN Reconstruction**

Enables/disables the ability of the scanner to decode a class of UPC/EAN labels with voids. The label voids may be caused by printing defects or physical damage. This feature may be helpful in environments with instore printed labels.



Enabling this feature increases the potential of misreads.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.

Complete the programming sequence by scanning the SWITCH barcode.



UPC/EAN RECONSTRUCTION = DISABLE



UPC/EAN RECONSTRUCTION = ENABLE

## **Price Weight Check**

Enables/disables calculation and verification of price/weight check digits. Applies to all UPC-A and EAN/JAN-13 labels with eligible Number System/First Character digits.

#### Options are:

- Disable
- 4-digit price/weight
- 5-digit price/weight
- 4-digit European price/weight
- 5-digit European price/weight

- Scan the SWITCH barcode.
- 2. Scan the barcode representing the desired option below or on the following pages. You'll need to cover any unused barcodes on facing pages to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



PRICE WEIGHT CHECK = DISABLE

Price Weight Check generally applies to UPC-A labels with a Number System Digit of 2 and EAN/ JAN-13 labels with a First Character of 2. There are a total of six flag digits corresponding to the six types. Checking applies depending upon which type is enabled.

## **Price Weight Check — continued**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



PRICE WEIGHT CHECK = 4-DIGIT PRICE/WEIGHT



PRICE WEIGHT CHECK = 5-DIGIT PRICE/WEIGHT

## **Price Weight Check — continued**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



PRICE WEIGHT CHECK = 4-DIGIT EUROPEAN PRICE/WEIGHT



PRICE WEIGHT CHECK = 5-DIGIT EUROPEAN PRICE/WEIGHT

### **Enable EAN Two Label**

Enables/disables the ability of the scanner to decode EAN two-label pairs.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



Contact Customer Support for details about advanced programming for this feature.



EAN TWO LABEL = DISABLE



EAN TWO LABEL = ENABLE

#### **Addons**

The scanner is capable of processing different types of addon codes, including:

- 2-Digit Supplemental
- 5-Digit Supplemental

Options are provided on the following pages for your convenience:

- Disable all addons The scanner will not look for or read addons.
- Optional 2-Digit and 5-Digit Supplemental Barcodes can be read which include 2-Digit or 5-Digit Supplementals, however, it is not required that addons be included in barcodes.



NOTE

Contact customer support for advanced programming of optional and conditional addons.

- 1. Scan the SWITCH barcode.
- Scan the barcode representing the desired option on this and the following page. You'll need to cover any unused barcodes on facing pages to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



ADDONS = DISABLE

## Addons — continued

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



ADDONS = OPTIONAL 2-DIGIT AND 5-DIGIT SUPPLEMENTAL

## **UPC-A and EAN-13 Decoding Levels**

Decoding levels allow the decoder to be set to perform at one of four selectable levels:

- Very Conservative Slower scan time, virtually eleminates misreads. The most secure setting.
- Slightly More Aggressive Faster scanning, more aggressive, yet minimizes misreads.
- Moderately Aggressive Even faster scanning, even more aggressive.
- Very Aggressive Fastest scan speed, most aggressive.



Use caution when setting this feature, as the aggressive settings for this feature allow a higher potential for misreads.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode representing the desired option on the following pages. You'll need to cover any unused barcodes on facing pages to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



NOTE

It is important to note that the default for this feature is the "Slightly More Aggressive" setting. For default settings for other features, see Appendix E.

## **UPC-A and EAN-13 Decoding Levels — continued**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



UPC-A/EAN-13 DECODING LEVELS = VERY CONSERVATIVE



UPC-A/EAN-13 DECODING LEVELS = SLIGHTLY MORE AGGRESSIVE

## **UPC-A and EAN-13 Decoding Levels — continued**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



UPC-A/EAN-13 DECODING LEVELS = MODERATELY AGGRESSIVE



UPC-A/EAN-13 DECODING LEVELS = VERY AGGRESSIVE

### **GTIN Enable**

Enables/Disables the ability to convert UPCE, UPCA, EAN8, and EAN13 labels into the GTIN 14-character format.



If add-on information is present on the base label prior to the conversion taking place, the add-on information will be appended to the converted GTIN barcode.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



GTIN = DISABLE



GTIN = ENABLE

#### **GTIN Label ID**

This feature specifies a GTIN label ID to be added to barcode data when GTIN conversion is enabled.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET GTIN LABEL ID* below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF (for each of the two characters).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET GTIN LABEL ID

## **GTIN 2-Digit Supplemental Label ID**

This feature specifies a GTIN label ID to be added to barcode data when GTIN conversion is enabled and 2-digit supplemental addon barcode labels are converted.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- Scan the SWITCH barcode.
- 2. Scan the barcode, SET GTIN 2-DIGIT SUPPLEMENTAL LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF (for each of the two characters).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET GTIN 2-DIGIT SUPPLEMENTAL LABEL ID

# **GTIN 5-Digit Supplemental Label ID**

This feature specifies a GTIN label ID to be added to barcode data when GTIN conversion is enabled and 5-digit supplemental addon barcode labels are converted.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- Scan the SWITCH barcode.
- Scan the barcode, SET GTIN 5-DIGIT SUPPLEMENTAL LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF (for each of the two characters).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET GTIN 5-DIGIT SUPPLEMENTAL LABEL ID

# **GTIN Code 128 Supplemental Label ID**

This feature specifies a GTIN label ID to be added to barcode data when GTIN conversion is enabled and Code 128 supplemental addon barcode labels are converted



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET GTIN CODE 128 SUPPLEMENTAL LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF (for each of the two characters).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET GTIN CODE 128 SUPPLEMENTAL LABEL ID

# **DataBar Omnidirectional Enable**

Enables/disables the ability of the scanner to decode DataBar Omnidirectional labels.



This value-added feature is a factory-programmed option. Contact your dealer for information about upgrading your system to include this advanced capability.

NOTE

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



DATABAR OMNIDIRECTIONAL = DISABLE



DATABAR OMNIDIRECTIONAL = ENABLE

#### **DataBar Omnidirectional Check Character Transmission**

Enables/disables transmission of the DataBar Omnidirectional check character.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



DATABAR OMNIDIRECTIONAL CHECK CHARACTER TRANSMISSION = DISABLE



DATABAR OMNIDIRECTIONAL CHECK CHARACTER TRANSMISSION = ENABLE

#### **DataBar Omnidirectional/EAN-128 Emulation**

Enables/disables the ability of DataBar Omnidirectional to be transmitted as EAN-128.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



DATABAR OMNIDIRECTIONAL/EAN-128 EMULATION = DISABLE



DATABAR OMNIDIRECTIONAL/EAN-128 EMULATION = ENABLE

# **DataBar Omnidirectional 2D Component Enable**

When this feature is enabled, the software will not decode an DataBar Omnidirectional barcode with a 2D component associated with it, and the 2D component will be discarded.

#### To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



DATABAR OMNIDIRECTIONAL 2D COMPONENT = DISABLE



DATABAR OMNIDIRECTIONAL 2D COMPONENT = ENABLE

#### **DataBar Omnidirectional AIM ID**

This feature enables/disables transmission of the DataBar Omnidirectional AIM symbology identifier.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



DATABAR OMNIDIRECTIONAL AIM ID = DISABLE



DATABAR OMNIDIRECTIONAL AIM ID = ENABLE

#### **DataBar Omnidirectional Label ID**

This feature specifies an DataBar Omnidirectional label ID to be added to barcode data.

To set this feature:



The programming feature, RS-232 Label ID Control, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- Scan the barcode, SET DATABAR OMNIDIRECTIONAL LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the ASCII Character Set and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FE.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET DATABAR OMNIDIRECTIONAL LABEL ID

# **DataBar Expanded Enable**

Enables/disables the ability of the scanner to decode DataBar Expanded labels.



NOTE

This value-added feature is a factory-programmed option. Contact your dealer for information about upgrading your system to include this advanced capability.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



DATABAR EXPANDED = DISABLE



DATABAR EXPANDED = ENABLE

# **DataBar Expanded EAN-128 Emulation**

Enables/disables EAN 128 emulation for DataBar Expanded.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



DATABAR EXPANDED/EAN-128 EMULATION = DISABLE



DATABAR EXPANDED/EAN-128 EMULATION = ENABLE

# **DataBar Expanded 2D Component Enable**

When this feature is enabled, the software will not decode an DataBar Expanded barcode with a 2D component associated with it, and the 2D component will be discarded.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



DATABAR EXPANDED 2D COMPONENT = DISABLE



DATABAR EXPANDED 2D COMPONENT = ENABLE

# **DataBar Expanded AIM ID**

This feature enables/disables transmission of the DataBar Expanded AIM symbology identifier.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



DATABAR EXPANDED AIM ID = DISABLE



DATABAR EXPANDED AIM ID = ENABLE

# **DataBar Expanded Label ID**

This feature specifies an DataBar Expanded label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- Scan the SWITCH barcode.
- 2. Scan the barcode, SET DATABAR EXPANDED LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET DATABAR EXPANDED LABEL ID

# **DataBar Expanded Length Control**

This feature specifies either variable-length or fixed-length decoding for DataBar Expanded.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



DATABAR EXPANDED LENGTH CONTROL = VARIABLE-LENGTH



DATABAR EXPANDED LENGTH CONTROL = FIXED-LENGTH

# **DataBar Expanded Length 1**

If DataBar Expanded Length Control is set to Fixed-Length decoding, this feature specifies DataBar Expanded first fixed length. If DataBar Expanded Length Control is set to Variable-Length decoding, this feature specifies the minimum label length.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET DATABAR EXPANDED LENGTH 1 below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 00 to 74. Pad all single digit numbers with a leading zero to yield a two-digit entry (00-74).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET DATABAR EXPANDED LENGTH 1

# **DataBar Expanded Length 2**

If DataBar Expanded Length Control is set to Fixed-Length decoding, this feature specifies DataBar Expanded second fixed length. If DataBar Expanded Length Control is set to Variable-Length decoding, this feature specifies the maximum label length.



When in Fixed Length mode, if Length 2 is set to the value of 00 (zero), then only Length 1 will apply.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET DATABAR EXPANDED LENGTH 2* below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 00 to 74. Pad all single digit numbers with a leading zero to yield a two-digit entry (00-74).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET DATABAR EXPANDED LENGTH 2

# Code 39 Enable

Enables/disables the ability of the scanner to decode Code 39 labels.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 39 = DISABLE



CODE 39 = ENABLE

# **Code 39 Start Stop Character Transmission**

Enables/disables transmission of Code 39 start and stop characters.



This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 39 START STOP CHARACTER TRANSMISSION = DISABLE



CODE 39 START STOP CHARACTER TRANSMISSION = ENABLE

#### **Code 39 Check Character Calculation**

Enables/disables calculation and verification of an optional Code 39 check character. When disabled, any check character in label is treated as a data character.



If check calculation is disabled, the risk is increased that a misread can occur.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 39 CHECK CHARACTER CALCULATION = DISABLE



CODE 39 CHECK CHARACTER CALCULATION = ENABLE

### **Code 39 Check Character Transmission**

Enables/disables transmission of optional Code 39 check character.



This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 39 CHECK CHARACTER TRANSMISSION = DISABLE



CODE 39 CHECK CHARACTER TRANSMISSION = ENABLE

#### **Code 39 Full ASCII**

Enables/disables the ability of the scanner to translate to Code 39 full ASCII labels.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 39 FULL ASCII = DISABLE



CODE 39 FULL ASCII = ENABLE

#### Code 39 AIM ID

This feature enables/disables transmission of the Code 39 AIM symbology identifier.

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 39 AIM ID = DISABLE



CODE 39 AIM ID = ENABLE

#### Code 39 Label ID

This feature specifies a Code 39 label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET CODE 39 LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET CODE 39 LABEL ID

# **Code 39 Length Control**

This feature specifies whether variable-length or fixed-length decoding will be set for Code 39.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 39 LENGTH CONTROL = VARIABLE-LENGTH



CODE 39 LENGTH CONTROL = FIXED-LENGTH

# Code 39 Length 1

If Code 39 Length Control is set to Fixed-Length decoding, this feature specifies Code 39 first fixed length. If Code 39 Length Control is set to Variable-Length decoding, this feature specifies the minimum label length.

- Scan the SWITCH barcode.
- 2. Scan the barcode, *SET CODE 39 LENGTH 1* below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 00 to 50. Pad all single digit numbers with a leading zero to yield a two-digit entry (00-50).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET CODE 39 LENGTH 1

# Code 39 Length 2

If Code 39 Length Control is set to Fixed-Length decoding, this feature specifies Code 39 second fixed length. If Code 39 Length Control is set to Variable-Length decoding, this feature specifies the maximum label length.



When in Fixed Length mode, if Length 2 is set to the value of 00, then only Length 1 will apply

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET CODE 39 LENGTH 2* below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 00, no second fixed length, or 01 to 50. Pad all single digit numbers with a leading zero to yield a two-digit entry (00-50).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET CODE 39 LENGTH 2

# **Code 39 Stitching**

Enables/disables stitching for Code 39 labels. When parts of a Code 39 barcode are presented to the scanner with this feature enabled, the barcode parts will be assembled by the scanner's software, and the data will be decoded if all barcode proofing requirements are met.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.

Complete the programming sequence by scanning the SWITCH barcode.



CODE 39 STITCHING = DISABLE



CODE 39 STITCHING = ENABLE

# **Code 32 Enable**

Enables/disables the ability of the scanner to decode Italian Pharmaceutical Code 32 labels.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 32 = DISABLE



CODE 32 = ENABLE

# **Code 32 Start Stop Character Transmission**

Enables/ disables transmission of start and stop characters for Code 32.



This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 32 START STOP CHARACTER TRANSMISSION = DISABLE



CODE 32 START STOP CHARACTER TRANSMISSION = ENABLE

#### **Code 32 Check Character Transmission**

Enables/disables transmission of Code 32 check character.



This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 32 CHECK CHARACTER TRANSMISSION = DISABLE



CODE 32 CHECK CHARACTER TRANSMISSION = ENABLE

#### Code 32 Label ID

This feature specifies a Code 32 label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET CODE 32 LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET CODE 32 LABEL ID

### **Code 128 Enable**

Enables/disables the ability of the scanner to decode Code 128 labels.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 128 = DISABLE



CODE 128 = ENABLE

#### **Code 128 Transmit Function Characters**

Enables/disables transmission of Code 128 function characters 1, 2, 3, and 4.



Disabled is the recommended setting for all interfaces.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 128 TRANSMIT FUNCTION CHARACTERS = DISABLE



CODE 128 TRANSMIT FUNCTION CHARACTERS = ENABLE

#### **Convert Code 128 to Code 39**

Enables/disables conversion of Code 128 labels to Code 39.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CONVERT CODE 128 TO CODE 39 = DISABLE



CONVERT CODE 128 TO CODE 39 = ENABLE

#### Code 128 AIM ID

This feature enables/disables transmission of the Code 128 AIM symbology identifier.

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 128 AIM ID = DISABLE



CODE 128 AIM ID = ENABLE

#### Code 128 Label ID

This feature specifies a Code 128 label ID to be added to barcode data...



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET CODE 128 LABEL ID* below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the ASCII Character Set and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET CODE 128 LABEL ID

# **Code 128 Length Control**

This feature specifies whether variable-length or fixed-length decoding will be set for Code 128.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 128 LENGTH CONTROL = VARIABLE-LENGTH



CODE 128 LENGTH CONTROL = FIXED-LENGTH

# Code 128 Length 1

If Code 128 Length Control is set to Fixed-Length decoding, this feature specifies Code 128 first fixed length. If Code 128 Length Control is set to Variable-Length decoding, this feature specifies the minmum label length.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET CODE 128 LENGTH 1 below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 01 to 80. Pad all single digit numbers with a leading zero to yield a two-digit entry (01-80).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET CODE 128 LENGTH 1

## Code 128 Length 2

If Code 128 Length Control is set to Fixed-Length decoding, this feature specifies Code 128 second fixed length. If Code 128 Length Control is set to Variable-Length decoding, this feature specifies the maximum label length.



When in Fixed Length mode, if Length 2 is set to the value of 00 (zero), then only Length 1 will apply.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET CODE 128 LENGTH 2 below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 01 to 80. Pad all single digit numbers with a leading zero to yield a two-digit entry (01-80).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET CODE 128 LENGTH 2

# **Code 128 Stitching**

Enables/disables stitching for Code 128 labels. When parts of a Code 128 barcode are presented to the scanner with this feature enabled, the barcode parts will be assembled by the scanner's software, and the data will be decoded if all barcode proofing requirements are met.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.

Complete the programming sequence by scanning the SWITCH barcode.



CODE 128 STITCHING = DISABLE



CODE 128 STITCHING = ENABLE

## **EAN-128 Enable**

Enables/disables the ability of the scanner to decode EAN-128 labels.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



EAN-128 = DISABLE



EAN-128 = ENABLE

### **EAN 128 AIM ID**

This feature enables/disables transmission of the EAN 128 AIM symbology identifier.

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



EAN 128 AIM ID = DISABLE



EAN 128 AIM ID = ENABLE

### EAN 128 Label ID

This feature specifies an EAN 128 label ID to be added to barcode data...



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET EAN 128 LABEL ID* below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET EAN 128 LABEL ID

# Interleaved 2 of 5 (I 2 OF 5) Enable

Enables/disables the ability of the scanner to decode Interleaved 2 of 5 labels.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



12 OF 5 = DISABLE



12 OF 5 = ENABLE

## I 2 of 5 Check Character Calculation

Enables/disables calculation and verification of an optional Interleaved 2 of 5 check character.



If check character calculation is disabled, the risk is increased that a misread can occur. When disabled, any check characters in a barcode are treated as data characters.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



I 2 of 5 CHECK CHARACTER CALCULATION = DISABLE



I 2 of 5 CHECK CHARACTER CALCULATION = ENABLE

## 12 of 5 Check Character Transmission

Enables/disables transmission of an optional Interleaved 2 of 5 check character.



This feature applies only when *I 2 of 5 Check Character Calculation* is enabled. This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



I 2 of 5 CHECK CHARACTER TRANSMISSION = DISABLE



12 of 5 CHECK CHARACTER TRANSMISSION = ENABLE

## I 2 of 5 AIM ID

This feature enables/disables transmission of the I 2 of 5 AIM symbology identifier.

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



I 2 of 5 AIM ID = DISABLE



L2 of 5 AIM ID = ENABLE

### I 2 of 5 Label ID

This feature specifies an I 2 of 5 label ID to be added to barcode data..



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET I 2 of 5 LABEL ID* below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the ASCII Character Set and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET I 2 of 5 LABEL ID

# I 2 of 5 Length Control

This feature specifies whether variable-length or fixed-length decoding will be set for I 2 of 5.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



I 2 OF 5 LENGTH CONTROL = VARIABLE-LENGTH



12 OF 5 LENGTH CONTROL = FIXED-LENGTH

# I 2 of 5 Length 1

If I 2 of 5 Length Control is set to Fixed-Length decoding, this feature specifies I 2 of 5 first fixed length. If I 2 of 5 Length Control is set to Variable-Length decoding, this feature specifies the minimum label length.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET I 2 OF 5 LENGTH 1* below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 02 to 50, even numbers only. Pad all single digit numbers with a leading zero to yield a two-digit entry (02-50).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET I 2 OF 5 LENGTH 1

# I 2 of 5 Length 2

If I 2 of 5 Length Control is set to Fixed-Length decoding, this feature specifies I 2 of 5 second fixed length. If I 2 of 5 Length Control is set to Variable-Length decoding, this feature specifies the maximum label length.



When in Fixed Length mode, if Length 2 is set to the value of 00 (zero), then only Length 1 will apply.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET I 2 OF 5 LENGTH 2* below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 00, or 02 to 50; even numbers only. Pad all single digit numbers with a leading zero to yield a two-digit entry (02-50).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET 12 OF 5 LENGTH 2

# I 2 of 5 Stitching

Enables/disables stitching for I 2 of 5 labels. When parts of an I 2 of 5 barcode are presented to the scanner with this feature enabled, the barcode parts will be assembled by the scanner's software, and the data will be decoded if all barcode proofing requirements are met.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.

Complete the programming sequence by scanning the SWITCH barcode.



12 OF 5 STITCHING = DISABLE



12 OF 5 STITCHING = ENABLE

## **Codabar Enable**

Enables/disables the ability of the scanner to decode Codabar labels.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODABAR = DISABLE



CODABAR = ENABLE

# **Codabar Start Stop Character Transmission**

Enables/disables transmission of Codabar start and stop characters.



This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODABAR START STOP CHARACTER TRANSMISSION = DISABLE



CODABAR START STOP CHARACTER TRANSMISSION = ENABLE

# **Codabar Start Stop Character Set**

This feature selects the format of transmitted Codabar start/stop characters.

## Options are:

- ABCD/TN\* E
- ABCD/ABCD
- abcd/tn\* e
- abcd/abcd

#### To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode below or from the following page representing the desired option. You'll need to cover any unused barcodes and facing pages to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODABAR START STOP CHARACTER = ABCD/TN\* E



CODABAR START STOP CHARACTER = ABCD/ABCD

# **Codabar Start Stop Character Set — continued**

Remember to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



CODABAR START STOP CHARACTER = abcd/tn\* e




CODABAR START STOP CHARACTER = abcd/abcd

# **Codabar Start Stop Character Match**

Enables/disables the requirement that start and stop characters match.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODABAR START STOP CHARACTER MATCH = DISABLE



CODABAR START STOP CHARACTER MATCH = ENABLE

## **Codabar Check Character Calculation**

Enables/disables calculation and verification of an optional Codabar check character.



If check character calculation is disabled, the risk is increased that a misread can occur. When disabled, any check characters in a barcode are treated as data characters.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODABAR CHECK CHARACTER CALCULATION = DISABLE



CODABAR CHECK CHARACTER CALCULATION = ENABLE

## **Codabar Check Character Transmission**

Enables/disables transmission of an optional Codabar check character.



Applies only when *Codabar Check Character Calculation* is enabled. This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODABAR CHECK CHARACTER TRANSMISSION = DISABLE



CODABAR CHECK CHARACTER TRANSMISSION = ENABLE

## **Codabar AIM ID**

This feature enables/disables transmission of the Codabar AIM symbology identifier.

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODABAR AIM ID = DISABLE



CODABAR AIM ID = ENABLE

### **Codabar Label ID**

This feature specifies a Codabar label ID to e added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- 1. Scan the SWITCH barcode.
- Scan the barcode, SET CODABAR LABEL ID below. You'll need
  to cover any unused barcodes on this and the facing page to
  ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET CODABAR LABEL ID

# **Codabar Length Control**

This feature specifies whether variable-length or fixed-length decoding will be set for Codabar.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODABAR LENGTH CONTROL = VARIABLE-LENGTH



CODABAR LENGTH CONTROL = FIXED-LENGTH

# **Codabar Length 1**

If Codabar Length Control is set to Fixed-Length decoding, this feature specifies Codabar first fixed length. If Codabar Length Control is set to Variable-Length decoding, this feature specifies the minimum label length.

- Scan the SWITCH barcode.
- 2. Scan the barcode, SET CODABAR LENGTH 1 below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 03 to 50. Pad all single digit numbers with a leading zero to yield a two-digit entry (03-50).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET CODABAR LENGTH 1

# **Codabar Length 2**

If Codabar Length Control is set to Fixed-Length decoding, this feature specifies Codabar second fixed length. If Codabar Length Control is set to Variable-Length decoding, this feature specifies the maximum label length.



When in Fixed Length mode, if Length 2 is set to the value of 00 (zero), then only Length 1 will apply.

- 1. Scan the SWITCH barcode.
- Scan the barcode, SET CODABAR LENGTH 2 below. You'll
  need to cover any unused barcodes on this and the facing page to
  ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 00, or 03 to 50. Pad all single digit numbers with a leading zero to yield a two-digit entry (03-50).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET CODABAR LENGTH 2

# **Codabar Stitching**

Enables/disables stitching for Codabar labels. When parts of a Codabar barcode are presented to the scanner with this feature enabled, the barcode parts will be assembled by the scanner's software, and the data will be decoded if all barcode proofing requirements are met.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.

Complete the programming sequence by scanning the SWITCH barcode.



CODABAR STITCHING = DISABLE



CODABAR STITCHING = ENABLE

## **Code 93 Enable**

Enables/disables the ability of the scanner to decode Code 93 labels.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 93 = DISABLE



CODE 93 = ENABLE

## Code 93 AIM ID

This feature enables/disables transmission of the Code 93 AIM symbology identifier.

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 93 AIM ID = DISABLE



CODE 93 AIM ID = ENABLE

### Code 93 Label ID

This feature specifies a Code 93 label ID to be added to barcode data...



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET CODE 93 LABEL ID* below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the ASCII Character Set and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET CODE 93 LABEL ID

# **Code 93 Length Control**

This feature specifies whether variable-length or fixed-length decoding will be set for Code 93.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



CODE 93 LENGTH CONTROL = VARIABLE-LENGTH



CODE 93 LENGTH CONTROL = FIXED-LENGTH

# Code 93 Length 1

If Code 93 Length Control is set to Fixed-Length decoding, this feature specifies Code 93 first fixed length. If Code 93 Length Control is set to Variable-Length decoding, this feature specifies the minimum label length.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET CODE 93 LENGTH 1 below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 01 to 50. Pad all single digit numbers with a leading zero to yield a two-digit entry (01-50).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET CODE 93 LENGTH 1

# Code 93 Length 2

If Code 93 Length Control is set to Fixed-Length decoding, this feature specifies Code 93 second fixed length. If Code 93 Length Control is set to Variable-Length decoding, this feature specifies the maximum label length.



When in Fixed Length mode, if Fixed Length 2 is set to the value of 00 (zero), then only Length 1 will apply.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET CODE 93 LENGTH 2* below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 00, or 01 to 50. Pad all single digit numbers with a leading zero to yield a two-digit entry (01-50).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET CODE 93 LENGTH 2

# **Code 93 Stitching**

Enables/disables stitching for Code 93 labels. When parts of a Code 93 barcode are presented to the scanner with this feature enabled, the barcode parts will be assembled by the scanner's software, and the data will be decoded if all barcode proofing requirements are met.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.

Complete the programming sequence by scanning the SWITCH barcode.



CODE 93 STITCHING = DISABLE



CODE 93 STITCHING = ENABLE

## **MSI/Plessey Enable**

Enables/disables the ability of the scanner to decode MSI/Plessey labels.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



MSI/PLESSEY = DISABLE



MSI/PLESSEY = ENABLE

## **MSI/Plessey Check Character Calculation**

Enables/disables calculation and verification of optional MSI/Plessey check characters.



If check character calculation is disabled, the risk is increased that a misread can occur. When disabled, any check characters in a barcode are treated as data characters.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



MSI/PLESSEY CHECK CHARACTER CALCULATION = DISABLE



MSI/PLESSEY CHECK CHARACTER CALCULATION = ENABLE

### **MSI/Plessey Number of Check Characters**

Specifies number of MSI/Plessey check characters to be calculated and verified.



Check characters are always modulus 10.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode below representing the desired number of MSI/ Plessey check characters to be calculated and verified. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



MSI/PLESSEY NUMBER OF CHECK CHARACTERS = 1



MSI/PLESSEY NUMBER OF CHECK CHARACTERS = 2

## **MSI/Plessey Check Character Transmission**

Enables/disables transmission of optional MSI/Plessey check characters.



This feature applies only when *MSI/Plessey Check Character Calculation* is enabled. This item is ignored when the advanced feature, Full Label Edit, is enabled.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



MSI/PLESSEY CHECK CHARACTER TRANSMISSION = DISABLE



MSI/PLESSEY CHECK CHARACTER TRANSMISSION = ENABLE

#### **MSI/Plessey AIM ID**

This feature enables/disables transmission of the MSI/Plessey AIM symbology identifier.

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



MSI/PLESSEY AIM ID = DISABLE



MSI/PLESSEY AIM ID = ENABLE

## **MSI/Plessey Label ID**

This feature specifies an MSI/Plessey label ID to be added to barcode data.



The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET MSI/PLESSEY LABEL ID below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the *ASCII Character Set* and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET MSI/PLESSEY LABEL ID

### **MSI/Plessey Length Control**

This feature specifies whether variable-length or fixed-length decoding will be set for MSI/Plessey.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



MSI/PLESSEY LENGTH CONTROL = VARIABLE-LENGTH



MSI/PLESSEY LENGTH CONTROL = FIXED-LENGTH

## **MSI/Plessey Length 1**

If MSI/Plessey Length Control is set to Fixed-Length decoding, this feature specifies MSI/Plessey first fixed length. If MSI/Plessey Length Control is set to Variable-Length decoding, this feature specifies the minimum label length.

- 1. Scan the SWITCH barcode.
- Scan the barcode, SET MSI/PLESSEY LENGTH 1 below. You'll
  need to cover any unused barcodes on this and the facing page to
  ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 4 to 16. Pad all single digit numbers with a leading zero to yield a two-digit entry (04-16).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET MSI/PLESSEY LENGTH 1

### **MSI/Plessey Length 2**

If MSI/Plessey Length Control is set to Fixed-Length decoding, this feature specifies MSI/Plessey second fixed length. If MSI/Plessey Length Control is set to Variable-Length decoding, this feature specifies the maximum label length.



When in Fixed Length mode, if Length 2 is set to the value 00 (zero), then only Length 1 will apply.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET MSI/PLESSEY LENGTH 2 below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 0 (zero), or 4 to 16. Pad all single digit numbers with a leading zero to yield a two-digit entry (00, 04-16).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET MSI/PLESSEY LENGTH 2

## **MSI/Plessey Stitching**

Enables/disables stitching for MSI/Plessey labels. When parts of an MSI/Plessey barcode are presented to the scanner with this feature enabled, the barcode parts will be assembled by the scanner's software, and the data will be decoded if all barcode proofing requirements are met.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.

Complete the programming sequence by scanning the SWITCH barcode.



MSI/PLESSEY STITCHING = DISABLE



MSI/PLESSEY STITCHING = ENABLE

## Standard 2 of 5 Enable

Enables/disables the ability of the scanner to decode Standard 2 of 5 labels.

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



STANDARD 2 OF 5 = DISABLE



STANDARD 2 OF 5 = ENABLE

#### Standard 2 of 5 Check Character Calculation

Enables/disables calculation and verification of an optional Standard 2 of 5 check character.



**NOTE** 

If check character calculation is disabled, the risk is increased that a misread can occur. When disabled, any check character in a barcode is treated as data character.

#### To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



STANDARD 2 of 5 CHECK CHARACTER CALCULATION = DISABLE



STANDARD 2 of 5 CHECK CHARACTER CALCULATION = ENABLE

#### Standard 2 of 5 Check Character Transmission

Enables/disables transmission of an optional Standard 2 of 5 check character.



**NOTE** 

This feature applies only when *Standard 2 of 5 Check Character Calculation* is enabled. This item is ignored when the advanced feature, Full Label Edit, is enabled.

#### To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan either the enable or disable barcode below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



STANDARD 2 of 5 CHECK CHARACTER TRANSMISSION = DISABLE



STANDARD 2 of 5 CHECK CHARACTER TRANSMISSION = ENABLE

#### Standard 2 of 5 AIM ID

This feature enables/disables transmission of the Standard 2 of 5 AIM symbology identifier.

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



STANDARD 2 of 5 AIM ID = DISABLE



STANDARD 2 of 5 AIM ID = ENABLE

#### Standard 2 of 5 Label ID

This feature specifies an Standard 2 of 5 label ID to be added to barcode data.



NOTE

The programming feature, *RS-232 Label ID Control*, designates whether the Label ID is transmitted as a prefix or suffix or if Label ID is disabled.

- Scan the SWITCH barcode.
- 2. Scan the barcode, *SET STANDARD 2 of 5 LABEL ID* below. You'll need to cover any unused barcodes on this and the facing page to ensure the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired Label ID characters; entered as two hex pairs. A table containing the ASCII Character Set and their corresponding Hex Values is available in the inside back cover of this manual. ASCII parameters must be input by scanning a pair of hexadecimal digits for each character. Thus, to set a two-character value of AB, barcodes containing the digits '4', '1', '4', and '2' must be scanned. The selectable range for this option is any hex value from 00 to FF.
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET STANDARD 2 of 5 LABEL ID

### **Standard 2 of 5 Length Control**

This feature specifies whether variable-length or fixed-length decoding will be set for Standard 2 of 5.

To set this feature:

- 1. Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Complete the programming sequence by scanning the SWITCH barcode.



STANDARD 2 OF 5 LENGTH CONTROL = VARIABLE-LENGTH



STANDARD 2 OF 5 LENGTH CONTROL = FIXED-LENGTH

### Standard 2 of 5 Length 1

If Standard 2 of 5 Length Control is set to Fixed-Length decoding, this feature specifies Standard 2 of 5 first fixed length. If Standard 2 of 5 Length Control is set to Variable-Length decoding, this feature specifies the minimum label length.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, *SET STANDARD 2 OF 5 LENGTH 1* below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 1 to 50. Pad all single digit numbers with a leading zero to yield a two-digit entry (01-50).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET STANDARD 2 OF 5 LENGTH 1

### Standard 2 of 5 Length 2

If Standard 2 of 5 Length Control is set to Fixed-Length decoding, this feature specifies Standard 2 of 5 second fixed length. If Standard 2 of 5 Length Control is set to Variable-Length decoding, this feature specifies the maximum label length.



When in Fixed Length mode, if Length 2 is set to the value of 00 (zero), then only Length 1 will apply.

- 1. Scan the SWITCH barcode.
- 2. Scan the barcode, SET STANDARD 2 OF 5 LENGTH 2 below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.
- 3. Scan the appropriate digits from the keypad in Appendix C that represent the desired label length. The selectable range for this option is 1 to 50. Pad all single digit numbers with a leading zero to yield a two-digit entry (01-50).
- 4. Complete the programming sequence by scanning the SWITCH barcode.



SET STANDARD 2 OF 5 LENGTH 2

### **Standard 2 of 5 Stitching**

Enables/disables stitching for Standard 2 of 5 labels. When parts of a Standard 2 of 5 barcode are presented to the scanner with this feature enabled, the barcode parts will be assembled by the scanner's software, and the data will be decoded if all barcode proofing requirements are met.



This applies when *Standard 2 of 5 Length Control* is set to fixed-length decoding.

To set this feature:

- Scan the SWITCH barcode.
- 2. Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.

Complete the programming sequence by scanning the SWITCH barcode.



STANDARD 2 OF 5 STITCHING = DISABLE



STANDARD 2 OF 5 STITCHING = ENABLE


# **NOTES**

# **Appendix A**

## **LED/Beeper Indications & Controls**

Figure A-1 shows the operator's controls and indicators. The descriptions following identify the use or function of each component. Your model may not contain all the controls and indicators listed in this appendix.

Figure A-1. Scanner and Scale Controls



#### **Controls and Indicators**

The control panel consists of three indicator LEDs and three push buttons as described in the following pages. The unit also includes a beeper which can be configured to sound indications of scanning, weighing, and deactivation activities.



Since beeper indications are configurable, your unit may not be programmed to sound all the indications listed. For more information, see the Programming section of this manual.

#### **LED and Beeper Indications**

#### **Scanner and Scale LEDs**

The Scanner LED (green, top-most) indicates scanner status, and the Scale LED (yellow, middle) is primarily used to show scale status (see Table 1-1).

Table 1-1. Scanner and Scale LED Indications

LED INDICATION	DURATION	COMMENT
Scale at Zero <sup>a</sup>	Scale (Yellow) LED on steady	The scale is at rest and reads zero weight. The scale is ready to weigh.
Scanner Active <sup>a</sup> (Normal Mode)	Scanner (Green) LED on steady and dim	The scanner is ready for operation. Scanning is immediately available.
Good Read Indication <sup>a</sup>	Scanner (Green) LED - bright flash	Indicates a barcode has been read and decoded.
Program Mode Indication	Scanner (Green) LED - Continuous flashing	Indicates the scanner is in Label Programming Mode. Cycle power to exit Programming Mode.
Sleep Mode Indication	Scanner (Green) LED flashes slowly	The scanner motor and/or laser have automatically switched off and the unit has entered Sleep Mode due to extended inactivity.

**Table 1-1. Scanner and Scale LED Indications** 

LED INDICATION	DURATION	COMMENT
Host Disabled	Scanner (Green) LED 1-second off, 1/10-second on	Host has disabled scanning.
Field Replace- able Unit (FRU) Warning (Error Mode)	Audible low tone 1 second. Alternating Scanner/Scale (Green/ Yellow) LEDs flash continuously <sup>b</sup> .	Serves notice that a fatal FRU failure has been detected. Consult Error Codes in this manual for more details. If a low tone is heard, but continuous flashing is not observed, the scanner can still function in a limited capacity. Call systems support for service in either case.
FRU Indication	Scanner (Green) LED flashes a coded sequence in concert with the speaker.	Occurs ONLY upon Volume/Tone button push following a FRU warning. Enables service technicians to identify FRU failures.

a. Certain functions of the Green and Yellow LEDs are selectable to be enabled or disabled. Your scanner may not be programmed to display all indications.

b. For FRU error 9, the Deactivator LED (tri-color) is off.

#### **Deactivator LED**

The Deactivator LED (tri-color, bottom-most) designates EAS deactivation status (see Table 1-2). The table also provides information about special beeper indications which can be sounded in response to changes in deactivation status.

**Table 1-2. EAS Indications** 

EAS DEACTIVATION DISABLED				
INDICATION	LED DURATION	EAS BEEPER	COMMENT	
Deactivation Disabled	Deactivation (Tri-color) LED is OFF	OFF	Deactivation mode must be selected via programming. Refer- ence EAS Mode.	
ALL MODES (COL	JPLED, DECOUPLED, HYBRID o	r HOST)		
Deactivation Ready	Deactivation (Tri-color) LED is lit steadily Green.	OFF	Deactivation is ready.	
EAS tag Detected	flashes Red. OFF b		An EAS tag has been sensed in the scan volume.	
Power-up Initialization	Deactivation (Tri-color) LED <sup>a</sup> blinks ON/OFF Red.	OFF	System is attempting to initialize EAS	
EAS Error	Deactivation (Tri-color) LED flashes Red while FRU Status LED flashes error code nine (9).	Low frequency beep (1 second)	EAS system is not on line.	

**Table 1-2. EAS Indications** 

	COUPLED MODE ONLY				
Deactivation Indicated	Deactivation (Tri-color) LED flashes Red, then Orange, then returns to Green.	Good read beep follows deactivation.	The EAS antenna has been triggered ON to deactivate a label following successful barcode read.		
Manual Deactivation in Progress	Deactivation (Tri-color) LED is lit steadily Green.	Ticking sound (for configurable duration)	The Manual EAS Deactivation Push Button was pressed & released <sup>b</sup> .		
Manual Deactivation Successful	Deactivation (Tri-color) LED flashes Red, then Orange, then returns to Green.	High frequency beep	An EAS tag was successfully deactivated via manual push button.		
Deactivate EAS System When Failed	Deactivation (Tri-color) LED is flashing slowly Red. FRU Status LED displays error code nine (9)	Upon initiating this state (pressing EAS Button for 3 seconds): 3 high-pitched beeps	Upon EAS malfunction/failure, scanning function can continue independent of EAS if the EAS button is held for 3 seconds.		
	DECOUPLE	D MODE			
Deactivation (Tri-color) LED flashes Red.		EAS Beep OFF	An EAS tag has been successfully deactivated.		
Deactivation Indicated					

**Table 1-2. EAS Indications** 

HYBRID MODE			
Deactivation Indicated	Deactivation (Tri-color) LED flashes Red, then Orange, then returns to Green.	High frequency beep	An EAS tag has been successfully deactivated.

- a. Additionally, the FRU LED (7-segment display located in the bottom of the optic cavity visible through the horizontal scan window) blinks the number '9'. If EAS deactivation fails to initiate, a low, error tone will be sounded, and the FRU LED will display the error code '9' steadily (without flashing).
- b. Ticking sound will stop upon one of the following: 1) Manual EAS Deactivation Push Button is pressed and released again, 2) EAS timer runs out, or 3) Following a successful EAS tag deactivation.

#### **Volume/Tone Push Button**

The Volume/Tone Push Button also performs multiple functions depending upon the duration of time it is pressed:



Volume changes made using the Volume/Tone Push Button are lost when the scanner is powered-down and are reset to the factory default setting. If you wish to permanently change the volume, use the special programming labels in Chapter 7, *Programming*.

Table 1-3. Volume/Tone Push Button Functions

PRESS DURATION	FUNCTION	COMMENT
Momentary (when scanner is asleep)	Wakes scanner from Sleep Mode	Alternatively, the scanner can be awakened by:  - Moving an object through the scan zone.  - A weight change on the scale.  - Scanning with an attached auxiliary scanner.
Momentary (when scanner is awake)	Increments volume	Press the push button momentarily to increase speaker volume. When the loudest volume is reached, a repeated press of the push button cycles volume back to the lowest setting, then volume increases on subsequent press(es). Four volume levels are available.

**Table 1-3. Volume/Tone Push Button Functions (Continued)** 

PRESS DURATION	FUNCTION	COMMENT
Hold, then release when the beeper sounds	Increments tone	Press the push button for approximately 2 seconds, then release. Each time this is done, the beeper will sound at one of three tones. Stop when the desired tone (high, medium or low) is sounded.
4 Seconds	Scanner Diagnostics Mode <sup>a</sup>	This mode allows system support personnel to trouble-shoot problems with the scanner. Upon entering Scanner Diagnostic Mode, view the 7-segment display to view Interface Type, Bootloader Version Number, Application Version Number and Configuration File Number. This mode is used to determine if a scanner can read barcodes. Press the button for eight seconds or cycle power to exit Scanner Diagnostics Mode and reset the scanner.
8 Seconds	Resets Scanner <sup>b</sup>	Only system support personnel should perform a reset.

a. By standard default, this function is normally disabled to prevent accidental activation by users.

b. Users should not perform scanner resets except under the direction of trained systems support personnel.

#### **Manual EAS Deactivation Push Button**

Using the programming barcodes contained in Chapter 7, Programming, the button can be configured to operate always, or only function when the scanner is enabled.

PRESS DURATION	FUNCTION	COMMENT
Momentary <sup>a</sup>	Manually initiates EAS deactivation	Place the item with the EAS tag downstream <sup>b</sup> of the horizontal scan window and push the button.
3 Seconds upon EAS error	Allows scanner to resume function despite EAS system failure (non-fatal error)	EAS Failure Mode is indicated <sup>c</sup> by: - EAS LED blinks ON/OFF red, scanning disabled FRU Status LED Indicator blinks '9' - Error tone is sounded for one second Upon pressing the button for 3 seconds, the scanner will sound 3 high-pitched beeps, then resume scan function. The EAS LED and FRU Status LED will continue blinking as above, but at a slower rate until EAS system function is restored.

- a. For use in Coupled Mode only
- b. "Downstream" in this case is defined as being the downstream side of the scan window from the direction of product flow, or scanning direction.
- c. If the EAS failure corrects itself, blinking will stop and the EAS LED will turn green.

#### **Scale Zero Push Button**

The Scale Zero Push Button is used for multiple functions as listed in Table 1-4.



The Scale Zero Push Button has no function in a "scanner only" model.

**Table 1-4. Scale Zero Push Button Functions** 

PRESS DURATION	FUNCTION	COMMENT
Momentary	Zero Scale	When programmed to do so, the yellow LED should be lit when no weight is on the scale, indicating scale at zero. If it is not, press the switch to zero the scale. The unit will sound a "click" upon pressing the button.
4 Seconds	Scale Diagnostics Mode <sup>a</sup>	This mode allows system support personnel to troubleshoot prob- lems with the scale. Momentarily press the Scale Zero Push Button or cycle power to exit Scale Diagnostics Mode.
8 Seconds	Resets Scanner	Only system support personnel

Diagnostics Mode is meant for use by trained systems support personnel. Users should not need to initiate this function under normal circumstances.

#### **Calibration Switch**

This switch initiates the scale's calibration routine. A certified weight set is needed to perform the scale calibration steps detailed in Chapter 5, Calibration Procedures, Single Interval. This switch is not included in scanners without scale modules.

#### **Calibration Switch Seal**

This seal allows you to secure the Calibration Switch access cover and restrict access to the Calibration Switch. If the calibration seal is broken or missing, you may be prohibited from operating the scale without recertification. Check local and state requirements for specific restrictions.

#### **Calibration Switch Cover**


This cover restricts access to the Calibration Switch to help guard against unauthorized tampering when sealed. See Figure A-2.



There are regulations that must be followed in order to ensure compliance when operating a weighing device such as the scanner/scale. Failure to observe and comply with these regulations could result in legal action.

Figure A-2. Calibration Switch Cover

or...



# **Appendix B**

## **Cable Information**

## Introduction

The following pages contain pinout information, enabling you to create standard interface cables for use in interconnecting the scanner, scale, external handheld scanner, and POS terminal.

## **General Specifications**

#### **Wire Requirements**

- Cable length should not exceed 15 feet.
- Wire gauge = Standard for RJ-45 connectors (28-26 AWG).
- If run exceeds 15 feet, we recommend 26 AWG wire size.

## **RS-232 Cable Pinout**

#### **Scanner**

#### **Connector Hardware**

RJ45, 10 Position

**Cable Pinout** 

**Table 2-1RS-232 Cable Pinouts** 

PIN#	FUNCTION	DESCRIPTION
1	N/C	No Connection
2	CTS in	Clear To Send (input)
3	N/C	No Connection
4	RTS out	Request To Send (output)
5	RxD in	Receive Data (Input)
6	TxD out	Transmit Data (output)
7	N/C	No Connection
8	N/C	No Connection
9	GND	Signal Ground
10	N/C	No Connection

## **RS-232 Cable Pinout — continued**

#### Scale

#### **Connector Hardware**

RJ45, 10 Position

**Cable Pinout** 

**Table 2-2RS-232 Scale Cable Pinouts** 

PIN#	FUNCTION	DESCRIPTION
1	+5V pullup	+5V pullup
2	CTS IN	Clear To Send (input)
3	N/C	No Connection
4	RTS OUT	Request To Send (output)
5	RxD IN	Receive Data (Input)
6	TxD OUT	Transmit Data (output)
7	N/C	No Connection
8	N/C	No Connection
9	Gnd	Signal Ground
10	N/C	No Connection

## **IBM Cable Pinout**

#### **Scanner and Scale**

#### **Connector Hardware**

RJ45, 10 Position

#### **Cable Pinout**

**Table 2-3IBM Cable Pinouts** 

PIN #	FUNCTION	DESCRIPTION
1	N/C	No Connection
2	N/C	No Connection
3	N/C	No Connection
4	LINEB	Line B
5	N/C	No Connection
6	LINEA	Line A
7	N/C	No Connection
8	N/C	No Connection
9	GND	Signal Ground
10	N/C	No Connection

### **OEM USB Cable Pinout**

### **Scanner and Scale**

### **Connector Hardware**

RJ45, 10 Position

**Cable Pinout** 

### **Table B-4 OEM USB Cable Pinouts**

PIN#	FUNCTION	DESCRIPTION
1	N/C	No Connection
2	N/C	No Connection
3	N/C	No Connection
4	USB D-	USB D-
5	N/C	No Connection
6	USB D+	USB D+
7	N/C	No Connection
8	N/C	No Connection
9	GND	Signal Ground
10	N/C	No Connection

## **Auxilliary Port**

## **External Handheld Input**

### **Connector Hardware**

RJ45, 10 Position

**Cable Pinout** 

**Table 2-5Auxilliary Port Cable Pinouts** 

PIN#	FUNCTION	DESCRIPTION
1	+5V pullup	+5V pullup
2	CTS in	Clear To Send (input)
3	N/C	No Connection - Reserved
4	RTS out	Request To Send (output)
5	RxD in	Receive Data (Input)
6	TxD out	Transmit Data (output)
7	N/C	No Connection
8	+5V out (500mA max)	+5V out
9	GND	Signal Ground
10	N/C	No Connection

### **Power Cable**

### **Connector Hardware**

6 pin Molex

**Cable Pinout** 

**Table 2-6Power Cable Pinouts** 

PIN#	FUNCTION	DESCRIPTION
1	EARTH GND	Earth Ground
2	SIGNAL GND	Signal Ground
3	+5V IN	+5V in
4	N/C	No Connection
5	N/C	No Connection
6	+12V IN	+12V in

## **Remote Display**

### **Connector Hardware**

4 pin SDL

### **Cable Pinout**

### **Table 2-7Remote Display Cable Pinouts**

PIN#	FUNCTION	DESCRIPTION				
1	+12V OUT	+12V out				
2	LINE_A_DSPLY	LINE A Display				
3	LINE_B_DSPLY	LINE B Display				
4	GND	Ground				

### **EAS Comm Port — Sensormatic**

### **EAS Deactivator Control Box Connection**

### **Connector Hardware**

RJ10

**Cable Pinout** 

**Table 2-8EAS Comm Port Cable Pinouts** 

PIN#	FUNCTION	DESCRIPTION
1	VCC5	VCC5
2	EAS DEACT EN~	EAS Deactivation
3	VCC5	VCC5
4	EAS DETECT EN~	EAS Detection
5	EAS LBL DETECT EN~	EAS tag Detect
6	GND	Signal Ground
7	N/C	No Connection
8	EAS TXD	EAS Transmit Data
9	EAS RXD	EAS Receive Data
10	GND	Signal Ground

## **EAS Interlock Connector — Checkpoint**



Antenna Connections. Connect ONLY using approved cables approved by the manufacturer for this product.

#### **Connector Hardware**

RJ-4

#### **Cable Pinout**

Table B-9

PIN#	SIGNAL
1	GND
2	+5V Out
3	EAS Out
4	Speaker Out <sup>a</sup>

a. The "Speaker Out" line is an analog signal (5Vpp max), connected to one of the internal speaker terminals, intended to connect to an external amplifier to drive an external speaker.

# **Appendix C**

## **Keypad**

Use the barcodes in this section to enter numbers and characters as you would select digits/characters from a keypad.

Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



(



Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



2





4



Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



C



Scan your selection from the barcodes below. You'll need to cover any unused barcodes on this and the facing page to ensure that the scanner reads only the barcode you intend to scan.



ζ





A





C



D



ь



F

# **Appendix D**

### **Host Commands**

## **Accepting Commands from an RS-232 Scanner Host**

The scanner responds to the following RS-232 commands:

COMMAND	ASCII	HEX	COMMENT
Enable Scanner	Е	0x45	
Disable Scanner	D	0x44	
Reset Scanner	R	0x52	
Not On File Indication	F	0x46	Long series of beeps
Beep Good Read Tone	В	0x42	Beeps if Good Read Beep is enabled
Force Good Read Tone		0x01	Beeps regardless of beep setting
Bel		0x07	Force Good Read Tone
Identification request	i	0x69	Returns long response <sup>a</sup>
Health request	h	0x68	Returns long response <sup>a</sup>
Status request	S	0x73	Returns long response <sup>a</sup>

a. Call Tech Support for information.

If one of the above commands is received, the scanner will perform the steps indicated for the command. Host commands for other interfaces is also available. Contact Tech Support for more details.

# **NOTES**

# **Appendix E**

# **Factory Defaults**

The following table provides a listing of the most common factory settings for the interfaces shown.

**Table 5-1. Factory Default Settings** 

	Aux	RS-232	Wincor- Nixdorf	Single Cable	IBM 17	OEM USB
Double Read Time- out	60 (600ms)	60 (600ms)	60 (600ms)	60 (600ms)	60 (600ms)	60 (600ms)
Laser Timeout	20 (5 min.)					
Motor Timeout	40 (10 min.)					
Green LED Idle State	2 (on dim)					
Scanner Button Options	1 (vol/tone/ reset)	1 (vol/tone/ reset)	1 (vol/tone/ reset)	1 (vol/tone/ reset)	1 (vol/tone/ reset)	1 (vol/tone/ reset)
Power-up Beep Control	1 beep					
Good Read Beep Control	1 (enable)					
Good Read Beep Frequency	1 (medium)	1 (medium)	1 (medium)	1 (medium)	1 (medium)	1 (medium)
Good Read Beep Length	8 (80ms)					
Good Read Beep Volume	3 (med- high)					
Good Read When to Indicate	0 (after decode)					
Scale Enable	0 (disable)	1 (enable)	0 (disable)	1 (enable)	1 (enable)	1 (enable)

	Aux	RS-232	Wincor- Nixdorf	Single Cable	IBM 17	OEM USB
Scale Enforced Zero Return	0 (disable)					
Scale Interface Type	4 (RS-232 SASI)	4 (RS-232 SASI)	4 (RS-232 SASI)	7 (RS-232 single cable)	1 (IBM Port 17)	3 (OEM USB)
Remote Display — Enable/Disable	1 (enable)					
Aux Port Mode	0 (disable)					
Laser Failure Mode	0 (single OK)					
Productivity Index Reporting (PIR)/ Cashier Training (CT)	0 (disable)					
EAS Mode	0 (disable)					
EAS Beep Duration	8 (80ms)					
EAS Retry Count	3	3	3	3	3	3
Manual EAS Deactivation Push Button	2 (enable only when scanner enabled)					
EAS Deactivation Duration — Coupled	50 (500ms)	50 (500ms)	50 (500ms)	50 (500ms)	50 (500ms)	50 (500ms)
EAS Deactivation Duration — Retry	50 (500ms)	50 (500ms)	50 (500ms)	50 (500ms)	50 (500ms)	50 (500ms)
EAS Deactivation Duration — Manual	100 (5sec)					
EAS Active State	0 (active low)					
EAS Timeout	2 (20ms)					

	Aux	RS-232	Wincor- Nixdorf	Single Cable	IBM 17	OEM USB
Maximum Host- Transmitted Mes- sage Length	0 (no limit)	0 (no limit)	0 (no limit)	0 (no limit)	0 (no limit)	0 (no limit)
Number of Host Transmission Buffers	1 (2 buffers)	1 (2 buffers)	1 (2 buffers)	1 (2 buffers)	0 (1 buffer)	0 (1 buffer)
Global Prefix	("")	("")	("")	("")		
Global Suffix	0D00 ("\0D")	0D00 ("\0D")	0D00("")	("")		
IBM Scale Address					110	
IBM Transmit Labels in Code 39 Format					0 (disable)	
OEM USB Scanner Device Type						0 (fixed scanner)
RS-232 Baud Rate	1 (9600)	1 (9600)	1 (9600)	1 (9600)		
RS-232 Number of Data Bits	1 (8 data bits)	1 (8 data bits)	1 (8 data bits)	0 (7 data bits)		
RS-232 Number of Stop Bits	0 (1 stop bit)	0 (1 stop bit)	0 (1 stop bit)	0 (1 stop bit)		
RS-232 Parity	0 (none)	0 (none)	2 (odd)	2 (odd)		
RS-232 Hardware Control	0 (disable)	0 (disable)	1 (enable CTS flow)			
RS-232 Intercharacter Delay	0 (none)	0 (none)	0 (none)			
RS-232 Software Flow Control	0 (disable)	0 (disable)	0 (disable)	0 (disable)		
RS-232 Host Echo		0 (disable)	0 (disable)			
RS-232 Host Echo Quiet Interval	1 (10ms)	1 (10ms)				

	Aux	RS-232	Wincor- Nixdorf	Single Cable	IBM 17	OEM USB
RS-232 Ignore Host Commands	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
RS-232 TTL		0 (normal RS-232)	0 (normal RS-232)			
RS-232 TTL Invert	0 (disable)	0 (disable)				
RS-232 Beep on ASCII BEL	0 (disable)	0 (disable)	0 (disable)			
RS-232 Beep After Weigh	1 (enable)	1 (enable)	0 (disable)	1 (enable)		
RS-232 Beep on Not on File	1 (enable)	1 (enable)	1 (enable)	1 (enable)		
RS-232 ACK NAK Enable	0 (disable)	0 (disable)	0 (disable)			
RS-232 ACK Character	6 (ACK)	6 (ACK)	6 (ACK)			
RS-232 NAK Character	21 (NAK)	21 (NAK)	21 (NAK)			
RS-232 Retry on ACK NAK Timeout	1 (enable)	1 (enable)	1 (enable)			
RS-232 ACK NAK Timeout Value	1 (200ms)	1 (200ms)	1 (200ms)			
RS-232 ACK NAK Retry Count	3 resets	3 resets	3 resets			
RS-232 ACK NAK Error Handling	0 (ignore errors)	0 (ignore errors)	0 (ignore errors)			
RS-232 Label ID Control	1 (enable as prefix)	1 (enable as prefix)	1 (enable as prefix)	1 (enable as prefix)		
Single Cable RS-232 Scanner Only Proto- col		0 (scan- ner-scale)				

	Aux	RS-232	Wincor- Nixdorf	Single Cable	IBM 17	OEM USB
Single Cable RS-232 RTS CTS Selection				Option 5		
Single Cable RS-232 Use BCC			0 (disable)			
Single Cable RS-232 Use ACK/NAK			0 (disable)			
Single Cable RS-232 Use STX			1 (enable)			
Set Single Cable RS- 232 STX Character				83 (S)		
Single Cable RS-232 Use ETX			1 (enable)			
Set Single Cable RS- 232 ETX Character				13 (CR)		
Single Cable RS-232 Datalogic Extensions				0 (std protocol)		
UPC-A Enable	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)
UPC-A Number System Character Transmission	0 (disable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)
UPC-A Check Character Transmission	1 (enable)	1 (enable)	1 (enable)	0 (disable)	1 (enable)	1 (enable)
Expand UPC-A to EAN-13	0 (disable)	0 (disable)	1 (enable)	0 (disable)	0 (disable)	0 (disable)
UPC/EAN AIM ID	0 (disable)	0 (disable)	0 (disable)			
UPC-A Label ID	4100("A")	4100("A")	4100("A")	4100("A")		
UPC-A 2-Digit Supplemental Label ID	4100("A")	4100("A")	4100("A")	4100("A")		
UPC-A 5-Digit Supplemental Label ID	4100("A")	4100("A")	4100("A")	4100("A")		

	Aux	RS-232	Wincor- Nixdorf	Single Cable	IBM 17	OEM USB
UPC-A 128 Supple- mental Label ID	4100("A")	4100("A")	4100("A")	4100("A")		
UPC-E Enable	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)
UPC-E Number System Character Transmission	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)
UPC-E Check Character Transmission	0 (disable)	0 (disable)	0 (disable)	0 (disable)	1 (enable)	1 (enable)
Expand UPC-E to UPC-A	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
Expand UPC-E to EAN-13	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
UPC-E Label ID	4500("E")	4500("E")	4300("C")	4500("E")		
UPC-E 2-Digit Supplemental Label ID	4500("E")	4500("E")	4300("C")	4500("E")		
UPC-E 5-Digit Supplemental Label ID	4500("E")	4500("E")	4300("C")	4500("E")		
UPC-E 128 Supple- mental Label ID	4500("E")	4500("E")	4300("C")	4500("E")		
EAN-13 Enable	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)
UPC-E 128 Supplemental Label ID	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)
EAN-13 Check Character Transmission	1 (enable)	1 (enable)	1 (enable)	0 (disable)	1 (enable)	1 (enable)
EAN-13 ISBN Conversion Enable	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
EAN 13 Label ID	4600("F")	4600("F")	4100("A")	4600("F")		
EAN-13 2-Digit Supplemental Label ID	4600("F")	4600("F")	4100("A")	4600("F")		

	Aux	RS-232	Wincor- Nixdorf	Single Cable	IBM 17	OEM USB
EAN-13 5-Digit Supplemental Label ID	4600("F")	4600("F")	4100("A")	4600("F")		
EAN-13 128 Supplemental Label ID	4600("F")	4600("F")	4100("A")	4600("F")		
Bookland AIM ID	0 (disable)	0 (disable)	0 (disable)			
Bookland Label ID	4900 ("I")	4900 ("I")	4100 ("A")	4900 ("I")		
EAN-8 Enable	1 (enable)					
EAN-8 Check Character Transmission	1 (enable)	1 (enable)	1 (enable)	0 (disable)	1 (enable)	1 (enable)
Expand EAN-8 to EAN-13	0 (disable)					
EAN 8 Label ID	4646 ("FF")	4646 ("FF")	4200 ("B")	4646 ("FF")		
EAN-8 2-Digit Supplemental Label ID	4646 ("FF")	4646 ("FF")	4200 ("B")	4646 ("FF")		
EAN-8 5-Digit Supplemental Label ID	4646 ("FF")	4646 ("FF")	4200 ("B")	4646 ("FF")		
EAN-8 128 Supple- mental Label ID	4646 ("FF")	4646 ("FF")	4200 ("B")	4646 ("FF")		
UPC/EAN Reconstruction	0 (disable)					
Price Weight Check	0 (disable)					
Enable EAN Two Label	0 (disable)					
Addons	Disable All					
UPC-A and EAN-13 Decoding Levels	Slightly More Aggres- sive	Slightly More Aggres- sive	Slightly More Aggres- sive	Slightly More Aggres- sive	Slightly More Aggres- sive	Slightly More Aggres- sive

	Aux	RS-232	Wincor- Nixdorf	Single Cable	IBM 17	OEM USB
GTIN Label ID	4700 ("G")	4700 ("G")	4700 ("G")	4700 ("G")		
GTIN 2-Digit Supplemental Label ID	4700 ("G")	4700 ("G")	4700 ("G")	4700 ("G")		
GTIN 5-Digit Supplemental Label ID	4700 ("G")	4700 ("G")	4700 ("G")	4700 ("G")		
GTIN Code 128 Supplemental Label ID	4700 ("G")	4700 ("G")	4700 ("G")	4700 ("G")		
DataBar Omnidirectional Enable	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
DataBar Omnidirectional Check Character Transmission	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)
DataBar Omnidirectional/EAN-128 Emulation	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
DataBar Omnidirectional 2D Component Enable	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
DataBar Omnidirectional AIM ID	0 (disable)	0 (disable)	0 (disable)			
DataBar Omnidirectional Label ID	5234 ("R4")	5234 ("R4")	4500 ("E")	5234 ("R4")		
DataBar Expanded Enable	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
DataBar Expanded EAN-128 Emulation	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
DataBar Expanded 2D Component Enable	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
DataBar Expanded AIM ID	0 (disable)	0 (disable)	0 (disable)			

	Aux	RS-232	Wincor- Nixdorf	Single Cable	IBM 17	OEM USB
DataBar Expanded Label ID	5258 ("RX")	5258 ("RX")	4500 ("E")	5258 ("RX")		
DataBar Expanded Length Control	0 (variable)	0 (variable)	0 (variable)	0 (variable)	0 (variable)	0 (variable)
DataBar Expanded Length 1	8 Fixed 1 Min					
DataBar Expanded Length 2	14 Fixed 74Max					
Code 39 Enable	1 (enable)	1 (enable)	0 (disable)	1 (enable)	1 (enable)	1 (enable)
Code 39 Start Stop Character Transmis- sion	0 (disable)					
Code 39 Check Character Calculation	0 (disable)					
Code 39 Check Character Transmission	1 (enable)					
Code 39 Full ASCII	0 (disable)					
Code 39 AIM ID	0 (disable)	0 (disable)	0 (disable)			
Code 39 Label ID	2A00 ("*")	2A00 ("*")	4D00 ("M")	4231 ("B1")		
Code 39 Length Control	0 (variable)	0 (variable)	0 (variable)	0 (variable)	0 (variable)	0 (variable)
Code 39 Length 1	8 Fixed 2 Min					
Code 39 Length 2	14 Fixed 50 Max					
Code 39 Stitching	1 (enable)					
Code 32 Enable	1 (enable)	0 (disable)				

	Aux	RS-232	Wincor- Nixdorf	Single Cable	IBM 17	OEM USB
Code 32 Start Stop Character Transmis- sion	0 (disable)					
Code 32 Check Character Transmission	1 (enable)					
Code 32 Label ID	4100("A")	4100("A")	4100("A")	4100("A")		
Code 128 Enable	1 (enable)	1 (enable)	0 (disable)	1 (enable)	1 (enable)	1 (enable)
Code 128 Transmit Function Characters	0 (disable)					
Convert Code128 to Code 39	0 (disable)					
Code 128 AIM ID	0 (disable)	0 (disable)	0 (disable)			
Code 128 Label ID	2300 ("#")	2300 ("#")	4B00 ("K")	4233 ("B3")		
Code 128 Length Control	0 (variable)	0 (variable)	0 (variable)	0 (variable)	0 (variable)	0 (variable)
Code 128 Length 1	8 Fixed 2 Min					
Code 128 Length 2	14 Fixed 80 Max					
Code 128 Stitching	1 (enable)					
EAN-128 Enable	0 (disable)					
EAN 128 AIM ID	1 (enable)	1 (enable)	0 (disable)			
EAN 128 Label ID	0000 ("")	0000 ("")	5000 ("P")	0000 ("")		
Interleaved 2 of 5 (I 2 OF 5) Enable	0 (disable)					
I 2 of 5 Check Character Calculation	0 (disable)					

	Aux	RS-232	Wincor- Nixdorf	Single Cable	IBM 17	OEM USB
I 2 of 5 Check Character Transmission	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)
I 2 of 5 AIM ID	0 (disable)	0 (disable)	0 (disable)			
I 2 of 5 Label ID	6900 ("i")	6900 ("i")	4900 ("I")	4232 ("B2")		
I 2 of 5 Length Control	0 (variable)	0 (variable)	0 (variable)	0 (variable)	0 (variable)	0 (variable)
I 2 of 5 Length 1	10 Fixed 6 Min	10 Fixed 6 Min	10 Fixed 6 Min	10 Fixed 6 Min	10 Fixed 6 Min	10 Fixed 6 Min
I 2 of 5 Length 2	0 Fixed 50 Max	0 Fixed 50 Max	0 Fixed 50 Max	0 Fixed 50 Max	0 Fixed 50 Max	0 Fixed 50 Max
I 2 of 5 Stitching	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
Codabar Enable	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
Codabar Start Stop Character Transmis- sion	0 (disable)	0 (disable)	1 (enable)	0 (disable)	0 (disable)	0 (disable)
Codabar Start Stop Character Set	3 (abcd/ abcd)	3 (abcd/ abcd)	3 (abcd/ abcd)	3 (abcd/ abcd)	3 (abcd/ abcd)	3 (abcd/ abcd)
Codabar Start Stop Character Match	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
Codabar Check Character Calculation	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
Codabar Check Character Transmission	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)
Codabar AIM ID	0 (disable)	0 (disable)	0 (disable)			
Codabar Label ID	2500 ("%")	2500 ("%")	4E00 ("N")	2500 ("%")		
Codabar Length Control	0 (variable)	0 (variable)	0 (variable)	0 (variable)	0 (variable)	0 (variable)

	Aux	RS-232	Wincor- Nixdorf	Single Cable	IBM 17	OEM USB
Codabar Length 1	8	8	8	8	8	8
Codabar Length 2	14 Fixed 50 Max	14 Fixed 50 Max	14 Fixed 50 Max	14 Fixed 50 Max	14 Fixed 50 Max	14 Fixed 50 Max
Codabar Stitching	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
Code 93 Enable	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
Code 93 AIM ID	0 (disable)	0 (disable)	0 (disable)			
Code 93 Label ID	2600 ("&")	2600 ("&")	4C00 ("L")	2600 ("&")		
Code 93 Length Control	0 (variable)	0 (variable)	0 (variable)	0 (variable)	0 (variable)	0 (variable)
Code 93 Length 1	8 Fixed 2 Min	8 Fixed 2 Min	8 Fixed 2 Min	8 Fixed 2 Min	8 Fixed 2 Min	8 Fixed 2 Min
Code 93 Length 2	14 Fixed 50 Max	14 Fixed 50 Max	14 Fixed 50 Max	14 Fixed 50 Max	14 Fixed 50 Max	14 Fixed 50 Max
Code 93 Stitching	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)
MSI/Plessey Enable	0 (disable)	0 (disable)	0 (disable)	0 (disable)		
MSI/Plessey Check Character Calculation	1 (enable)	1 (enable)	1 (enable)	1 (enable)		
MSI/Plessey Number of Check Characters	0 (1 check char)	0 (1 check char)	0 (1 check char)	0 (1 check char)		
MSI/Plessey Check Character Transmis- sion	1 (enable)	1 (enable)	1 (enable)	1 (enable)		
MSI/Plessey AIM ID	0 (disable)	0 (disable)	0 (disable)			
MSI/Plessey Label ID	4000 ("@")	4000 ("@")	4F00 ("O")	4000 ("@")		
MSI/Plessey Length Control	0 (variable)	0 (variable)	0 (variable)	0 (variable)		

	Aux	RS-232	Wincor- Nixdorf	Single Cable	IBM 17	OEM USB
MSI/Plessey Length 1	7 Fixed 4 Min	7 Fixed 4 Min	7 Fixed 4 Min	7 Fixed 4 Min		
MSI/Plessey Length 2	8 Fixed 16 Max	8 Fixed 16 Max	8 Fixed 16 Max	8 Fixed 16 Max		
MSI/Plessey Stitching	0 (disable)	0 (disable)	0 (disable)	0 (disable)		
Standard 2 of 5 Enable	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
Standard 2 of 5 Check Character Cal- culation	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
Standard 2 of 5 Check Character Transmission	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)	1 (enable)
Standard 2 of 5 AIM ID	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)
Standard 2 of 5 Label ID	5300 ("S")	5300 ("S")	5300 ("S")	5300 ("S")	5300 ("S")	5300 ("S")
Standard 2 of 5 Length Control	0 (variable)	0 (variable)	0 (variable)	0 (variable)	0 (variable)	0 (variable)
Standard 2 of 5 Length 1	10 Fixed 6 Min	10 Fixed 6 Min	10 Fixed 6 Min	10 Fixed 6 Min	10 Fixed 6 Min	10 Fixed 6 Min
Standard 2 of 5 Length 2	0 Fixed 50 Max	0 Fixed 50 Max	0 Fixed 50 Max	0 Fixed 50 Max	0 Fixed 50 Max	0 Fixed 50 Max
Standard 2 of 5 Stitching	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)	0 (disable)

# **NOTES**

# **Appendix F**

## **Handheld Data Format Requirements**

This appendix provides application notes to describe the general format of data that can be accepted by the scanner through the auxiliary port as transmitted from a handheld scanner.

### **Handheld Data Format Requirements General**

- 9600 bps, 8 data bits, 1 stop bit, no parity.
- RTS is used to "bracket" the data received from the handheld: RTS must be asserted high during data transmission, and deasserted after label transmission is complete. No other flow control mechanisms are required or supported.
- Symbologies requiring fixed lengths (UPC/EAN) will enforce length requirements for validation of the label.
- Handheld will be required to transmit start and stop characters for Codabar and Code 39 labels.
- Appropriate industrial length requirements will be enforced (if configured) for validation of the label.
- Maximum label lengths will be enforced for label validation (i.e. labels longer than the maximum label size will not be validated).
- Standard Datalogic formats generally use a single prefix character.
   The specific formats are provided below.

### **Datalogic Handheld Data Format Requirements**

The following sections describe label transmission formats that are typically observed in factory configurations of Datalogic handheld scanners.

#### **DataBar Omnidirectional**

- Prefix must be ASCII characters 'R4'
- Check character must be included in label
- Application identifier "01" must follow the prefix and preced the base label
- Label length excluding prefix characters must be 16 characters.
- Example: 'R40101044123456789'

### **DataBar Expanded**

Prefix must be ASCII characters 'R4'
 Check character must be included in label

#### **UPC-A**

- Number system must be included in label data.
- Check digit must be included in label data and is assumed to be correct.
- Prefix must be an ASCII character 'A' total length including prefix must be 13.
- Example: 'A060992011187'.

### **UPC-A with 2-Digit Supplemental**

- Number system must be included in label data.
- Check digit must be included in label data and is assumed to be correct.
- Supplemental data is appended to base label.
- Prefix must be an ASCII character 'A' total length including prefix must be 15.
- Example: 'A06099201118712'.

### **UPC-A with 5-Digit Supplemental**

- Number system must be included in label data
- Check digit must be included in label data and is assumed to be correct
- Prefix must be an ASCII character 'A' total length including prefix must be 18
- Example: 'A06099201118712345'

### **UPC-A with Code 128 Supplemental**

- Number system must be included in label data.
- Check digit must be included in label data and is assumed to be correct.
- Supplemental data is appended to base label.
- Prefix must be an ASCII character 'A' total length including prefix must be greater or equal to 19 Code 128 Supplemental codes are variable length having a minimum of 2 data characters).
- Characters immediately following base label must be of the form '8100', '8101' or '8102'.
- Example: 'A0609920111878100000951'.

#### **UPC-E**

- Number system must be included in label data
- Check digit must be included in label data and is assumed to be correct
- Prefix must be an ASCII character 'E' total length including prefix must be 9
- Example: 'E09988750'

### **UPC-E with 2-Digit Supplemental**

- Number system must be included in label data.
- Check digit must be included in label data and is assumed to be correct.
- Supplemental data is appended to base label.
- Prefix must be an ASCII character 'E' total length including prefix must be 11.
- Example: 'E0998875012'.

### **UPC-E with 5-Digit Supplemental**

- Number system must be included in label data.
- Check digit must be included in label data and is assumed to be correct.
- Prefix must be an ASCII character 'E' total length including prefix must be 14.
- Example: 'E0998875012345'.

### **UPC-E with Code 128 Supplemental**

- Number system must be included in label data.
- Check digit must be included in label data and is assumed to be correct.
- Supplemental data is appended to base label.
- Prefix must be an ASCII character 'E' total length including prefix must be greater or equal to 15 (code 128 Supplemental codes are variable length having a minimum of 2 data characters).
- Characters immediately following base label must be of the form '8100', '8101' or '8102'.
- Example: 'E099887508101000951'.

#### EAN-8

- Check digit must be included in label data and is assumed to be correct
- Prefix must be an ASCII characters 'FF' total length including prefix must be 10
- Example: 'FF00210126'

### **EAN-8 with 2-Digit Supplemental**

- Check digit must be included in label data and is assumed to be correct.
- Supplemental data is appended to base label.
- Prefix must be an ASCII characters 'FF' total length including prefix must be 12.
- Example: 'FF0021012612'.

### **EAN-8 with 5-Digit Supplemental**

- Check digit must be included in label data and is assumed to be correct.
- Prefix must be an ASCII characters 'FF' total length including prefix must be 15.
- Example: 'FF0021012612345'.

### **EAN-8 with Code 128 Supplemental**

- Check digit must be included in label data and is assumed to be correct.
- Supplemental data is appended to base label.
- Prefix must be an ASCII characters 'FF' total length including prefix must be greater than 16 (code 128 Supplemental codes are variable length having a minimum of 2 data characters).
- Characters immediately following base label must be of the form '8100', '8101' or '8102'.
- Example: 'FF002101268102000951'.

#### **EAN-13**

- Check digit must be included in label data and is assumed to be correct
- Prefix must be an ASCII character 'F'- total length including prefix must be 14
- Example: 'F1101234567891'

### **EAN-13 with 2-Digit Supplemental**

- Check digit must be included in label data and is assumed to be correct
- Supplemental data is appended to base label
- Prefix must be an ASCII character 'F'- total length including prefix must be 16
- Example: 'F110123456789112'

### **EAN-13 with 5-Digit Supplemental**

- Check digit must be included in label data and is assumed to be correct.
- Prefix must be an ASCII character 'F'- total length including prefix must be 19.
- Example: 'F110123456789112345'.

### **EAN-13 with Code 128 Supplemental**

- Check digit must be included in label data and is assumed to be correct
- Supplemental data is appended to base label
- Prefix must be an ASCII character 'F'- total length including prefix must be greater or equal to 20 (code 128 Supplemental codes are variable length having a minimum of 2 data characters)
- Characters immediately following base label must be of the form '8100', '8101' or '8102'
- Example: 'F11012345678918100000951'

#### Code 39

- Check character must be included in label data.
- Label length including start, stop and check characters and excluding prefix character must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.
- Start and stop characters "\*" must be included in label.
- Prefix must be an ASCII character '\*'.
- Example: '\*\*Code 39.TEST\*'.

#### Code 39-Code 32

- Check character must be included in label data.
- Label length including start, stop and check characters and excluding prefix character must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.
- Start and stop characters "\*" must be included in label.
- Prefix must be an ASCII character 'p'.
- Example: 'p\*123456789\*'.

#### 12 of 5

- Check character must be included in label data.
- Label length including check characters and excluding prefix character must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.
- Prefix must be an ASCII character 'i'.
- Example: 'i0123456789'.

#### Codabar

- Check character must be included in label data.
- Label length including check character and excluding prefix character must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.
- Prefix must be an ASCII character '%'.
- Start stop character sets must meet the matching requirement set forth by the scanner configuration item Codabar Start Stop Character Match.
- Start stop character sets must be of the form ABCD/ABCD and must be included in the label.
- Example: '%s\$99.95s' (the lower case 's' at each end of the example is a placeholder for the start stop character set).

#### **Code 128**

- Prefix must be an ASCII character '#'.
- Label length excluding prefix character must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.
- Function characters may be transmitted as a hexadecimal value 8x. Where x correlates to function characters 1 thru 4 as follows:
- x80 = function code 1
- x81 = function code 2
- x82 = function code 3
- x83 = function code 4
- For Code 128 programming labels the format is of the general form '#/82nnnnn/r ' - /82 is hexadecimal 82 and /r is carriage return.
- Example: '#Code\_128.Test'.

## **MSI/Plessey**

- Check character must be included in label data.
- Label length including check character and excluding prefix character must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.
- Prefix must be an ASCII character '@'.
- Example: '@144769254'.

#### Code 93

- Prefix must be an ASCII character '&'.
- Label length excluding prefix character must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.
- Example: '&Code93-test'.

#### **PDF417**

- Prefix must be an ASCII character 'P'.
- Label length excluding prefix character cannot exceed 300 characters. In addition to this, label length excluding prefix character must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.

## **AIM Formats**

AIM specifies a 3-character string that is attached as a prefix to the label data for transmission. Because AIM specifies one identifier for UPC-A, UPC-E and EAN-13 labels, UPC-A, UPC-E and EAN-13 will be received from the handheld and transmitted by the scanner as EAN-13. The ']' character must be the first character received in the label transmission from the handheld.

The following sections describe the prefix strings and identify what specific label characteristics can be supported.

#### **UPC-A**

• AIM does not specify UPC-A as a separate symbology using this transmission format - labels will be transmitted as EAN-13.

• Example: ']E00060992011187'.

### **UPC-E**

- AIM does not specify UPC-E as a separate symbology using this transmission format - labels will be transmitted as EAN-13.
- Example: ']E0000000998875'.

#### **EAN-13**

- Check digit must be included in label data and is assumed to be correct
- Prefix must be ASCII characters ']E0'- total length including prefix must be 16.
- Example: ']E01101234567891'.

#### EAN-8

- Check digit must be included in label data and is assumed to be correct.
- Prefix must be ASCII characters ']E4' total length including prefix must be 11.
- Example: ']E400210126'.

## 2-Digit Supplemental

- Supplemental data is appended to any EAN base label.
- Prefix must be ASCII characters ']E1'.
- length of Supplemental data including prefix must be 5. Total required length is 21 for EAN-13 and 16 for EAN-8.
- Examples: addon portion is highlighted data is underlined.

UPC-A 2-Digit addon	']E00060992011187 <b>]E1<u>12</u></b> '
UPC-E 2-Digit addon	']E00000000998875 <b>]E1<u>12</u></b> '
EAN-8 2-Digit addon	']E400210126 <b>]E1<u>12</u></b> '
EAN-13 2-Digit addon	']E01101234567891 <b>]E1<u>12</u></b> '

## 5-Digit Supplemental

- Supplemental data is appended to any EAN base label.
- Prefix must be ASCII characters ']E2'.
- Length of supplemental data including prefix must be 8. Total required length is 24 for EAN-13 and 19 for EAN-8.
- Examples: addon portion is highlighted data is underlined.

UPC-A 5-Digit addon	']E00060992011187 <b>]E2<u>12345</u></b> '
UPC-E 5-Digit addon	']E00000000998875 <b>]E2<u>12345</u></b> '
EAN-8 5-Digit addon	']E400210126 <b>]E2<u>12345</u></b> '
EAN-13 5-Digit addon	']E01101234567891 <b>]E2<u>12345</u></b> '

## **Code 128 Supplemental**

- Supplemental data is appended to any EAN base label.
- Prefix must be ASCII characters ']C0'.
- length of Supplemental data including prefix is variable but must be at least 9.
- Examples: addon portion is highlighted data is underlined.

UPC-A Code 128 addon	']E00060992011187 <b>]C0<u>8100000951</u></b> '
UPC-E Code 128 addon	'E0000000998875 <b>]C0<u>8100000951</u></b> '
EAN-8 Code 128 addon	']E400210126 <b>]C0<u>8100000951</u></b> '
EAN-13 Code 128 addon	']E01101234567891 <b>]C0<u>8100000951</u></b> '

## **Bookland**

- The 'Bookland' / ISBN code will be formatted as a vendor specific AIM label.
- Prefix must be ASCII characters ']X0'.
- length of label data including prefix is 13.
- Examples: ']X01234567890'.

#### Code 39

- Check character must be included in label data.
- Label length including start, stop and check characters and excluding prefix characters must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.
- Start and stop characters "\*" must be included in label.
- Prefix must be ASCII characters ']A0' or ']A1'.
- Example: '\*]A0Code 39.TEST\*'.

#### Codabar

- Check character must be included in label data.
- Label length including check character and excluding prefix characters must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.
- Prefix must be ASCII characters ']F0'.
- Start stop character sets must meet the matching requirement set forth by the scanner configuration item Codabar Start Stop Character Match.
- Start stop character sets s must be of the form ABCD/ABCD and must be included in the label.
- Example: ']F0s\$99.95s' (the lower case 's' at each end of the example is a placeholder for the start stop character set).

## **MSI/Plessey**

- Check character must be included in label data.
- Label length including check character and excluding prefix characters must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.
- Prefix must be ASCII characters ']M0'.
- Example: ']M0144769254'.

#### Code 93

- Prefix must be ASCII characters ']G0'.
- Label length excluding prefix characters must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.
- Example: ']G0Code93-test'.

#### **DataBar Omnidirectional**

- Prefix must be ASCII characters ']e0'.
- Check character must be included in label.
- Label length excluding prefix characters must be 14 characters.
- Example: ']e001044123456789'.

## **DataBar Expanded**

- Prefix must be ASCII characters ']e0'.
- Label length excluding prefix characters must be at least 1 character. Maximum length is the maximum label size supported by the scanner.
- Example: ']e001900123456789083103001750'.

#### 12 of 5

- Check character must be included in label data.
- Label length including check characters and excluding prefix characters must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.
- Prefix must be an ASCII character ']I1' (other prefixes specify different check character properties which are not supported).
- Example: ']I10123456789'.

#### **Code 128 / EAN128**

- Prefix must be either ASCII characters ']C0', ']C1' or ']C2'.
- Label length excluding prefix character must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.

- If EAN-128 Symbology is Enabled and prefix is ']C1', label will be identified as an EAN128 otherwise it is identified as a Code 128.
- A prefix of ']C0' designates that no function code is present in the 1st or 2nd character position.
- A prefix of ']C2' designates that a function code 1 is present in the 2nd character.
- Example: ']C0Code\_128.Test'.

### **PDF417**

- Prefix must be an ASCII characters ']L0'.
- Label length excluding prefix character cannot exceed 300 characters. In addition to this, label length excluding prefix character must meet requirements imposed by the main scanner's fixed or variable label length control for this symbology type.
- Example : ']L0pdf\_test\_label'.

# **NOTES**

# **NOTES**

## **ASCII Character Set**

The table on this page shows a set of ASCII characters and their corresponding Hex Values. The Hex Values in this table are needed for setting symbology specific label identifiers, as well as enabling custom prefix and suffix characters.

## **ASCII/Hex Conversion Table**

ASCII Char.	Hex No.	ASCII Char.	Hex No.	ASCII Char.	Hex No.	ASCII Char.	Hex No.
NUL	00	SP	20	@	40	í	60
SOH	01	!	21	A	41	а	61
STX	02	"	22	В	42	b	62
ETX	03	#	23	C	43	C	63
EOT	04	\$	24	D	44	d	64
ENQ	05	%	25	E	45	e	65
ACK	06	&	26	F	46	f	66
BEL	07	,	27	G	47	g	67
BS	08	(	28	H	48	h	68
HT	09	)	29	ı	49	i	69
LF	0A	*	2A	J	4A	j	6A
VT	0B	+	2B	K	4B	k	6B
FF	0C	,	2C	L	4C	1	6C
CR	0D	_	2D	М	4D	m	6D
SO	0E		2E	N	4E	n	6E
SI	0F	/	2F	0	4F	0	6F
DLE	10	0	30	Р	50	р	70
DC1	11	1	31	Q	51	q	71
DC2	12	2	32	R	52	r	72
DC3	13	3	33	S	53	S	73
DC4	14	4	34	Т	54	t	74
NAK	15	5	35	U	55	u	75
SYN	16	6	36	V	56	V	76
ETB	17	7	37	W	57	W	77
CAN	18	8	38	Х	58	Х	78
EM	19	9	39	Υ	59	у	79
SUB	1A	:	3A	Z	5A	Z	7A
ESC	1B	,	3B	[	5B	{	7B
FS	1C	<	3C	\	5C		7C
GS	1D	=	3D	]	5D	}	7D
RS	1E	>	3E	۸	5E	~	7E
US	1F	?	3F	_	5F	DEL	7F



# **STATALOGIC**

## www.datalogic.com

© 2004-2014 Datalogic ADC, Inc. • All rights reserved. • Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A. in many countries, including the U.S.A. and the E.U.

## Datalogic ADC, Inc.

959 Terry Street | Eugene | OR 97402 | USA Telephone: (1) 541-683-5700 | Fax: (1) 541-345-7140



820032814 (Rev. J)

January 2014