




<b>PowerScan PM9300 Laser</b>	
PowerScan PM9300, 433MHz, Laser Scanner, Auto Range, Display/16-Key, Removable Battery	PM9300-DKAR433RB
PowerScan PM9300, 433MHz, Laser Scanner, Auto Range, Display/4-Key, Removable Battery	PM9300-DAR433RB
PowerScan PM9300, 433MHz, Laser Scanner, Auto Range, Removable Battery	PM9300-AR433RB
PowerScan PM9300, 433MHz, Laser Scanner, Standard Range, Display/16-Key, Removable Battery	PM9300-DK433RB
PowerScan PM9300, 433MHz, Laser Scanner, Standard Range, Display/4-Key, Removable Battery	PM9300-D433RB
PowerScan PM9300, 433MHz, Laser Scanner, Standard Range, Removable Battery	PM9300-433RB
PowerScan PM9300, 910MHz, Laser Scanner, Auto Range, Display/16-Key, Removable Battery	PM9300-DKAR910RB
PowerScan PM9300, 910MHz, Laser Scanner, Auto Range, Display/4-Key, Removable Battery	PM9300-DAR910RB
PowerScan PM9300, 910MHz, Laser Scanner, Auto Range, Removable Battery	PM9300-AR910RB
PowerScan PM9300, 910MHz, Laser Scanner, Standard Range, Display/16-Key, Removable Battery	PM9300-DK910RB
PowerScan PM9300, 910MHz, Laser Scanner, Standard Range, Display/4-Keys, Removable Battery	PM9300-D910RB
PowerScan PM9300, 910MHz, Laser Scanner, Standard Range, Removable Battery	PM9300-910RB
PowerScan PM9300, RS-232 Kit, 433MHz, Removable Battery (Kit inc. PM9300-433RB Scanner, BC9030-433 Base, EU Power Brick/Cord, CAB-433 Cable.)	PM9300-433RBK20
PowerScan PM9300, RS-232 Kit, 433MHz, Removable Battery (Kit inc. PM9300-AR433RB Scanner, BC9030-433 Base, EU Power Brick/Cord, CAB-433 Cable.)	PM9300-AR433RBK20
PowerScan PM9300, RS-232 Kit, 433MHz, Removable Battery (Kit inc. PM9300-D433RB Scanner, BC9030-433 Base, EU Power Brick/Cord, CAB-433 Cable.)	PM9300-D433RBK20
PowerScan PM9300, RS-232 Kit, 910MHz, Removable Battery (Kit inc. PM9300-910RB Scanner, BC9030-910 Base, US Power Brick/Cord, CAB-433 Cable.)	PM9300-910RBK20
PowerScan PM9300, RS-232 Kit, 910MHz, Removable Battery (Kit inc. PM9300-AR910RB Scanner, BC9030-910 Base, US Power Brick/Cord, CAB-433 Cable.)	PM9300-AR910RBK20
PowerScan PM9300, RS-232 Kit, 910MHz, Removable Battery (Kit inc. PM9300-D910RB Scanner, BC9030-910 Base, US Power Brick/Cord, CAB-433 Cable.)	PM9300-D910RBK20
PowerScan PM9300, USB Kit, 433MHz, Removable Battery (Kit inc. PM9300-433RB Scanner, BC9030-433 Base, EU Power Brick/Cord, CAB-438 Cable.)	PM9300-433RBK10
PowerScan PM9300, USB Kit, 433MHz, Removable Battery (Kit inc. PM9300-AR433RB Scanner, BC9030-433 Base, EU Power Brick/Cord, CAB-438 Cable.)	PM9300-AR433RBK10
PowerScan PM9300, USB Kit, 433MHz, Removable Battery (Kit inc. PM9300-D433RB Scanner, BC9030-433 Base, EU Power Brick/Cord, CAB-438 Cable.)	PM9300-D433RBK10
PowerScan PM9300, USB Kit, 910MHz, Removable Battery (Kit inc. PM9300-910RB Scanner, BC9030-910 Base, US Power Brick/Cord, CAB-438 Cable.)	PM9300-910RBK10




PowerScan PM9300, USB Kit, 910MHz, Removable Battery (Kit inc. PM9300-AR910RB Scanner, BC9030-910 Base, US Power Brick/Cord, CAB-438 Cable.)	PM9300-AR910RBK10
PowerScan PM9300, USB Kit, 910MHz, Removable Battery (Kit inc. PM9300-D910RB Scanner, BC9030-910 Base, US Power Brick/Cord, CAB-438 Cable.)	PM9300-D910RBK10

<b>BASE STATION</b>	
BC9030 Base Presentation Charger, 433MHz, Multi-Interface (RS-232, USB and KBW), Black	BC9030-BK-433-BP
BC9030 Base Presentation Charger, 433MHz, Multi-Interface (RS-232, USB and KBW), White	BC9030-WH-433-BP
BC9030 Base Presentation Charger, 910MHz, Multi-Interface (RS-232, USB and KBW), Black	BC9030-BK-910-BP
BC9030 Base Presentation Charger, 910MHz, Multi-Interface (RS-232, USB and KBW), White	BC9030-WH-910-BP
BC9030 Base Presentation Charger, BT, Multi-Interface (RS-232, USB and KBW), Black	BC9030-BK-BT-BP
BC9030 Base Presentation Charger, BT, Multi-Interface (RS-232, USB and KBW), White	BC9030-WH-BT-BP
BC9030 Base Station/Charger, 433 MHz, Multi-Interface (RS-232, USB and KBD Wedge)	BC9030-433
BC9030 Base Station/Charger, 910 MHz, Multi-Interface (RS-232, USB and KBD Wedge)	BC9030-910
BC9030 Base/Charger BT Multi-Interface (RS-232, USB and KBW)	BC9030-BT
BC9130 Base Station/ Dual Charger, 433 MHz, Multi-Interface (RS-232, USB and KBD Wedge), Spare Battery Slot	BC9130-433
BC9130 Base Station/ Dual Charger, 910 MHz, Multi-Interface (RS-232, USB and KBD Wedge), Spare Battery Slot	BC9130-910
BC9130 Base/Dual Charger BT Multi-Interface (RS-232, USB and KBW), Spare Battery Slot	BC9130-BT
BC9160 Base Station/Dual Charger, 433 MHz, Multi-Interface (RS-232, USB, KBD Wedge and RS485), Spare Battery Slot	BC9160-433
BC9160 Base Station/Dual Charger, 910 MHz, Multi-Interface (RS-232, USB, KBD Wedge and RS485), Spare Battery Slot	BC9160-910
BC9180 Base Station/Dual Charger, 433 MHz, Ethernet	BC9180-433
BC9180 Base Station/Dual Charger, 910 MHz, Ethernet	BC9180-910
BC9180 Base/Dual Charger BT Ethernet, Spare Battery Slot	BC9180-BT


<b>BATTERIES/BATTERY CHARGERS</b>		
<b>Image:</b>	Battery Charger, 4-Slot, MC-9000; (requires the 90ACC0350 power supply)	MC-P090
	Battery Charger, C-9000	CHR-P090
	Battery Pack, Fixed, FBP-9000	FBP-PM90
	Battery Pack, Fixed, FBP-9000 Rugged	FBP-PM90-01
<b>Image:</b>	Battery Pack, Removable, RBP-9000	RBP-PM90




<b>CABLES</b>	
Cable, IBM USB, 12 VDC, Powers USB, Coiled, 15 ft, CAB-486	CAB-486
Cable, KBW 3151, 347x, 378x, Coiled, CAB-485, 11 ft.	CAB-485
Cable, KBW, PS/2, Coiled, CAB-437, 9 ft.	CAB-437
Cable, KBW, PS/2, External Power, Coiled, CAB-443	CAB-443
Cable, KBW, PS/2, External Power, Straight, CAB-442	CAB-442
Cable, KBW, PS/2, Laptop, Coiled, 3.6 m, CAB-463	CAB-463
Cable, KBW, PS/2, PWR, Coiled 3.6 m, CAB-462	CAB-462
Cable, KBW, PS/2, Straight, CAB-436, 6 ft.	CAB-436
Cable, RS-232 PWR, 25P, Female, Coiled, 3.6 m, CAB-474	CAB-474
Cable, RS-232 PWR, 25P, Female, Coiled, 7.6 m, CAB-477	CAB-477

Cable, RS-232 PWR, 9P, Female, Coiled, 3.6 m, CAB-459	CAB-459
Cable, RS-232 PWR, 9P, Female, Coiled, CAB-434, 8 ft.	CAB-434
Cable, RS-232 PWR, 9P, Female, Straight, 3.2 m, CAB-501	CAB-501
Cable, RS-232 PWR, 9P, Female, Straight, CAB-433, 6 ft.	CAB-433
Cable, RS-232, 25P, Female, Coiled, CAB-471, 10 ft.	CAB-471
Cable, RS-232, 25P, Male, CBX800 Power Off Terminal, Coiled, 12 ft.	CAB-512
Cable, RS-232, 25P, Male, CBX800, External Power, Coil, 12 ft	CAB-509
Cable, RS-232, 25P, Male, Coiled, CAB-472, 10 ft.	CAB-472
Cable, RS-232, 9D, Female, POT, Coiled, 25 ft, 90A052014, CAB-479	CAB-479
Cable, RS-232, 9P, Female, Straight, CAB-448, 6 ft.	CAB-448
Cable, RS-232, 9P, Male, Coiled, 3.6 m, CAB-456	CAB-456
Cable, RS-232, RJ10 Magellan Bi-Optic AUX Port, Coiled, 3.6 m, CAB-461, 12 ft.	CAB-461
Cable, USB, Type A, Coiled, TPUW, CAB-550, 2.4m	CAB-550
Cable, USB, Type A, External Power, Coiled, CAB-441, 8 ft.	CAB-441
Cable, USB, Type A, External Power, Straight, CAB-440, 8 ft.	CAB-440
Cable, USB, Type A, Straight, 3.6 m, CAB-465	CAB-465
Cable, USB, Type A, Straight, CAB-438, 6.5 ft.	CAB-438

CASES/HOLSTERS		
	Holder, Desk/Wall Mount	HLD-P080
	Holster, Universal, HLS-8000	HLS-P080
	Protective Case/Belt Holster, PC-9000	PC-P090

<b>EASEOFCARE AGREEMENTS</b>	
PM/BT93 AR, EofC OVRNGHT, 3 YEARS, COMP	ZSC1PM93AR31
PM/BT93 AR, EofC OVRNGHT, 5 YEARS, COMP	ZSC1PM93AR51
PM/BT93 AR, EofC OVRNGHT, RENEWAL, COMP	ZSC1PM93ARR1
PM/BT93 SR, EofC OVRNGHT, 3 YEARS, COMP	ZSC1PM93SR31
PM/BT93 SR, EofC OVRNGHT, 5 YEARS, COMP	ZSC1PM93SR51
PM/BT93 SR, EofC OVRNGHT, RENEWAL, COMP	ZSC1PM93SRR1
PM/BT93XX AR, EofC 2 DAYS, 3 YEARS, COMP	ZSC2PM93AR31
PM/BT93XX AR, EofC 2 DAYS, 5 YEARS, COMP	ZSC2PM93AR51
PM/BT93XX AR, EofC 2 DAYS, RENEWAL, COMP	ZSC2PM93ARR1
PM/BT93XX AR, EofC 5 DAYS, 3 YEARS	ZSN5PM93AR31
PM/BT93XX AR, EofC 5 DAYS, 5 YEARS	ZSN5PM93AR51
PM/BT93XX AR, EofC 5 DAYS, RENEWAL	ZSN5PM93ARR1
PM/BT93XX SR, EofC 2 DAYS, 3 YEARS, COMP	ZSC2PM93SR31
PM/BT93XX SR, EofC 2 DAYS, 5 YEARS, COMP	ZSC2PM93SR51
PM/BT93XX SR, EofC 2 DAYS, RENEWAL, COMP	ZSC2PM93SRR1
PM/BT93XX SR, EofC 5 DAYS, 3 YEARS	ZSN5PM93SR31
PM/BT93XX SR, EofC 5 DAYS, 5 YEARS	ZSN5PM93SR51
PM/BT93XX SR, EofC 5 DAYS, RENEWAL	ZSN5PM93SRR1
POWERSCAN PM/BT93/95 BASE, 2 DAYS, 3 YEARS, COMPREHENSIVE	ZSC2PM95B31
POWERSCAN PM/BT93/95 BASE, 2 DAYS, 5 YEARS, COMPREHENSIVE	ZSC2PM95B51
POWERSCAN PM/BT93/95 BASE, 2 DAYS, RENEWAL, COMPREHENSIVE	ZSC2PM95BR1
POWERSCAN PM/BT93/95 BASE, 5 DAYS, 3 YEARS	ZSN5PM95B31
POWERSCAN PM/BT93/95 BASE, 5 DAYS, 5 YEARS	ZSN5PM95B51
POWERSCAN PM/BT93/95 BASE, 5 DAYS, RENEWAL	ZSN5PM95BR1
POWERSCAN PM/BT93/95 BASE, OVERNIGHT, 3 YEARS, COMPREHENSIVE	ZSC1PM95B31
POWERSCAN PM/BT93/95 BASE, OVERNIGHT, 5 YEARS, COMPREHENSIVE	ZSC1PM95B51
POWERSCAN PM/BT93/95 BASE, OVERNIGHT, RENEWAL, COMPREHENSIVE	ZSC1PM95BR1

MISCELLANEOUS		
	Replaceable Window, Plastic, RWB-9300	RWD-P093-PL

MOUNTS/STANDS		
	Industrial Take Up Reel	7-0404
	STAND,HANDS-FREE,STD-9000	STD-P090
	Vehicle Mount Kit, VMK-9000	VMK-P090

POWER SUPPLIES/CORDS	
ADAPTER, POWER PLUG, AUSTRALIA	90ACC0309
ADAPTER, POWER PLUG, EURO, 2 PIN	90ACC0307
ADAPTER, POWER PLUG, UK	90ACC0308
ADAPTER, POWER PLUG, US/JAPAN	90ACC0306
Power Adapter, 12V DC, AC/DC Regulated, RoHS (For Use with 6003-XXXX Power Cords)	8-0935
Power Cord, 100V, Japan	6003-0927
Power Cord, 110V, US, Standard	6003-0941
Power Cord, 120V, Taiwan	6003-0929
Power Cord, 120V, US, Twist & Lock	6003-0932
Power Cord, 220V, Australia	6003-0925
Power Cord, 220V, Italy/Chile	6003-0924

Power Cord, 240V, UK	6003-0923
Power Cord, 2-Pin, EU	90ACC1885
Power Cord, 2-Pin, UK	90ACC1887
Power Cord, 2-Pin, US	90ACC1886
Power Cord, AC, IEC/EU	6003-0940
Power Cord, Euro Monitor	6003-0931
Power Cord, IEC C13, Argentina	6003-0926
Power Cord, IEC C13, Brazil (For use with 8-0935)	6003-0942
Power Cord, IEC C13, China	6003-0935
Power Cord, IEC C13, Korea	6003-0930
Power Supply, 12VDC, PG12-10P55 (For Use with 90ACCXXXX Power Cords Sold Separately)	90ACC1883
Power Supply, 12VDC, US, PG12-10P35-US (includes power cord 90ACC1886)	90ACC1920
Power Supply, 5VDC, without power cord	90ACC0287
Power Supply, Switching, 12V, 5A	90ACC0350